

Operating instructions Compax3 I22T11

Positioning via DeviceNet



192-120114 N06 C3I22T11

Release R09-10

December 2010

Windows NT®, Windows 2000™, Windows XP™, Windows Vista are trademarks of Microsoft Corporation.

nonwarranty clause

We checked the contents of this publication for compliance with the associated hard and software. We can, however, not exclude discrepancies and do therefore not accept any liability for the exact compliance. The information in this publication is regularly checked, necessary corrections will be part of the subsequent publications.

Worldwide sales

http://divapps.parker.com/divapps/eme/EME/Contact_sites/Sales%20Channel_Parker-EME.pdf

Production site:



Parker Hannifin GmbH
 Electromechanical Automation Europe [EME]
 Robert-Bosch-Strasse 22
 77656 Offenburg (Germany)
 Tel.: + 49 (0781) 509-0
 Fax: + 49 (0781) 509-98176
 Internet: www.parker-eme.com <http://www.parker-eme.com>
 E-mail: sales.automation@parker.com <mailto:sales.automation@parker.com>

Parker Hannifin GmbH - registered office: Bielefeld HRB 35489
 Geschäftsführung: Dr. Gerd Scheffel, Günter Schrank, Christian Stein, Kees Veraart - Aufsichtsratsvorsitzender: Hansgeorg Greuner

Headquarters:

England: Parker Hannifin PLC • Electromechanical Automation • Arena Business Centre
 Holy Rood Close • Poole, Dorset BH17 7FJ UK
 Tel.: +44 (0)1202 606300 • Fax: +44 (0)1202 606301
 E-mail: sales.automation@parker.com <mailto:sales.automation@parker.com> •
 Internet: www.parker-eme.com <http://www.parker-eme.com>

Italy: Parker Hannifin S.p.A • SSD SBC • Electromechanical Automation • Via Gounod, 1
 I-20092 Cinisello Balsamo (MI), Italy
 Tel.: +39 (0)2 66012459 • Fax: +39 (0)2 66012808
 E-mail: sales.automation@parker.com <mailto:sales.sbc@parker.com> •
 Internet: www.parker-eme.com <http://www.parker-eme.com>

USA: Parker Hannifin Corporation • Electromechanical Automation
 5500 Business Park Drive • Rohnert Park, CA 94928
 Phone #: (800) 358-9068 • FAX #: (707) 584-3715
 E-mail: CMR_help@parker.com mailto:emn_support@parker.com • Internet:
www.compumotor.com <http://www.compumotor.com>

Inhalt

1. Introduction	11
1.1 Device assignment	11
1.2 Scope of delivery	12
1.3 Type specification plate	13
1.4 Packaging, transport, storage	14
1.5 Safety instructions.....	16
1.5.1. General hazards.....	16
1.5.2. Safety-conscious working	16
1.5.3. Special safety instructions	17
1.6 Warranty conditions	18
1.7 Conditions of utilization	19
1.7.1. Conditions of utilization for CE-conform operation.....	19
1.7.1.1 Conditions of utilization mains filter	19
1.7.1.2 Conditions of utilization for cables / motor filter	20
1.7.1.3 Additional conditions of utilization	21
1.7.2. Conditions of utilization for UL certification Compax3S.....	22
1.7.3. Conditions of utilization for UL certification Compax3M	23
1.7.4. Conditions of utilization for UL certification Compax3H.....	24
1.7.5. Current on the mains PE (leakage current).....	25
1.7.6. Supply networks	25
2. Compax3 Xxxx I22T11 Introduction	26
3. Compax3 device description	28
3.1 Meaning of the status LEDs - Compax3 axis controller	28
3.2 Meaning of the status LEDs - PSUP (mains module).....	29
3.3 Connections of Compax3S	30
3.3.1. Compax3S connectors.....	30
3.3.2. Connector and pin assignment C3S.....	31
3.3.3. Control voltage 24VDC / enable connector X4 C3S	33
3.3.4. Motor / Motor brake (C3S connector X3).....	34
3.3.5. Compax3Sxxx V2.....	35
3.3.5.1 Main voltage supply C3S connector X1	35
3.3.5.2 Braking resistor / high voltage DC C3S connector X2	36
3.3.6. Compax3Sxxx V4.....	38
3.3.6.1 Power supply connector X1 for 3AC 400VAC/480VAC-C3S devices	38
3.3.6.2 Braking resistor / high voltage supply connector X2 for 3AC 400VAC/480VAC_C3S devices.....	39
3.3.6.3 Connection of the power voltage of 2 C3S 3AC devices	39

3.4	Installation instructions Compax3M	40
3.5	PSUP/Compax3M Connections	42
3.5.1.	Front connector	42
3.5.2.	Connections on the device bottom.....	43
3.5.3.	Connections of the axis combination.....	44
3.5.4.	Control voltage 24VDC PSUP (mains module)	45
3.5.5.	Mains supply PSUP (mains module) X41	46
3.5.6.	Braking resistor / temperature switch PSUP (mains module)	49
3.5.6.1	Temperature switch PSUP (mains module).....	50
3.5.7.	Motor / motor brake Compax3M (axis controller)	50
3.5.7.1	Measurement of the motor temperature of Compax3M (axis controller)	51
3.5.8.	Safety technology option for Compax3M (axis controller)	52
3.6	Connections of Compax3H	53
3.6.1.	Compax3H plugs/connections	53
3.6.2.	Connection of the power voltage	54
3.6.3.	Compax3H connections front plate	56
3.6.4.	Plug and pin assignment C3H.....	56
3.6.5.	Motor / Motor brake C3H.....	58
3.6.6.	Control voltage 24 VDC C3H.....	59
3.6.7.	Mains connection Compax3H.....	59
3.6.8.	Braking resistor / supply voltage C3H.....	60
3.6.8.1	Connect braking resistor C3H.....	60
3.6.8.2	Power supply voltage DC C3H	60
3.6.8.3	Connection of the power voltage of 2 C3H 3AC devices.....	61
3.7	Communication interfaces	62
3.7.1.	RS232/RS485 interface (plug X10)	62
3.7.2.	Communication Compax3M	63
3.7.2.1	PC - PSUP (Mains module)	63
3.7.2.2	Communication in the axis combination (connector X30, X31)	63
3.7.2.3	Adjusting the basic address	64
3.7.2.4	Setting the axis function.....	64
3.7.3.	DeviceNet connector X23.....	65
3.7.3.1	Adjusting the bus address.....	65
3.7.3.2	Function of the Bus LEDs	66
3.8	Signal interfaces	67
3.8.1.	Resolver / feedback (plug X13)	67
3.8.2.	Analogue / encoder (plug X11).....	68
3.8.2.1	Wiring of analog interfaces	68
3.8.2.2	Connections of the encoder interface	68
3.8.3.	Digital inputs/outputs (plug X12)	69
3.8.3.1	Connection of the digital Outputs/Inputs.....	70
3.8.3.2	Logic proximity switch types	70
3.9	Installation and dimensions Compax3.....	71
3.9.1.	Mounting and dimensions Compax3S	71
3.9.1.1	Mounting and dimensions Compax3S0xxV2	71
3.9.1.2	Mounting and dimensions Compax3S100V2 and S0xxV4	72
3.9.1.3	Mounting and dimensions Compax3S150V2 and S150V4.....	73
3.9.1.4	Mounting and dimensions Compax3S300V4.....	74

3.9.2.	Mounting and dimensions PSUP/C3M.....	75
3.9.2.1	Mounting and dimensions PSUP10/C3M050D6, C3M100D6, C3M150D6.....	75
3.9.2.2	Mounting and dimensions PSUP20/PSUP30/C3M300D6.....	76
3.9.2.3	With upper mounting, the housing design may be different	76
3.9.3.	Mounting and dimensions C3H.....	77
3.9.3.1	Mounting distances, air currents Compax3H050V4	78
3.9.3.2	Mounting distances, air currents Compax3H090V4	78
3.9.3.3	Mounting distances, air currents Compax3H1xxV4.....	79
3.10	Safety function - STO (=safe torque off)	80
3.10.1.	General Description.....	80
3.10.1.1	Important terms and explanations	80
3.10.1.2	Intended use	81
3.10.1.3	Advantages of using the "safe torque off" safety function.	81
3.10.1.4	Devices with the STO (=safe torque off) safety function	82
3.10.2.	STO (= safe torque off) with Compax3S.....	83
3.10.2.1	STO Principle (= Safe Torque Off) with Compax3S	83
3.10.2.2	Conditions of utilization STO (=safe torque off) Safety function.....	85
3.10.2.3	Notes on the STO function.....	85
3.10.2.4	STO application example (= safe torque off)	87
3.10.2.5	Technical Characteristics STO Compax3S	94
3.10.3.	STO (= safe torque off) with Compax3m (Option S1).....	95
3.10.3.1	Safety switching circuits.....	95
3.10.3.2	Safety notes for the STO function in the Compax3M	96
3.10.3.3	Conditions of utilization for the STO function with Compax3M.....	96
3.10.3.4	STO delay times	97
3.10.3.5	Compax3M STO application description	98
3.10.3.6	STO function test	102
3.10.3.7	Technical details of the Compax3M S1 option	104

4. Setting up Compax3..... 105

4.1	Configuration	105
4.1.1.	Test commissioning of a Compax3 axis	107
4.1.2.	Selection of the supply voltage used	107
4.1.3.	Motor selection	107
4.1.4.	Optimize motor reference point and switching frequency of the motor current	108
4.1.5.	Ballast resistor	111
4.1.6.	General drive	111
4.1.7.	Defining the reference system	112
4.1.7.1	Measure reference.....	112
4.1.7.2	Machine Zero	115
4.1.7.3	Travel Limit Settings	132
4.1.7.4	Change assignment direction reversal / limit switches	135
4.1.7.5	Change initiator logic	135
4.1.8.	Defining jerk / ramps	136
4.1.8.1	Speed for positioning and velocity control	136
4.1.8.2	Acceleration for positioning and velocity control.....	136
4.1.8.3	Acceleration / deceleration for positioning.....	136
4.1.8.4	Jerk limit for positioning	136
4.1.8.5	Ramp upon error and de-energize.....	138
4.1.8.6	Jerk for STOP, MANUAL and error	138
4.1.9.	Limit and monitoring settings	139

4.1.9.1	Current (Torque) Limit.....	139
4.1.9.2	Positioning window - Position reached	139
4.1.9.3	Following error limit.....	140
4.1.9.4	Maximum operating speed.....	141
4.1.10.	Encoder simulation	142
4.1.10.1	Encoder bypass with Feedback module F12 (for direct drives).....	142
4.1.11.	I/O Assignment	142
4.1.12.	Position mode in reset operation.....	144
4.1.12.1	Examples in the help file.....	145
4.1.13.	Reg-related positioning / defining ignore zone	146
4.1.14.	Write into set table.....	147
4.1.14.1	Programmable status bits (PSBs).....	147
4.1.15.	Motion functions.....	148
4.1.15.1	MoveAbs and MoveRel.....	148
4.1.15.2	Reg-related positioning (RegSearch, RegMove).....	149
4.1.15.3	Electronic gearbox (Gearing).....	153
4.1.15.4	Speed specification (Velocity).....	154
4.1.15.5	Stop command (Stop).....	154
4.1.16.	Error response	154
4.1.17.	Configuration name / comments.....	155
4.1.18.	Dynamic positioning	155
4.2	Configuring the signal Source.....	157
4.2.1.	Signal source of the load feedback system.....	157
4.2.2.	Select signal source for Gearing	157
4.2.2.1	Signal source HEDA	158
4.2.2.2	Encoder A/B 5V, step/direction or SSI feedback as signal source	158
4.2.2.3	+/-10V analog speed setpoint value as signal source	160
4.3	Load control	161
4.3.1.	Configuration of load control	163
4.3.2.	Error: Position difference between load mounted and motor feedback too high	164
4.3.3.	Load control signal image	164
4.3.3.1	Object for the load control (overview)	165
4.3.3.2	Objects for load control.....	165
4.4	Optimization	166
4.4.1.	Optimization window.....	167
4.4.2.	Scope	168
4.4.2.1	Monitor information	168
4.4.2.2	User interface.....	169
4.4.2.3	Example: Setting the Oscilloscope	174
4.4.3.	Controller optimization	176
4.4.3.1	Introduction	176
4.4.3.2	Configuration.....	179
4.4.3.3	Automatic controller design.....	197
4.4.3.4	Setup and optimization of the control	209
4.4.4.	Signal filtering with external command value	241
4.4.4.1	Signal filtering for external setpoint specification and electronic gearbox	241
4.4.4.2	Signal filtering for external setpoint specification and electronic cam	242
4.4.5.	Input simulation	244
4.4.5.1	Calling up the input simulation.....	244

4.4.5.2	Operating Principle	245
4.4.6.	Setup mode	246
4.4.6.1	Motion objects in Compax3.....	247
4.4.7.	Load identification	248
4.4.7.1	Principle	248
4.4.7.2	Boundary conditions	248
4.4.7.3	Process of the automatic determination of the load characteristic value (load identification)	249
4.4.7.4	Tips	250
4.4.8.	Alignment of the analog inputs	251
4.4.8.1	Offset alignment.....	251
4.4.8.2	Gain alignment.....	251
4.4.8.3	Signal processing of the analog inputs	252
4.4.9.	C3 ServoSignalAnalyzer	253
4.4.9.1	ServoSignalAnalyzer - function range	253
4.4.9.2	Signal analysis overview.....	254
4.4.9.3	Installation enable of the ServoSignalAnalyzer	255
4.4.9.4	Analyses in the time range.....	257
4.4.9.5	Measurement of frequency spectra	260
4.4.9.6	Measurement of frequency responses	263
4.4.9.7	Overview of the user interface	270
4.4.9.8	Basics of frequency response measurement.....	284
4.4.9.9	Examples are available as a movie in the help file.....	289
4.4.10.	ProfileViewer for the optimization of the motion profile	290
4.4.10.1	Mode 1: Time and maximum values are deduced from Compax3 input values	290
4.4.10.2	Mode 2: Compax3 input values are deduced from times and maximum values	291
4.4.11.	Turning the motor holding brake on and off.....	292

5. Communication293

5.1	Compax3 communication variants.....	293
5.1.1.	PC <-> Compax3 (RS232).....	294
5.1.2.	PC <-> Compax3 (RS485).....	296
5.1.3.	PC <-> C3M device combination (USB).....	297
5.1.4.	USB-RS485 Moxa Uport 1130 adapter	298
5.1.5.	ETHERNET-RS485 NetCOM 113 adapter	299
5.1.6.	Modem MB-Connectline MDH 500 / MDH 504	300
5.1.7.	C3 settings for RS485 two wire operation.....	301
5.1.8.	C3 settings for RS485 four wire operation	302
5.2	COM port protocol	303
5.2.1.	RS485 settings values.....	303
5.2.2.	ASCII - record	304
5.2.3.	Binary record	305
5.3	Remote diagnosis via Modem.....	308
5.3.1.	Structure	308
5.3.2.	Configuration of local modem 1	309
5.3.3.	Configuration of remote modem 2	310
5.3.4.	Recommendations for preparing the modem operation	310
5.4	DeviceNet.....	311

5.4.1.	DeviceNet Configuration	311
5.4.2.	Error Reaction on Bus Failure	311
5.4.3.	DeviceNet Operating modes	312
5.4.3.1	Operating mode: Speed control.....	313
5.4.3.2	Operating mode: Direct positioning	314
5.4.3.3	Operating mode: Positioning with set selection.....	316
5.4.3.4	Controlword /Statusword.....	318
5.4.4.	State machine	327
5.4.5.	DeviceNet object classes	329
5.4.5.1	Overview of the DeviceNet object classes.....	330
5.4.5.2	Object classes.....	330
5.4.5.3	Manufacturer-specific object class.....	331
5.4.5.4	Data formats of the bus objects	337
5.4.6.	DeviceNet application description	340
6.	Status values	341
6.1	D/A-Monitor	341
6.2	Status values	341
7.	Error	342
7.1	Error list	342
8.	Order code	343
8.1	Order code device: Compax3	343
8.2	Order code for mains module: PSUP	344
8.3	Order code for accessories	344
9.	Compax3 Accessories	348
9.1	Parker servo motors	348
9.1.1.	Direct drives	348
9.1.1.1	Transmitter systems for direct drives.....	349
9.1.1.2	Linear motors	350
9.1.1.3	Torque motors.....	350
9.1.2.	Rotary servo motors	350
9.2	EMC measures	351
9.2.1.	Mains filter	351
9.2.1.1	Mains filter NFI01/01.....	352
9.2.1.2	Mains filter NFI01/02.....	352
9.2.1.3	Mains filter for NFI01/03.....	353
9.2.1.4	Mains filter NFI02/0x.....	353
9.2.1.5	Mains filter NFI03/01& NFI03/03	354
9.2.1.6	Mains filter NFI03/02.....	355
9.2.2.	Motor output filter	356
9.2.2.1	Motor output filter MDR01/04.....	356
9.2.2.2	Motor output filter MDR01/01.....	356
9.2.2.3	Motor output filter MDR01/02.....	357

9.2.2.4	Wiring of the motor output filter.....	357
9.2.3.	Mains filters.....	358
9.2.3.1	Mains filter for PSUP30.....	358
9.3	Connections to the motor	359
9.3.1.	Resolver cable	360
9.3.2.	SinCos© cable.....	361
9.3.3.	EnDat cable	362
9.3.4.	Motor cable.....	362
9.3.4.1	Connection of terminal box MH145 & MH205	363
9.3.5.	Encoder cable	364
9.4	External braking resistors.....	365
9.4.1.	Permissible braking pulse powers of the braking resistors	366
9.4.1.1	Calculation of the BRM cooling time.....	367
9.4.1.2	Permissible braking pulse power: BRM08/01 with C3S015V4 / C3S038V4.....	368
9.4.1.3	Permissible braking pulse power: BRM08/01 with C3S025V2	368
9.4.1.4	Permissible braking pulse power: BRM09/01 with C3S100V2	369
9.4.1.5	Permissible braking pulse power: BRM10/01 with C3S150V4	369
9.4.1.6	Permissible braking pulse power: BRM10/02 with C3S150V4	370
9.4.1.7	Permissible braking pulse power: BRM05/01 with C3S063V2	370
9.4.1.8	Permissible braking pulse power: BRM05/01 with C3S075V4	371
9.4.1.9	Permissible braking pulse power: BRM05/02 with C3S075V4	371
9.4.1.10	Permissible braking pulse power: BRM04/01 with C3S150V2	372
9.4.1.11	Permissible braking pulse power: BRM04/01 with C3S300V4	372
9.4.1.12	Permissible braking pulse power: BRM04/02 with C3S150V2	373
9.4.1.13	Permissible braking pulse power: BRM04/02 with C3S300V4	373
9.4.1.14	Permissible braking pulse power: BRM04/03 with C3S300V4	374
9.4.1.15	Permissible braking pulse power: BRM11/01 with C3H0xxV4	374
9.4.1.16	Permissible braking pulse power: BRM12/01 with C3H1xxV4	375
9.4.1.17	Permissible braking pulse power: BRM13/01 with PSUP10D6	375
9.4.1.18	Permissible braking pulse power: BRM14/01 with PSUP10D6	375
9.4.2.	Dimensions of the braking resistors	376
9.4.2.1	BRM8/01braking resistors.....	376
9.4.2.2	BRM5/01 braking resistor	376
9.4.2.3	Braking resistor BRM5/02, BRM9/01 & BRM10/01	376
9.4.2.4	Ballast resistor BRM4/0x and BRM10/02	377
9.4.2.5	Braking resistor BRM11/01 & BRM12/01	377
9.4.2.6	Ballast resistor BRM13/01 & BRM14/01	378
9.5	Condenser module C4.....	379
9.6	Operator control module BDM.....	380
9.7	EAM06: Terminal block for inputs and outputs.....	381
9.8	Interface cable.....	383
9.8.1.	RS232 cable.....	383
9.8.2.	RS485 cable to Pop	384
9.8.3.	I/O interface X12 / X22	385
9.8.4.	Ref X11.....	385
9.8.5.	Encoder coupling of 2 Compax3 axes.....	386
9.8.6.	Modem cable SSK31.....	387
9.9	Options M1x	388

9.9.1.	Input/output option M12	388
9.9.1.1	Assignment of the X22 connector	388
9.9.2.	HEDA (motion bus) - Option M11	389
9.9.3.	Option M10 = HEDA (M11) & I/Os (M12)	391

10. Technical Characteristics392

11. Index.....410

1. Introduction

In this chapter you can read about:

Device assignment	11
Scope of delivery	12
Type specification plate	13
Packaging, transport, storage	14
Safety instructions	16
Warranty conditions	18
Conditions of utilization	19

1.1 Device assignment

This manual is valid for the following devices:

- ◆ Compax3S025V2 + supplement
- ◆ Compax3S063V2 + supplement
- ◆ Compax3S100V2 + supplement
- ◆ Compax3S150V2 + supplement
- ◆ Compax3S015V4 + supplement
- ◆ Compax3S038V4 + supplement
- ◆ Compax3S075V4 + supplement
- ◆ Compax3S150V4 + supplement
- ◆ Compax3S300V4 + supplement
- ◆ Compax3H050V4 + supplement
- ◆ Compax3H090V4 + supplement
- ◆ Compax3H125V4 + supplement
- ◆ Compax3H155V4 + supplement
- ◆ Compax3M050D6 + supplement
- ◆ Compax3M100D6 + supplement
- ◆ Compax3M150D6 + supplement
- ◆ Compax3M300D6 + supplement
- ◆ PSUP10D6
- ◆ PSUP20D6

With the supplement:

- ◆ F10 (Resolver)
- ◆ F11 (SinCos®)
- ◆ F12 (linear and rotary direct drives)
- ◆ I22 T11

1.2 Scope of delivery

The following items are furnished with the device:

- ◆ Manuals*
 - ◆ Installation manual (German, English, French)
 - ◆ Compax3 DVD
 - ◆ Startup Guide (German / English)
- *Comprehensiveness of documentation depends on device type
- ◆ Device accessories
 - Device accessories for Compax3S
 - ◆ Cable clamps in different sizes for large area shielding of the motor cable, the screw for the cable clamp as well as
 - ◆ the mating plug connectors for the Compax3S plug connectors X1, X2, X3, and X4
 - ◆ a toroidal core ferrite for one cable of the motor holding brake
 - ◆ Lacing cord
 - Device accessories for Compax3M
 - ◆ Cable clamps in different sizes for large area shielding of the motor cable, the screw for the cable clamp as well as
 - ◆ the matching plug for the Compax3M connectors X14, X15, X43
 - ◆ a toroidal core ferrite for one cable of the motor holding brake
 - ◆ an interface cable (SSK28/23) for communication within the axis combination
 - Device accessories for PSUP
 - ◆ Matching plug for the PSUP connectors X9, X40, X41
 - ◆ 2 bus terminal connectors (BUS07/01) for mains module and the last axis controller in the combination
 - Device accessories for Compax3H
 - ◆ Mating connector for X3 and X4
 - ◆ SSK32/20: RS232 adapter cable (programming port C3HxxxV4 - SSK1 - PC)
 - ◆ VBK17/01: SubD jumper mounted

1.3 Type specification plate

Compax3 - Type specification plate (example):

The present device type is defined by the type specification plate (on the housing):



Explanation:

1	Type designation The complete order designation of the device (2, 5, 6, 9, 8).
2	C3: Abbreviation for Compax3
	S025: Single axis device, nominal device current in 100mA (025=2.5A) M050: Multi-axis device, nominal device current in 100mA (050=5A) H050: High power device, nominal device current in 1A (050=50A)
	D6: Designation nominal supply V2: Mains supply voltage (2=230VAC/240VAC, 4=400VAC/480VAC)
3	Unique number of the particular device
4	Nominal supply voltage Power Input: Input supply data Power Output: Output data
5	Designation of the feedback system F10: Resolver F11: SinCos© / Single- or Multiturn F12: Feedback module for direct drives
6	Device interface I10: Analog, step/direction and encoder input I11 / I12: Digital Inputs / Outputs and RS232 / RS485 I20: Profibus DP / I21: CANopen / I22: DeviceNet / I30: Ethernet Powerlink / I31: EtherCAT / I32: Profinet C20: integrated controller C3 <i>powerPLmC</i> , Linux & Web server
7	Date of factory test
8	Options Mxx: I/O extension, HEDA Sx: optional safety technology on C3M
9	Technology function T10: Servo drive T11: Positioning T30: Motion control programmable according to IEC61131-3 T40: Electronic cam
10	CE compliance
11	Certified safety technology (corresponding to the logo displayed)
12	UL certified (corresponding to the logo displayed)

1.4 Packaging, transport, storage

Packaging material and transport



Caution!

The packaging material is inflammable, if it is disposed of improperly by burning, lethal fumes may develop.

The packaging material must be kept and reused in the case of a return shipment. Improper or faulty packaging may lead to transport damages.

Make sure to transport the drive always in a safe manner and with the aid of suitable lifting equipment (**Weight** (see on page 392, see on page 404)). Do never use the electric connections for lifting. Before the transport, a clean, level surface should be prepared to place the device on. The electric connections may not be damaged when placing the device.

First device checkup

- ◆ Check the device for signs of transport damages.
- ◆ Please verify, if the indications on the **Type identification plate** (see on page 13) correspond to your requirements.
- ◆ Check if the consignment is complete.

Disposal

This product contains materials that fall under the special disposal regulation from 1996, which corresponds to the EC directory 91/689/EEC for dangerous disposal material. We recommend to dispose of the respective materials in accordance with the respectively valid environmental laws. The following table states the materials suitable for recycling and the materials which have to be disposed of separately.

Material Option	suitable for recycling	Disposal
Metal	yes	no
Plastic materials	yes	no
Circuit boards	no	yes

Please dispose of the circuit boards according to one of the following methods:

- ◆ Burning at high temperatures (at least 1200°C) in an incineration plant licensed in accordance with part A or B of the environmental protection act.
- ◆ Disposal via a technical waste dump which is allowed to take on electrolytic aluminum condensers. Do under no circumstances dump the circuit boards at a place near a normal waste dump.

Storage

If you do not wish to mount and install the device immediately, make sure to store it in a dry and clean **environment** (see on page 406). Make sure that the device is not stored near strong heat sources and that no metal chippings can get into the device.

Please note in the event of storage >1 year:

Forming the capacitors

Forming the capacitors only required with 400VAC axis controllers and PSUP mains module

If the device was stored longer than one year, the intermediate capacitors must be re-formed!

Forming sequence:

- ◆ Remove all electric connections
- ◆ Supply the device with 230VAC single phase for 30 minutes
 - ◆ via the L1 and L2 terminals on the device or
 - ◆ multi axis devices via L1 and L2 on the PSUP mains module

1.5 Safety instructions

In this chapter you can read about:

General hazards	16
Safety-conscious working	16
Special safety instructions	17

1.5.1. General hazards

General Hazards on Non-Compliance with the Safety Instructions

The device described in this manual is designed in accordance with the latest technology and is safe in operation. Nevertheless, the device can entail certain hazards if used improperly or for purposes other than those explicitly intended.

Electronic, moving and rotating components can

- ◆ constitute a hazard for body and life of the user, and
- ◆ cause material damage

Usage in accordance with intended purpose

The device is designed for operation in electric power drive systems (VDE0160). Motion sequences can be automated with this device. Several motion sequences can be combined by interconnecting several of these devices. Mutual interlocking functions must be incorporated for this purpose.

1.5.2. Safety-conscious working

This device may be operated only by qualified personnel.

Qualified personnel in the sense of these operating instructions consists of:

- ◆ Persons who, by virtue to their training, experience and instruction, and their knowledge of pertinent norms, specifications, accident prevention regulations and operational relationships, have been authorized by the officer responsible for the safety of the system to perform the required task and in the process are capable of recognizing potential hazards and avoiding them (definition of technical personnel according to VDE105 or IEC364),
- ◆ Persons who have a knowledge of first-aid techniques and the local emergency rescue services.
- ◆ persons who have read and will observe the safety instructions.
- ◆ Those who have read and observe the manual or help (or the sections pertinent to the work to be carried out).

This applies to all work relating to setting up, commissioning, configuring, programming, modifying the conditions of utilization and operating modes, and to maintenance work.

This manual and the help information must be available close to the device during the performance of all tasks.

1.5.3. Special safety instructions

- ◆ Check the correct association of the device and its documentation.
- ◆ Never detach electrical connections while voltage is applied to them.
- ◆ Safety devices must be provided to prevent human contact with moving or rotating parts.
- ◆ Make sure that the device is operated only when it is in perfect condition.
- ◆ Implement and activate the stipulated safety functions and devices.
- ◆ Operate the device only with the housing closed.
- ◆ Make sure that all devices are sufficiently fixed.
- ◆ Check that all live terminals are secured against contact. Perilous voltage levels of up to 850V occur.
- ◆ Do not bypass power direct current

Achtung bei Konfigurations - Download bei Master - Slave Kopplungen (Elektronisches Getriebe, Kurvenscheibe)

Deaktivieren Sie den Antrieb vor dem Konfigurationsdownload: Master- und Slaveachse.



Caution!

Due to movable machine parts and high voltages, the device can pose a lethal danger. Danger of electric shock in the case of non-respect of the following instructions. The device corresponds to DIN EN 61800-3, i.e. it is subject to limited sale. The device can emit disturbances in certain local environments. In this case, the user is liable to take suitable measures.

- ◆ The device must be permanently grounded due to high earth leakage currents.
- ◆ The drive motor must be grounded with a suitable protective lead.
- ◆ The devices are equipped with high voltage DC condensers. Before removing the protective cover, the discharging time must be awaited. After switching off the supply voltage, it may take up to 10 minutes to discharge the capacitors. Danger of electric shock in case of non respect.
- ◆ Before you can work on the device, the supply voltage must be switched off at the L1, L2 and L3 clamps. Wait at least 10 minutes so that the power direct current may sink to a secure value (<50V). Check with the aid of a voltmeter, if the voltage at the DC+ and DC- clamps has fallen to a value below 50V. Danger of electric shock in case of non respect.
- ◆ Do never perform resistance tests with elevated voltages (over 690V) on the wiring without separating the circuit to be tested from the drive.
- ◆ Please exchange devices only in currentless state and, in an axis system, only in a defined original state.
- ◆ In the event of a axis controller device exchange it is absolutely necessary to transfer the configuration determining the correct operation of the drive to the device, before the device is put into operation. Depending on the operation mode, a machine zero run will be necessary.
- ◆ The device contains electrostatically sensitive components. Please heed the electrostatic protection measures while working at/with the device as well as during installation and maintenance.
- ◆ Operation of the PSUP30 only with mains filter.



Attention - hot surface!

The heat dissipator can reach very high temperatures (>70°C)

Protective seals



Caution!

The user is responsible for protective covers and/or additional safety measures in order to prevent damages to persons and electric accidents.

Please note in the event of storage >1 year:

Forming the capacitors

Forming the capacitors only required with 400VAC axis controllers and PSUP mains module

If the device was stored longer than one year, the intermediate capacitors must be re-formed!

Forming sequence:

- ◆ Remove all electric connections
- ◆ Supply the device with 230VAC single phase for 30 minutes
 - ◆ via the L1 and L2 terminals on the device or
 - ◆ multi axis devices via L1 and L2 on the PSUP mains module

1.6 Warranty conditions

- ◆ The device must not be opened.
- ◆ Do not make any modifications to the device, except for those described in the manual.
- ◆ Make connections to the inputs, outputs and interfaces only in the manner described in the manual.
- ◆ Fix the devices according to the **mounting instructions** (see on page 71, see on page 77).
We cannot provide any guarantee for other mounting methods.

Note on exchange of options

Device options must be exchanged in the factory to ensure hardware and software compatibility.

- ◆ When installing the device, make sure the heat dissipators of the device receive sufficient air and respect the recommended mounting distances of the devices with integrated ventilator fans in order to ensure free circulation of the cooling air.
- ◆ Make sure that the mounting plate is not exposed to external temperature influences.

1.7 Conditions of utilization

In this chapter you can read about:

Conditions of utilization for CE-conform operation	19
Conditions of utilization for UL certification Compax3S	22
Conditions of utilization for UL certification Compax3M	23
Conditions of utilization for UL certification Compax3H	24
Current on the mains PE (leakage current)	25
Supply networks	25

1.7.1. Conditions of utilization for CE-conform operation

- Industry and trade -

The EC guidelines for electromagnetic compatibility 2004/108/EC and for electrical operating devices for utilization within certain voltage limits 2006/95/EC are fulfilled when the following boundary conditions are observed:

Operation of the devices only in the condition in which they were delivered, i.e. with all housing panels.

In order to ensure contact protection, all mating plugs must be present on the device connections even if they are not wired.

Please respect the specifications of the manual, especially the technical characteristics (mains connection, circuit breakers, output data, ambient conditions,...).

1.7.1.1 Conditions of utilization mains filter

Mains filter: A mains filter is required in the mains input line if the motor cable exceeds a certain length. Filtering can be provided centrally at the system mains input or separately for jedes Gerät bzw. bei C3M für jeden Achsverbund.

Use of the devices in a commercial and residential area (limit value class in accordance with EN 61800-3)

The following mains filters are available for independent utilization:

Device: Compax3S	Limit value class	Motor cable length	Mains filter Order No.:
S0xxV2	C2	< 10 m	without
	C2	> 10 m, < 100 m	NFI01/01
S1xxV2, S0xxV4, S150V4	C2	< 10 m	without
	C2	> 10 m, < 100 m	NFI01/02
S300V4	C3	< 10 m	without
	C2, C3	> 10 m, < 100 m	NFI01/03
Device: Compax3H	Limit value class	Motor cable length	Mains filter Order No.:
H050V4	C2	< 10 m	without
	C2	> 10 m, < 50 m	NFI02/01
H090V4	C2	< 10 m	without
	C2	> 10 m, < 50 m	NFI02/02
H1xxV4	C2	< 10 m	without
	C2	> 10 m, < 50 m	NFI02/03

Use of the devices in the industrial area (limit values class C3 in accordance with EN 61800-3)

The following mains filters are available for independent utilization:

Device: PSU	Limit value class	Reference: Axis system with motor cable	Mains filter Order No.:
P10	C3	< 6 x 10 m	NFI03/01
P10	C3	< 6 x 50 m	NFI03/02
P20	C3	< 6 x 50 m	NFI03/03
P30	C3	< 6 x 50 m	NFI03/03

Connection length: Connection between mains filter and device:

unshielded: < 0.5 m

shielded < 5 (fully shielded on ground - e.g. ground of control cabinet)

1.7.1.2 Conditions of utilization for cables / motor filter

Motor and Feedback cable:

Operation of the devices only with motor and feedback cables whose plugs contain a special full surface area screening.

Compax3S motor cable

< 100 m (the cable should not be rolled up!)

A **motor output filter** (see on page 356) is required for motor cables >20 m:

- ◆ MDR01/04 (max. 6.3 A rated motor current)
- ◆ MDR01/01 (max. 16 A rated motor current)
- ◆ MDR01/02 (max. 30 A rated motor current)

Compax3H motor cable

A motor output filter is required for motor cables >50m. Please contact us.

Compax3M motor cable

<80m per axis (the cable must not be rolled up!)

The entire length of the motor cable per axis combination may not exceed 300m.

A **motor output filter** (see on page 356) is required for motor cables >20 m:

- ◆ MDR01/04 (max. 6.3 A rated motor current)
- ◆ MDR01/01 (max. 16 A rated motor current)
- ◆ MDR01/02 (max. 30 A rated motor current)

Shielding connection of the motor cable

The cable must be fully-screened and connected to the Compax3 housing. Use the cable clamps/shield connecting terminals furnished with the device.

The shield of the cable must also be connected with the motor housing. The fixing (via plug or screw in the terminal box) depends on the motor type.

Compax3 encoder cable:

< 100 m

Compax3M encoder cable:

< 80m

Cable for Compax3S, Compax3M

Corresponding to the specifications of the terminal clamp with a temperature range of up to 60°C.

Cable for Compax3H Corresponding to the specifications of the terminal clamp with a temperature range of up to 75°C.

- Cable installation:**
- ◆ Signal lines and power lines should be installed as far apart as possible.
 - ◆ Signal lines should never pass close to excessive sources of interference (motors, transformers, contactors etc.).
 - ◆ Do not place mains filter output cable parallel to the load cable.

1.7.1.3 Additional conditions of utilization

Motors: Operation with standard motors.

Control: Use only with aligned controller (to avoid control loop oscillation).

Grounding: Connect the filter housing and the device to the cabinet frame, making sure that the contact area is adequate and that the connection has low resistance and low inductance.

Never mount the filter housing and the device on paint-coated surfaces!

Compax3S300V4 For CE and UL conform operation of the Compax3S300V4, a mains filter is compulsory:

- ◆ 400 VAC / 0.740 mH certified in accordance with EN 61558-1 bzw. 61558-2-2
- ◆ We offer the mains filter as an accessory: LIR01/01

Accessories: Make sure to use only the accessories recommended by Parker

Connect all cable shields at both ends, ensuring large contact areas!

Warning:

This is a product in the restricted sales distribution class according to EN 61800-3. In a domestic area this product can cause radio frequency disturbance, in which case the user may be required to implement appropriate remedial measures.

1.7.2. Conditions of utilization for UL certification Compax3S

UL certification for Compax3S

conform to UL:	◆ according to UL508C
Certified	◆ E-File_No.: E235342

The UL certification is documented by a "UL" logo on the device (type specification plate).



"UL" logo:

Conditions of utilization

- ◆ The devices are only to be installed in a degree of contamination 2 environment (maximum).
- ◆ The devices must be appropriately protected (e.g. by a switching cabinet).
- ◆ The X2 terminals are not suitable for field wiring.
- ◆ Tightening torque of the field wiring terminals (green Phoenix plugs)
 - ◆ C3S0xxV2 0.57 - 0.79Nm 5 - 7Lb.in
 - ◆ C3S1xxV2, 0.57 - 0.79Nm 5 - 7Lb.in
C3S0xxV4, C3S150V4
 - ◆ C3S300V4 1.25 - 1.7Nm 11 - 15Lb.in
- ◆ Temperature rating of field installed conductors shall be at least 60°C Use copper lines only
Please use the cables described in the **accessories chapter** (see on page 343, see on page 344), they feature a temperature rating of at least 60°C.
- ◆ Maximum Surrounding Air Temperature: 45°C.
- ◆ Suitable for use on a circuit capable of delivering not more than 5000 rms symmetrical amperes and 480 volts maximum.



ATTENTION

Danger of electric shock.

Discharge time of the bus condenser is 10 minutes.

- ◆ The drive provides internal motor overload protection.
This must be set so that 200% of the motor nominal current are not exceeded.
- ◆ Cable cross-sections
 - ◆ Mains input: corresponding to the recommended fuses.
 - ◆ Motor cable: corresponding to the **Nominal output currents** (see on page 395, see on page 396)
 - ◆ Maximum cross-section limited by the terminals mm² / AWG
 - ◆ C3S0xxV2 2.5mm² AWG 12
 - ◆ C3S1xxV2, 4.0mm² AWG 10
C3S0xxV4, C3S150V4
 - ◆ C3S300V4 6.0mm² AWG 7
- ◆ Circuit breaker
In addition to the main circuit breaker, the devices must be equipped with a S271 K or S273 K circuit breaker with K characteristic made by ABB.
 - ◆ C3S025V2: ABB, nom 480V 10A, 6kA
 - ◆ C3S063V2: ABB, nom 480V, 16A, 6kA
 - ◆ C3S100V2: ABB, nom 480V, 16A, 6kA
 - ◆ C3S150V2: ABB, nom 480V, 20A, 6kA
 - ◆ C3S015V4: ABB, nom 480V, 6A, 6kA
 - ◆ C3S038V4: ABB, nom 480V, 10A, 6kA
 - ◆ C3S075V4: ABB, nom 480V, 16A, 6kA
 - ◆ C3S150V4: ABB, nom 480V, 20A, 6kA
 - ◆ C3S300V4: ABB, nom 480V, 25A, 6kA

1.7.3. Conditions of utilization for UL certification Compax3M

UL-approval for PSUP/Compax3M

conform to UL:	◆ according to UL508C
Certified	◆ E-File_No.: E235342

The UL certification is documented by a "UL" logo on the device (type specification plate).



Conditions of utilization

- ◆ The devices are only to be installed in a degree of contamination 2 environment (maximum).
- ◆ The devices must be appropriately protected (e.g. by a switching cabinet).
- ◆ Tightening torque of the field wiring terminals (green Phoenix plugs)

Device	X40: Ballast resistor	X41: Mains connector	X9: 24VDC
PSUP10	0.5 Nm (4.43Lb.in)	1.2 Nm (10.62Lb.in)	1.2 Nm (10.62Lb.in)
PSUP20	0.5 Nm (4.43Lb.in)	1.7 Nm (15Lb.in)	1.2 Nm (10.62Lb.in)
PSUP30	UL approval in preparation		
Device	X43: Motor connector	X15: Temperature monitoring	
C3M050-150	0.5Nm (4.43Lb.in)	0.22Nm (1.95Lb.in)	
C3M300	1.2Nm (10.62Lb.in)	0.22Nm (1.95Lb.in)	

- ◆ Temperature rating of field installed conductors shall be at least 60°C Use copper lines only
Please use the cables described in the **accessories chapter** (see on page 343, see on page 344), they feature a temperature rating of at least 60°C.
- ◆ Maximum Surrounding Air Temperature: 40°C.
- ◆ Suitable for use on a circuit capable of delivering not more than 5000 rms symmetrical amperes and 480 volts maximum.



Caution!

Danger of electric shock.

Discharge time of the bus capacitor is 10 minutes.

- ◆ The drive provides internal motor overload protection.
This must be set so that 200% of the motor nominal current are not exceeded.
- ◆ Cable cross-sections
 - ◆ Mains input: corresponding to the recommended fuses.
 - ◆ Motor cable: corresponding to the **Nominal output currents** (see on page 395, see on page 396)
- ◆ Maximum cross-section limited by the terminals mm² / AWG

Line cross-sections of the power connections (on the device bottoms)

Compax3 device:	Cross-section: Minimum... Maximum [with conductor sleeve]
M050, M100, M150	0.25 ... 4 mm ² (AWG: 23 ... 11)
M300	0.5 ... 6 mm ² (AWG: 20 ... 10)
PSUP10	Mains supply: 0.5 ... 6 mm ² (AWG: 20 ... 10) Braking resistor: 0.25 ... 4 mm ² (AWG: 23 ... 11)
PSUP20 & PSUP30	Mains supply: 0.5 ... 16 mm ² (AWG: 20 ... 6) Braking resistor: 0.25 ... 4 mm ² (AWG: 23 ... 11)

1.7.4. Conditions of utilization for UL certification Compax3H

UL certification for Compax3H

Conform to UL:	◆ according to UL508C
Certified	◆ E-File_No.: E235342

The UL certification is documented by a "UL" logo on the device (type specification plate).

"UL" logo:



Conditions of utilization

- ◆ The devices are only to be installed in a degree of contamination 2 environment (maximum).
- ◆ The devices must be appropriately protected (e.g. by a switching cabinet).
- ◆ Tightening Torque of the Field Wiring Terminals.

Terminal clamps - max. line cross sections

The line cross sections must correspond to the locally valid safety regulations. The local regulations have always priority.

	Power clamps (minimum/maximum section)	
C3H050V4	2.5 / 16mm ²	
	Massive	Multewire
C3H090V4	16 / 50mm ²	25 / 50mm ²
C3H1xxV4	25 / 95mm ²	35 / 95mm ²

The standard connection clamps of Compax3H090V4 and Compax3H1xxV4 are not suitable for flat line bars.

Temperature rating of field installed conductors shall be at least 75°C. Do only use copper lines.

- ◆ Maximum Surrounding Air Temperature: 45°C.
- ◆ Short Circuit Rating - Suitable for use on a circuit capable of delivering not more than 10000 RMS symmetrical amperes and 480 volts maximum.

CAUTION Danger of electric shock.



Upon removing power to the equipment, wait minimum 10 minutes before accessing the drive to ensure internal voltage levels are less than 50VDC.

- ◆ The drive provides internal motor overload protection.
This must be set so that 200% of the motor nominal current are not exceeded.
- ◆ Cable cross-sections
 - ◆ Mains input: corresponding to the recommended fuses.
 - ◆ Motor cable: corresponding to the **Nominal output currents** (see on page 395, see on page 396)
 - ◆ This device is provided with Solid State Short Circuit (output) Protection.

1.7.5. Current on the mains PE (leakage current)



Caution!

This product can cause a direct current in the protective lead. If a residual current device (RCD) is used for protection in the event of direct or indirect contact, only a type B (all current sensitive) RCD is permitted on the current supply side of this product. Otherwise, a different protective measure must be taken, such as separation from the environment by doubled or enforced insulation or separation from the mains power supply by means of a transformer.

Please heed the connection instructions of the RCD supplier.

Mains filters do have high leakage currents due to their internal capacity. An internal mains filter is usually integrated into the servo controllers. Additional leakage currents are caused by the capacities of the motor cable and of the motor windings. Due to the high clock frequency of the power output stage, the leakage currents do have high-frequency components. Please check if the FI protection switch is suitable for the individual application.

If an external mains filter is used, an additional leakage current will be produced.

The figure of the leakage current depends on the following factors:

- ◆ Length and properties of the motor cable
- ◆ Switching frequency
- ◆ Operation with or without external mains filter
- ◆ Motor cable with or without shield network
- ◆ Motor housing grounding (how and where)

Remark:

- ◆ The leakage current is important with respect to the handling and usage safety of the device.
- ◆ A pulsing leakage current occurs if the supply voltage is switched on.

Please note:


The device must be operated with effective grounding connection, which must comply with the local regulations for high leakage currents (>3.5mA).

Due to the high leakage currents it is not advisable to operate the servo drive with an earth leakage circuit breaker.


1.7.6. Supply networks

This product is designed for fixed connection to TN networks (TN-C, TN-C-S or TN-S). Please note that the line-earth voltage may not exceed 300VAC.

- ◆ When grounding the neutral conductor, mains voltages of up to 480VAC are permitted.



- ◆ When grounding an external conductor (delta mains, two-phase mains), mains voltages (external conductor voltages) of up to 240VAC are permitted.



Devices which are to be connected to an IT network must be provided with a separating transformer. Then the devices are operated locally as in a TN network. The secondary sided center of the separating transformer must be grounded and connected to the PE connector of the device.

2. Compax3 Xxx I22T11 Introduction

Due to its high functionality, the Positioning version of Compax3 forms an ideal basis for many applications in high-performance motion automation.

Up to 31 motion profiles with the motion functions:

- ◆ Absolute or relative positioning,
- ◆ electronic gearbox,
- ◆ register-related positioning,
- ◆ speed control,
- ◆ Stop - Set
- ◆ ...

can be created with the help of the PC software.

Via different operating modes:

- ◆ Speed Control
- ◆ Direct positioning
- ◆ Positioning with set selection

the motion functions can be triggered via the bus.

A number of different transfer telegrams, which can be conveniently adjusted with the Compax3 ServoManager), can be used to adjust cyclic bus communication to the requirements of specific applications.

Compax3 control technology	High-performance control technology and openness for various sender systems are fundamental requirements for a fast and high-quality automation of movement.
Model / standards / auxiliary material	<p>The structure and size of the device are of considerable importance. High-quality electronics are a fundamental requirement for the particularly small and compact form of the Compax3 devices. All connectors are located on the front of the Compax3S.</p> <p>Partly integrated mains filters permit connection of motor cables up to a certain length without requiring additional measures. EMC compatibility is within the limits set by EN 61800-3, Class A. The Compax3 is CE-conform.</p> <p>The intuitive user interface familiar from many applications, together with the oscilloscope function, wizards and online help, simplifies making and modifying settings via the PC.</p>

The optional **Operator control module (BDM01/01)** (see on page 380) for Compax3S/F makes it possible to exchange devices quickly without requiring a PC.



Configuration Configuration is made with a PC with the help of the Compax3 ServoManager.
General proceeding (see on page 107)

DeviceNet characteristics (I22)

DeviceNet	<ul style="list-style-type: none"> ◆ Predefined Master/Slave Connection Set ◆ Standard 2.0 Group-2-Slave ◆ Fieldbus I/O Data or Process Data (Polled, COS/Cyclic I/O and Bit Strobe)
Implemented object classes	<ul style="list-style-type: none"> ◆ Identify, Message Router, DeviceNet, Assembly, Connection, Acknowledge Handler
Baud rate [kBit/s]	<ul style="list-style-type: none"> ◆ 125, 250, 500
permissible cable length	<ul style="list-style-type: none"> ◆ up to 500m on 125Bit/s, ◆ up to 200m on 250Bit/s, ◆ up to 100m on 500Bit/s,
Max. Number of participants	<ul style="list-style-type: none"> ◆ 63 Slave
Insulation	<ul style="list-style-type: none"> ◆ Isolated Device Physical Layer
EDS file	<ul style="list-style-type: none"> ◆ C3_DeviceNet.EDS
Conformance (file in the Internet)	<ul style="list-style-type: none"> ◆ Statement of Conformance http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf
Further information:	<ul style="list-style-type: none"> ◆ Application example (C3I22_DeviceNet.ZIP) on the Compax3 CD in the "\Examples" directory"

3. Compax3 device description

In this chapter you can read about:

Meaning of the status LEDs - Compax3 axis controller	28
Meaning of the status LEDs - PSUP (mains module)	29
Connections of Compax3S	30
Installation instructions Compax3M.....	40
PSUP/Compax3M Connections	42
Connections of Compax3H	53
Communication interfaces	62
Signal interfaces	67
Installation and dimensions Compax3.....	71
Safety function - STO (=safe torque off).....	80

3.1 Meaning of the status LEDs - Compax3 axis controller

Device status LEDs	Right LED (red)	Left LED (green)
Voltages missing	off	off
During the booting sequence	alternately flashing	
<ul style="list-style-type: none"> ◆ No configuration present. ◆ SinCos[®] feedback not detected. ◆ Compax3 IEC61131-3 program not compatible with Compax3 Firmware. ◆ no Compax3 IEC61131-3 program ◆ For F12: Hall signals invalid. 	flashes slowly	off
Axis without current excitation	off	flashes slowly
Power supplied to axis; commutation calibration running	off	flashes quickly
Axis with current excitation	off	on
Axis in fault status / fault present / axis energized (error reaction 1)	flashes quickly	on
Axis in fault status / fault present / axis currentless (error reaction 2)	on	off
Compax3 faulty: please contact us	on	on

Note on Compax3H: The **internal** device status LEDs are only connected to the **external** housing LEDs, if the RS232 jumper at X10 is fitted to the control and the upper dummy cover is fitted.

3.2 Meaning of the status LEDs - PSUP (mains module)

PSUP Status LEDs	Left LED (green)	Right LED (red)
Control voltage 24 VDC is missing	off	off
Error of mains module*	off	on
DC power voltage is built up	-	flashes quickly
Phase failure / mains power supply undervoltage	on	flashes slowly
Address assignment CPU active	flashes quickly	-
Address assignment CPU completed	flashes slowly	-
PSUPxx Ready - State	on	off
Incorrect wiring of internal communication X30/31	flashes slowly	flashes quickly
Device in bootloader state	flashes slowly	flashes slowly

*can be read out in each axis controller



Caution!

When the control voltage is missing there is no indication whether or not high voltage supply is available.

3.3 Connections of Compax3S

In this chapter you can read about:

Compax3S connectors30
 Connector and pin assignment C3S.....31
 Control voltage 24VDC / enable connector X4 C3S33
 Motor / Motor brake (C3S connector X3)34
 Compax3Sxxx V235
 Compax3Sxxx V438

3.3.1. Compax3S connectors



X1	AC Supply	X20	HEDA in (Option)	
X2	Ballast / DC power voltage	X21	HEDA out (Option)	
X3	Motor / Brake	X22	Inputs Outputs (Option M10/12)	
X4	24VDC / Enable	X23/ X24	Bus (Option)	Connector type depends on the bus system!
X10	RS232/RS485	S24	bus settings	
X11	Analog/Encoder	LED1	Device status LEDs	
X12	Inputs/Outputs	LED2	HEDA LEDs	
X13	Motor position feedback	LED3	Bus LEDs	



Caution - Risk of Electric Shock!

Always switch devices off before wiring them!

Dangerous voltages are still present until 10 min. after switching off the power supply.



Caution!

When the control voltage is missing there is no indication whether or not high voltage supply is available.



Attention - PE connection!

PE connection with 10mm² via a grounding screw at the bottom of the device.



Attention - hot surface!


The heat dissipator can reach very high temperatures (>70°C)

Line cross sections of the line connections X1, X2, X3

Compax3 device:	Cross-section: Minimum... Maximum[mm ²]
S025V2, S063V2	0.25 ... 2.5 (AWG: 24 ... 12)
S100V2, S150V2 S015V4, S038V4, S075V4, S150V4	0.25 ... 4 (AWG: 24 ... 10)
S300V4	0.5 ... 6 (AWG: 20 ... 7)


3.3.2. Connector and pin assignment C3S

Overview:




Further information on the assignment of the plug mounted at the particular device can be found below!

In detail: The fitting of the different plugs depends on the extension level of Compax3. In part, the assignment depends on the Compax3 option implemented.



The jumper drawn in at X4 (at the left side in red) is used to enable the device for testing purposes. During operation, the enable input is in most cases switched externally.

3.3.3. Control voltage 24VDC / enable connector X4 C3S



PIN	Description
1	+24V (supply)
2	Gnd24V
3	Enable_in
4	Enable_out_a
5	Enable_out_b

Line cross sections:
 minimum: 0.25mm²
 maximum: 2.5mm²
 (AWG: 24 ... 12)

Control voltage 24VDC Compax3S and Compax3H

Controller type	Compax3
Voltage range	21 - 27VDC
Current drain of the device	0.8 A
Total current drain	0.8 A + Total load of the digital outputs + current for the motor holding brake
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes
Short-circuit proof	conditional (internally protected with 3.15AT)

Hardware - enable (input X4/3 = 24VDC)

This input is used as safety interrupt for the power output stage.

Tolerance range: 18.0V - 33.6V / 720Ω

"Safe torque off (X4/3=0V)

For implementation of the "safety torque off" safety feature in accordance with the "protection against unexpected start-up" described in EN1037. Observe instructions in the corresponding **chapter** (see on page 80) with the circuitry examples!

The energy supply to the drive is reliably shut off, the motor has no torque.

A relay contact is located between X4/4 and X4/5 (normally closed contact)

Enable_out_a - Enable_out_b	Power output stage is
Contact opened	activated
Contact closed	disabled

Series connection of these contacts permits certain determination of whether all drives are de-energized.


Relay contact data:

Switching voltage (AC/DC): 100mV - 60V

Switching current: 10mA - 0.3A

Switching power: 1mW...7W

3.3.4. Motor / Motor brake (C3S connector X3)




PIN	Designation	Motor cable lead designation*			
1	U (motor)	U / L1 / C / L+	1	U1	
2	V (motor)	V / L2	2	V2	
3	W (motor)	W / L3 / D / L-	3	W3	
4	PE (motor)	YE / GN	YE / GN	YE / GN	
5	BR+	Motor holding brake	WH	4	Br1
6	BR-	Motor holding brake	BK	5	Br2

* depending on the cable type

Requirements for motor cable

< 100m (the cable should not be rolled up!)

A **motor output filter** (see on page 356) is required for motor cables >20 m:



Shielding connection of the motor cable

The cable must be fully-screened and connected to the Compax3 housing. Use the cable clamps/shield connecting terminals furnished with the device.

The shield of the cable must also be connected with the motor housing. The fixing (via plug or screw in the terminal box) depends on the motor type.



Attention - Please wire the motor holding brake!

Connect the brake only on motors which have a holding brake! Otherwise make no brake connections at all.

Requirements cables for motor holding brake

If a motor holding brake is present, **one cable** of the motor holding brake must be fed on the device side through the toroidal core ferrite provided as accessory ZBH0x/xx (63Ω @1MHz, di=5.1mm), in order to ensure error-free switching on and off of the motor holding brake.

Motor holding brake output

Motor holding brake output	Compax3
Voltage range	21 – 27VDC
Maximum output current (short circuit proof)	1.6A

Motor cable

3.3.5. Compax3Sxxx V2

In this chapter you can read about:

Main voltage supply C3S connector X1 35
 Braking resistor / high voltage DC C3S connector X2 36


3.3.5.1 Main voltage supply C3S connector X1

Device protection

By cyclically switching on and off the power voltage, the input current limitation can be overloaded, which will cause a device error.

Therefore please wait at least 2 minutes after switching off before you switch the device on again!

Power supply plug X1 for 1 AC 230VAC/240VAC devices



PIN	Designation
1	L
2	N
3	PE

Mains connection Compax3S0xxV2 1AC

Controller type	S025V2	S063V2
Supply voltage	Single phase 230VAC/240VAC 80-253VAC / 50-60Hz	
Input current	6Arms	13Arms
Maximum fuse rating per device (=short circuit rating)	10 A (MCB miniature circuit breaker, K characteristic)	16A (automatic circuit breaker K)

* for **UL conform operation** (see on page 22), a miniature circuit breaker, K characteristic, Type S203 is to be used.




Caution - Risk of Electric Shock!

Always switch devices off before wiring them!

Dangerous voltages are still present until 10 min. after switching off the power supply.

Power supply plug X1 for 3AC 230VAC/240VAC devices



PIN	Designation
1	L1
2	L2
3	L3
4	PE

Mains connection Compax3S1xxV2 3AC

Controller type	S100V2	S150V2
Supply voltage	Three phase 3* 230VAC/240VAC 80-253VAC / 50-60Hz	
Input current	10Arms	13Arms
Maximum fuse rating per device (=short circuit rating)	16A	20A
	MCB miniature circuit breaker, K characteristic	

* for **UL conform operation** (see on page 22), a miniature circuit breaker, K characteristic, Type S203 is to be used.

Caution!



The 3AC V2 devices must only be operated with three phases!

Caution - Risk of Electric Shock!

Always switch devices off before wiring them!


Dangerous voltages are still present until 10 min. after switching off the power supply.

3.3.5.2 Braking resistor / high voltage DC C3S connector X2

The energy generated during braking operation is absorbed by the Compax3 storage capacity.

If this capacity is too small, the braking energy must be drained via a braking resistor.

Braking resistor / high voltage supply plug X2 for 1AC 230VAC/240VAC devices



PIN	Designation
1	factory use
2	- braking resistor (not short-circuit protected!)
3	PE
4	+ braking resistor (not short-circuit protected!)
5	factory use


Braking operation Compax3S0xxV2 1AC

Controller type	S025V2	S063V2
Capacitance / storable energy	560 μ F / 15Ws	1120 μ F / 30Ws
Minimum braking- resistance	100 Ω	56 Ω
Recommended nominal power rating	20 ... 60W	60 ... 180W
Maximum continuous current	8A	15A

Caution!

The power voltage DC of two Compax3 1AC V2 devices (230VAC/240VAC devices) must not be connected.

Braking resistor / high voltage supply plug X2 for 3AC 230VAC/240VAC devices



PIN	Description	
1	+ Braking resistor	no short-circuit protection!
2	- Braking resistor	
3	PE	
4	+ DC high voltage supply	
5	- DC high voltage supply	

Braking operation Compax3S1xxV2 3AC

Controller type	S100V2	S150V2
Capacitance / storable energy	780 μ F / 21Ws	1170 μ F / 31Ws
Minimum braking- resistance	22 Ω	15 Ω
Recommended nominal power rating	60 ... 450W	60 ... 600W
Maximum continuous current	20A	20A

Connection of a braking resistor

Minimum line cross section: 1.5mm²

Maximum line length: 2m

Maximum output voltage: 400VDC

3.3.6. Compax3Sxxx V4

In this chapter you can read about:


Power supply connector X1 for 3AC 400VAC/480VAC-C3S devices..... 38
 Braking resistor / high voltage supply connector X2 for 3AC 400VAC/480VAC_C3S devices 39
 Connection of the power voltage of 2 C3S 3AC devices..... 39

3.3.6.1 Power supply connector X1 for 3AC 400VAC/480VAC-C3S devices

Device protection

By cyclically switching on and off the power voltage, the input current limitation can be overloaded, which will cause a device error.

Therefore please wait at least 2 minutes after switching off before you switch the device on again!



PIN	Designation
1	L1
2	L2
3	L3
4	PE

Mains connection Compax3SxxxV4 3AC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Supply voltage	Three phase 3*400VAC/480VAC 80-528VAC / 50-60Hz				
Input current	3Aeff	6Arms	10Arms	16Arms	22Arms
Maximum fuse rating per device(=short circuit rating)	6A	10A	16A	20A	25A
	MCB miniature circuit breaker, K characteristic				D*

* for **UL conform operation** (see on page 22), a miniature circuit breaker, K characteristic, Type S203 is to be used.

Caution!




The 3AC V4 devices must only be operated with three phases!

Caution - Risk of Electric Shock!

Always switch devices off before wiring them!

Dangerous voltages are still present until 10 min. after switching off the power supply.

3.3.6.2 Braking resistor / high voltage supply connector X2 for 3AC 400VAC/480VAC_C3S devices



PIN	Description	
1	+ Braking resistor	no short-circuit protection!
2	- Braking resistor	
3	PE	
4	+ DC high voltage supply	
5	- DC high voltage supply	

Braking operation Compax3SxxxV4 3AC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Capacitance / storable energy 400V / 480V	235µF 37 / 21 Ws	235µF 37 / 21 Ws	470µF 75 / 42 Ws	690µF 110 / 61 Ws	1230µF 176 / 98 Ws
Minimum braking- resistance	100Ω	100Ω	56Ω	33Ω	15Ω
Recommended nominal power rating	60 ... 100W	60 ... 250W	60 ... 500 W	60 ... 1000 W	60 ... 1000 W
Maximum continuous current	10A	10A	15A	20A	30A

Connection of a braking resistor

Minimum line cross section: 1.5mm²

Maximum line length: 2m

Maximum output voltage: 800VDC

3.3.6.3 Connection of the power voltage of 2 C3S 3AC devices

Caution!

The power voltage DC of the single phase Compax3 servo axes must not be connected!

In order to improve the conditions during brake operation, the DC power voltage of 2 servo axes may be connected.

The capacity as well as the storable energy are increased; furthermore the braking energy of one servo axis may be utilized by a second servo axis, depending on the application.



It is not permitted to connect the power voltage in order to use one brake circuit for two servo axes, as this function cannot be ensured reliably.

Note the following:

Caution! In case of non-compliance with the following instructions, the device may be destroyed!

- ◆ You can only connect two similar servo axes (same power supply; same rated currents)
- ◆ Connected servo axes must always be fed separately via the AC power supply. If the external pre-fuse of one of the servo axes takes action, the second servo axis must also be disconnected automatically.

Please connect as follows:

Servo axis 1 X2/4 to servo axis 2 X2/4

Servo axis 1 X2/5 to servo axis 2 X2/5

3.4 Installation instructions Compax3M

General introductory notes

- ◆ Operation of the Compax3M multi-axis combination is only possible in connection with a PSUP (mains module).
- ◆ Axis controllers are aligned at the right of the mains module.
- ◆ Arrangement within the multi-axis combination sorted by power (with the same device types according to device utilization), the axis controller with the highest power is placed directly at the right of the mains module.
e.g. first the device type with high utilization, at the right of this, the same device type with a lower utilization.
- ◆ Max. 15 Compax3M (axis controllers) per PSUP (mains module) are permitted (please respect the total capacity of max. 2400µF for PSUP10, max. 5000µF for PSUP20).
- ◆ The continuation of the current rail connection outside the axis combination is not permitted and will lead to a loss of the CE and UL approbation.
- ◆ External components **may not** be connected to the rail system.

Required tools:

- ◆ Allen key M5 for fixing the devices in the control cabinet.
- ◆ Crosstip screwdriver M4 for connection rails of the DC rail modules.
- ◆ Crosstip screwdriver M5 for grounding screw of the device.
- ◆ Flat-bladed screwdriver 0.4x2.5 / 0.6x3.5 / 1.0x4.0 for wiring and mounting of the phoenix clamps.

Order of installation

- ◆ Fixing the devices in the control cabinet.
 - ◆ Pre-drilling the mounting plate in the control cabinet according to the specifications. Dimensions. Fit M5 screws loosely in the bores.
 - ◆ Fit device on the upper screws and place on lower screw. Tighten screws of all devices. The tightening torque depends on the screw type (e.g. 5.9Nm for M5 screw DIN 912 8.8).
- ◆ Connection of the internal supply voltage.
The Compax3M axis controllers are connected to the supply voltages via the rail modules. **Details** (see on page 44).
 - ◆ Deblocking the yellow protective cover with a flat-bladed screwdriver on the upper surface (click mechanism). Remove the closing devices (contact protection) that are not required from between the devices.
 - ◆ Connecting the rail modules, beginning with the mains module.
For this, loosen crosshead screws (5 screws at the right in the mains module, all 10 screws in the next axis controller), push the rails one after the other against to the left and tighten screws. Proceed accordingly for all adjacent axis controllers in the combination.
Max. tightening torque: 1.5Nm.
 - ◆ Close all protective covers. The protective covers must latch audibly.

Please note:

Insufficiently fixed screw connections of the DC power voltage rails may lead to the destruction of the devices.

Protective seals



Caution - Risk of Electric Shock!

In order to secure the contact protection against the alive rails, it is absolutely necessary to respect the following:

- ◆ Insert the yellow plastic comb at the left or right of the rails.
Make sure that the yellow plastic combs are placed at the left of the first device and at the right of the last device in the system and have not been removed.
- ◆ Setup of the devices only with closed protective covers.
- ◆ Connect protective earth to mains module (M5 crosshead screw on front of device bottom).
- ◆ Connecting the internal communication. **Details** (see on page 63).
- ◆ Connecting the signal and fieldbus connectors. **Details** (see on page 67).
- ◆ Connection of mains power supply **Details** (see on page 46) ballast resistor **details** (see on page 49) and motor **details** (see on page 50).
- ◆ Connecting the configuration interface to the PC. **Details** (see on page 63).

3.5 PSUP/Compax3M Connections

In this chapter you can read about:

Front connector42
 Connections on the device bottom43
 Connections of the axis combination.....44
 Control voltage 24VDC PSUP (mains module)45
 Mains supply PSUP (mains module) X4146
 Braking resistor / temperature switch PSUP (mains module)49
 Motor / motor brake Compax3M (axis controller)50
 Safety technology option for Compax3M (axis controller).....52

3.5.1. Front connector



P	Mains module PSUP
LED1	Status LEDs Mains module
S1	Basic address
X3	Configuration interface (USB)
X9	Supply voltage 24VDC
M	Axis controller
LED2	Status LEDs of the axis
S10	Function
X11	Analog/Encoder
X12	Inputs/Outputs
X13	Motor position feedback
X14	Safety technology (option)
X15	Motor temperature monitoring
LED3	HEDA LEDs
X20	HEDA in (Option)
X21	HEDA out (Option)
X22	Inputs Outputs (Option M10/12)
X23	Bus (option) connector type depends on the bus system!
X24	Bus (option) depends on the bus system!
LED4	Bus LEDs
S24	bus settings
1	Behind the yellow protective covers you can find the rails for the supply voltage connection. ♦ Supply voltage 24VDC ♦ DC power voltage supply

3.5.2. Connections on the device bottom



Caution - Risk of Electric Shock!

Always switch devices off before wiring them!

Dangerous voltages are still present until 10 min. after switching off the power supply.



Caution!

When the control voltage is missing there is no indication whether or not high voltage supply is available.




Attention - PE connection!

PE connection with 10mm² via a grounding screw at the bottom of the device.



Attention - hot surface!

The heat dissipator can reach very high temperatures (>70°C)



P	Mains module PSUP
X40	Ballast resistor
X41	Mains supply VAC/PE
1	Central ground connection for the axis system, with 10mm ² to the ground screw on the housing.
4	Fan*
M	Axis controller
X43	Motor / Brake
2	Fixing for motor shield clamp
4	Fan*
3	optionally, the axis controller features a ground screw on the housing, if the grounding is not possible via the back plate.

* is internally supplied.

Line cross-sections of the power connections (on the device bottoms)

Compax3 device:	Cross-section: Minimum... Maximum [with conductor sleeve]
M050, M100, M150	0.25 ... 4 mm ² (AWG: 23 ... 11)
M300	0.5 ... 6 mm ² (AWG: 20 ... 10)
PSUP10	Mains supply: 0.5 ... 6 mm ² (AWG: 20 ... 10) Braking resistor: 0.25 ... 4 mm ² (AWG: 23 ... 11)
PSUP20 & PSUP30	Mains supply: 0.5 ... 16 mm ² (AWG: 20 ... 6) Braking resistor: 0.25 ... 4 mm ² (AWG: 23 ... 11)

3.5.3. Connections of the axis combination

The axis controllers are connected to the supply voltages via rails.

- ◆ Supply voltage 24VDC
- ◆ DC power voltage supply

The rails can be found behind the yellow protective covers. In order to connect the rails of the devices, you may have to remove the yellow plastic device inserted at the side.

CAUTION: Risk of Electric Shock



Caution - Risk of Electric Shock!

Please note before opening:

- ◆ **Warning** - Possible risk of electric shock; disconnect power before removing cover.
- ◆ **Caution!** - Dangerous electric voltage! Respect discharge time.



Caution - Risk of Electric Shock!

Always switch devices off before wiring them!

Dangerous voltages are still present until 10 min. after switching off the power supply.



Caution!

When the control voltage is missing there is no indication whether or not high voltage supply is available.


Protective seals



Caution - Risk of Electric Shock!

In order to secure the contact protection against the alive rails, it is absolutely necessary to respect the following:

- ◆ Insert the yellow plastic comb at the left or right of the rails.
Make sure that the yellow plastic combs are placed at the left of the first device and at the right of the last device in the system and have not been removed.
- ◆ Setup of the devices only with closed protective covers.



- | | |
|---|--------|
| 1 | 24VDC |
| 2 | GND24V |
| 3 | -HV DC |
| 4 | PE |
| 5 | +HV DC |

Note: External components **may not** be connected to the rail system.

Maximum capacity in the axis system:

- ◆ PSUP10: 2400 μF
- ◆ PSUP20 & PSUP30: 5000 μF

Reference value for the required capacity in an axis system

100 μF per kW of the temporal medium value of the total power (transmissions + power dissipation) in the axis system


Example: PSUP20 (1175 μF) with one axis controller (440 μF)

Total power 15 kW, 100 $\mu\text{F}/\text{kW}$ \Rightarrow 1500 μF required in the axis system.

Axis system: 1615 μF are sufficient.

Protective seals**Caution!**

The user is responsible for protective covers and/or additional safety measures in order to prevent damages to persons and electric accidents.

3.5.4. Control voltage 24VDC PSUP (mains module)**Connector X9**

Pin	Designation
1	+24 V
2	GND24V

Line cross sections:

minimum: 0.5mm² with conductor sleeve

maximum: 6mm² with conductor sleeve

(AWG: 20 ... 10)

Control voltage 24 VDC PSUP

Device type	PSUP
Voltage range	21 - 27VDC
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes (class 2 mains module)
Current drain PSUP	PSUP10: 0.2A PSUP20 / PSUP30: 0.3A
Electric current drain Compax3M	C3M050D6: 0.85 3M100D6: 0.85A C3M150D6: 0.85A C3M300D6: 1.0 A + Total load of the digital outputs + current for the motor holding brake


3.5.5. Mains supply PSUP (mains module) X41

Device protection

By cyclically switching on and off the power voltage, the input current limitation can be overloaded, which may cause damage to the device.

Wait at least one minute between two switching on processes!

Operation of the PSUP30 only with mains filter!



Connector X41

Pin	Designation
PE	Earth conductor
L3	Phase 3
L2	Phase 2
L1	Phase 1

Mains connection PSUP10D6

Device type PSUP10	230V	400V	480V
Supply voltage	230VAC ±10% 50-60Hz	400VAC ±10% 50-60Hz	480VAC ±10% 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	22Arms	22Arms	18Arms
Output voltage	325VDC ±10%	565VDC ±10%	680VDC ±10%
Output power	6kW	10 kW	10 kW
Pulse power (<5s)	12kW	20kW	20kW
Power dissipation	60W	60W	60W
Maximum fuse rating per device (=short circuit rating)	Measure for line and device protection: MCB miniature circuit breaker (K characteristic) 25A in accordance with UL category DIVQ Recommendation: (ABB) S203UP-K 25(480VAC)		

Mains connection PSUP20D6

Device type PSUP20	230V	400V	480V
Supply voltage	230VAC ±10% 50-60Hz	400VAC ±10% 50-60Hz	480VAC ±10% 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	44Arms	44Arms	35Arms
Output voltage	325VDC ±10%	565VDC ±10%	680VDC ±10%
Output power	12kW	20kW	20kW
Pulse power (<5s)	24kW	40kW	40kW
Power dissipation	120W	120W	120W
Maximum fuse rating per device (=short circuit rating) 2 circuit breakers in line are required	Cable protection measure: MCB (K characteristic) with a rating of 50A / 4xVAC (depending on the input voltage) Recommendation: (ABB) S203U-K50 (440VAC) Device protection measure: Circuit breakers 80A / 700VAC per supply leg in accordance with UL category JFHR2 Requirement: Bussmann 170M1366 or 170M1566D		

PSUP30D6 Mains connection

Device type PSUP30	230V	400V	480V
Supply voltage	230VAC ±10% 50-60Hz	400VAC ±10% 50-60Hz	480VAC ±10% 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	50Arms	50Arms	42Arms
Output voltage	325VDC ±10%	565VDC ±10%	680VDC ±10%
Output power	17kW	30kW	30kW
Pulse power (<5s)	34kW	60kW	60kW
Power dissipation	140W	140W	140W
Maximum fuse rating per device (=short circuit rating) 2 circuit breakers in line are required	Cable protection measure: MCB (K characteristic) with a rating of 63A / 4xxVAC (depending on the input voltage) Recommendation: (ABB) S203U-K63 (440VAC) Device protection measure: Circuit breakers 125A / 700VAC per supply leg in accordance with UL category JFHR2 Requirement: Bussmann 170M1368 or 170M1568D		

Caution!

Only three-phase operation of the PSUP devices is permitted!


The PSUP30 mains module may only be operated with mains filter (see on page 358)

Required mains filter for the PSUP30: 0.45 mH / 55 A


We offer the following mains filters:

- ◆ LCG-0055-0.45 mH (WxDxH: 180 mm x 140 mm x 157 mm; 10 kg)
- ◆ LCG-0055-0.45 mH-UL (with UL approval) (WxDxH: 180 mm x 170 mm x 157 mm; 15 kg)

Dimensional drawing: LCG-0055-0.45 mH



Dimensional drawing: LCG-0055-0.45 mH-UL

**Caution - Risk of Electric Shock!**


Always switch devices off before wiring them!

Dangerous voltages are still present until 10 min. after switching off the power supply.

3.5.6. Braking resistor / temperature switch PSUP (mains module)

The energy generated during braking operation must be dissipated via a braking resistor.

Connector X40



Pin	Description
+R	+ Braking resistor
-R	- Braking resistor
PE	PE
T1R	Temperature Switch
T2R	Temperature Switch

short-circuit proof!

Braking operation PSUPxxD6 (mains module)

Device type	PSUP10	PSUP20	PSUP30
Capacitance / storable energy	550 μ F/ 92 Ws at 400 V 53 Ws at 480 V	1175 μ F/ 197 Ws at 400 V 114 Ws at 480 V	1175 μ F/ 197 Ws at 400 V 114 Ws at 480 V
Minimum braking-resistance	27 Ω	15 Ω	10 Ω
Recommended nominal power rating	500 ... 1500 W	500 ... 3500 W	500 ... 5000 W
Pulse power rating for 1s	22 kW	40 kW	60 kW
Maximum permissible continuous current	13 A	15 A	15 A

Maximum capacity in the axis system:

- ◆ PSUP10: 2400 μ F
- ◆ PSUP20 & PSUP30: 5000 μ F

Reference value for the required capacity in an axis system

100 μ F per kW of the temporal medium value of the total power (transmissions + power dissipation) in the axis system

Example: PSUP20 (1175 μ F) with one axis controller (440 μ F)

Total power 15 kW, 100 μ F/kW \Rightarrow 1500 μ F required in the axis system.

Axis system: 1615 μ F are sufficient.

Connection of a braking resistor on PSUP (mains module)

Minimum line cross section:	1.5 mm ²
Maximum line length:	2 m
Maximum intermediate circuit voltage:	810 VDC
Switch-on threshold:	780 VDC
Hysteresis	20 VDC

Braking operation Compax3MxxxD6 (axis controller)

Device type Compax3	M050	M100	M150	M300
Capacity/ storable energy	110 μ F/ 18Ws at 400V 10Ws at 480V	220 μ F/ 37Ws at 400V 21Ws at 480V	220 μ F/ 37Ws at 400V 21Ws at 480V	440 μ F/ 74Ws at 400V 42Ws at 480V

3.5.6.1 Temperature switch PSUP (mains module)

Connector X40 Pin T1R, T2R

Temperature monitoring:

The temperature switch (normally closed contact) must be connected, unless an error message will be issued.

Temperature switch/relay

No galvanic separation, the temperature sensor (normally closed contact) must comply with the safe separation according to EN 60664.

If there is no temperature monitoring due to the connected braking resistor, the T1R and T2R connections must be connected by a jumper.




Caution!

Without temperature monitoring, the braking resistor might be destroyed.

3.5.7. Motor / motor brake Compax3M (axis controller)

Connector X43



PIN	Designation	Motor cable lead designation*		
BR-	Motor holding brake *	BK	5	Br2
BR+	Motor holding brake *	WH	4	Br1
PE	PE (motor)	YE / GN	YE / GN	YE / GN
W	W (motor)	W / L3 / D / L-	3	U3
V	V (motor)	V / L2	2	U2
U	U (motor)	U / L1 / C / L+	1	U1

* depending on the cable type

Compax3M motor cable

<80m per axis (the cable must not be rolled up!)
 The entire length of the motor cable per axis combination may not exceed 300m.
 A **motor output filter** (see on page 356) is required for motor cables >20 m:
 ♦ MDR01/04 (max. 6.3 A rated motor current)
 ♦ MDR01/01 (max. 16 A rated motor current)
 ♦ MDR01/02 (max. 30 A rated motor current)

Shielding connection of the motor cable

The cable must be fully-screened and connected to the Compax3 housing. Use the cable clamps/shield connecting terminals furnished with the device.

The shield of the cable must also be connected with the motor housing. The fixing (via plug or screw in the terminal box) depends on the motor type.



Motor cables can be found in the accessories chapter of the device description.

Motor holding brake output

Motor holding brake output	Compax3
Voltage range	21 – 27VDC
Maximum output current (short circuit proof)	1.6A



Attention - Please wire the motor holding brake!

Connect the brake only on motors which have a holding brake! Otherwise make no brake connections at all.


Requirements cables for motor holding brake

If a motor holding brake is present, **one cable** of the motor holding brake must be fed on the device side through the toroidal core ferrite provided as accessory ZBH0x/xx (63Ω @1MHz, di=5.1mm), in order to ensure error-free switching on and off of the motor holding brake.

3.5.7.1 Measurement of the motor temperature of Compax3M (axis controller)

Connector X15

The acquisition of the motor temperature by the axis controller can either take place via the connection of X15 (Tmot) or via the feedback cable and the corresponding connection on X13 PIN10.



Pin	Description
1	+5V
2	Sensor

The temperature acquisition on X15 Tmot can not be connected at the same time as X13 Pin 10.

3.5.8. Safety technology option for Compax3M (axis controller)

Connector X14



Pin	Description	
1	STO1/	+24VDC
2	STO-GND	GND
3	STO2/	+24VDC
4	STO-GND	GND



Note!

If the Compax3M axis controller features a safety option, these connections must also be wired, otherwise it is not possible to set up the axis.

3.6 Connections of Compax3H


In this chapter you can read about:

Compax3H plugs/connections53
 Connection of the power voltage.....54
 Compax3H connections front plate56
 Plug and pin assignment C3H56
 Motor / Motor brake C3H58
 Control voltage 24 VDC C3H59
 Mains connection Compax3H59
 Braking resistor / supply voltage C3H60

3.6.1. Compax3H plugs/connections

The following figure is an example for all sizes.

The fitting of the different controller plugs depends on the extension level of Compax3.



- (1): Dummy cover with display of the **external** device status LEDs.
- (2): lower clamp cover, fixed by 2 screws at the device bottom.
- (3): RS232 programming interface
 Connection to the PC via adapter cable SSK32/20 (furnished with the device) and standard RS232 cable SSK1.
- (4): Control
- (5): Power connections



Always switch devices off before wiring them!

Dangerous voltages are still present until 5 minutes after switching off the power supply!



Caution!

If the control voltage is missing and if the X10-X10 jumper is not fitted (VBK17/01) on the control part, the availability of power voltage is not displayed.



PE connection

PE connection with 10mm² via a grounding screw at the bottom of the device.



Attention hot surface!


Metal parts can heat up to a temperature of 90°C during operation.

3.6.2. Connection of the power voltage

The terminal block of the drive can be found under the front cover. It is secured with 2 screws at the bottom of the device. Remove the bottom cover in order to access the connection clamps.

Make sure that all live parts are covered by the housing after installation.

Illustration of the connection clamps exemplarily for all sizes:



L1, L2, L3: 3 phase mains connection

M1, M2, M3: Motor connections

DC+, DC-: DC link voltage

(1) DBR+ und DBR-: Connection of external braking resistor

(2) AUX1, AUX2: only with C3H1xxV4 external supply (AC) for device ventilator L, N

- ◆ All shields must be connected via a cable joint to the cable feed through plate.
- ◆ Braking resistor and cable must be shielded if they are not installed in a control cabinet.
- ◆ The standard connection clamps of C3H090V4 and C3H1xxV4 are **not** suitable for flat line bars.

Attention: The MOT/TEMP connection is not supported by the Compax3H050; do therefore not wire this connection!

Terminal clamps - max. line cross sections

The line cross sections must correspond to the locally valid safety regulations. The local regulations have always priority.

	Power clamps (minimum/maximum section)	
C3H050V4	2.5 / 16mm ²	
	Massive	Multiwire
C3H090V4	16 / 50mm ²	25 / 50mm ²
C3H1xxV4	25 / 95mm ²	35 / 95mm ²

The standard connection clamps of Compax3H090V4 and Compax3H1xxV4 are not suitable for flat line bars.

Cover plate for cable feed through


The cable feed through holes have the following dimensions:	
C3H050V4	28.6mm for M20, PG16 and ½" NPT (America). 37.3mm for M32, PG29 and 1" NPT (America).
C3H090V4	22.8mm for M20, PG16 und ½" NPT (America). 28.6mm for M25, PG21 and ¾" NPT (America). 47.3mm for M40, PG36 and 1¼" NPT (America). 54.3mm for M50, PG42and 1½" NPT (America).
C3H1xxV4	22.8mm for M20, PG16 and ½" NPT (America) 28.6mm for M25, PG21 and ¾" NPT (America)

Recommended tightening torques

	High voltage supply	Ballast resistor	Grounding
C3H050V4	4Nm / 35lb-in	4Nm / 35lb-in	4.5Nm / 40lb-in
C3H090V4	6-8Nm / 53-70lb-in	6-8Nm / 53-70lb-in	6-8Nm / 53-70lb-in
C3H1xxV4	15-20Nm / 132-177lb-in	0.7Nm / 6.1lb-in	42Nm / 375lb-in

Cable joints

Use metallic cable joints permitting a 360° shielding in order to comply with the EMC directive.



1: Cable feed through plate

2: metallic joint with 360° shielding for EMC compliant design

The device must be grounded without interruption according to EN 61800-5-1. The mains supply lines must be protected with a suitable fuse or a circuit breaker (FI switches or earth fault fuses are not recommended).


For installation in accordance with EN 61800-5-1 mm Europe:

- ◆ For grounding without interruption, two separate protective leads (² cross-section) or one lead (>10mm² cross-section) are required. Each protective lead must meet the requirements according to EN 60204.

3.6.3. Compax3H connections front plate

Communication and signal interfaces

Showcase front plate of the control (number of connectors depends on the extension level of the Compax3)




X3	Motor brake	X20	HEDA in (Option)
X4	24VDC	X21	HEDA out (Option)
X10	RS232/RS485 with jumper to the programming interface	X22	Inputs Outputs (Option M10/12)
X11	Analog/Encoder	X23	Bus (Option) Connector type depends on the bus system!
X12	Inputs/Outputs	S24	Bus settings
X13	Motor position feedback	LED1	Device status LEDs
		LED2	HEDA LEDs
		LED3	Bus LEDs

Note on Compax3H: The **internal** device status LEDs are only connected to the **external** housing LEDs, if the RS232 jumper at X10 is fitted to the control and the upper dummy cover is fitted.

The RS232 programming interface under the upper dummy cover is only available if the X10 jumper at the controller is fitted.


3.6.4. Plug and pin assignment C3H

Overview



Further information on the assignment of the plug mounted at the particular device can be found below!

In detail: The fitting of the different plugs depends on the extension level of Compax3. In part, the assignment depends on the Compax3 option implemented.



The RS232 programming interface under the upper dummy cover is only available if the X10 jumper at the controller is fitted.

Please note

C3H1xxV4 uses a ventilator fan which must be externally supplied via separate connections. The ventilator fan is available in two versions for single phase feed: 220/240VAC; 110/120VAC

3.6.5. Motor / Motor brake C3H

Motor connection clamps - figure (see on page 54)

PIN	Designation	Motor cable lead designation*		
M1/U	U (motor)	U / L1 / C / L+	1	U1
M2/V	V (motor)	V / L2	2	U2
M3/W	W (motor)	W / L3 / D / L-	3	U3
PE	PE (motor)	YE / GN	YE / GN	YE / GN

* depending on the cable type

Compax3H motor cable

A motor output filter is required for motor cables >50m. Please contact us.

Shielding connection of the motor cable

The motor cable should be fully shielded and connected to the Compax3 housing. The shield of the motor cable must also be connected with the motor housing. The fixing (via plug or screw in the terminal box) depends on the motor type.



Attention - Please wire the motor holding brake!

Connect the brake only on motors which have a holding brake! Otherwise make no brake connections at all.

Requirements cables for motor holding brake

If a motor holding brake is present, **one cable** of the motor holding brake must be fed on the device side through the toroidal core ferrite provided as accessory ZBH0x/xx (63Ω @1MHz, di=5.1mm), in order to ensure error-free switching on and off of the motor holding brake.



Connection of motor brake X3 - figure (see on page 56)

PIN	Designation	Motor cable lead designation*		
1	BR	WH	4	Br1
2	GND	BK	5	Br2

Motor holding brake output

Motor holding brake output	Compax3
Voltage range	21 – 27VDC
Maximum output current (short circuit proof)	1.6A

3.6.6. Control voltage 24 VDC C3H



Connection of control voltage 24VDC figure (see on page 56)

Connector X4 Pin	Description	
1	NC	NC
2	GND24V	GND
3	+24 V	24 VDC (power supply)

Control voltage 24VDC Compax3S and Compax3H

Controller type	Compax3
Voltage range	21 - 27VDC
Current drain of the device	0.8 A
Total current drain	0.8 A + Total load of the digital outputs + current for the motor holding brake
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes
Short-circuit proof	conditional (internally protected with 3.15AT)

3.6.7. Mains connection Compax3H

Device protection

Avoid permanent switching on and off so that the charging connection is not overloaded. Therefore wait at least 1 minute before switching on the device again.

Connection of mains voltage figure (see on page 54)

Mains connection Compax3HxxxV4 3*400VAC

Device type Compax3	H050V4	H090V4	H125V4	H155V4
Supply voltage	Three-phase 3*400VAC 350-528VAC / 50-60Hz			
Input current	66Arms	95Arms	143Arms	164Arms
Output current	50Arms	90Arms	125Arms	155Arms
Maximum fuse rating per device(=short circuit rating) Branch circuit protection according to UL	80A	100A	160A	200A
	JDDZ Class K5 or H JDRX Class H			

Mains connection Compax3HxxxV4 3*480VAC

Device type Compax3	H050V4	H090V4	H125V4	H155V4
Supply voltage	Three-phase 3*480VAC 350-528VAC / 50-60Hz			
Input current	54Arms	82Arms	118Arms	140Arms
Output current	43Arms	85Arms	110Arms	132Arms
Maximum fuse rating per device(=short circuit rating) Branch circuit protection according to UL	80A	100A	160A	200A
	JDDZ Class K5 or H JDRX Class H			

3.6.8. Braking resistor / supply voltage C3H

The energy generated during braking operation is absorbed by the Compax3 storage capacity.

If this capacity is too small, the braking energy must be drained via a braking resistor.

3.6.8.1 Connect braking resistor C3H

Connection of braking resistor - figure (see on page 54)

PIN	Designation
DBR+	+ Braking resistor
DBR-	- Braking resistor

Braking operation of Compax3HxxxV4

Controller type	H050V4	H090V4	H125V4	H155V4
Capacitance / storable energy 400V / 480V	2600 μ F 602 / 419 Ws	3150 μ F 729 / 507 Ws	5000 μ F 1158 / 806 Ws	5000 μ F 1158 / 806 Ws
Minimum braking- resistance	24 Ω	15 Ω	8 Ω	8 Ω
Maximum continuous current	11 A	17 A	31 A	31 A

Minimum line cross section: 2.5mm²
 Maximum line length: 2m
 Maximum output voltage: 830VDC

3.6.8.2 Power supply voltage DC C3H

Connection of power voltage DC -figure (see on page 54)

PIN	Description
DC+	+ DC high voltage supply
DC-	- DC high voltage supply



Warning!

Do not connect any braking resistor on DC+/DC- .

3.6.8.3 Connection of the power voltage of 2 C3H 3AC devices

In order to improve the conditions during brake operation, the DC power voltage of 2 servo axes may be connected.

The capacity as well as the storable energy are increased; furthermore the braking energy of one servo axis may be utilized by a second servo axis, depending on the application.



It is not permitted to connect the power voltage in order to use one brake circuit for two servo axes, as this function cannot be ensured reliably.

Note the following:

Caution! In case of non-compliance with the following instructions, the device may be destroyed!

- ◆ You can only connect two similar servo axes (same power supply; same rated currents)
- ◆ Connected servo axes must always be fed separately via the AC power supply.
- ◆ If the external pre-fuse of one of the servo axes takes action, the second servo axis must also be disconnected automatically.

Please connect as follows:

Servo axis 1 DC+ with servo axis 2 DC+

Servo axis 1 DC- with servo axis 2 DC-


- **figure** (see on page 54)

3.7 Communication interfaces

In this chapter you can read about:

RS232/RS485 interface (plug X10).....	62
Communication Compax3M.....	63
DeviceNet connector X23	65

3.7.1. RS232/RS485 interface (plug X10)



Interface selectable by contact functions assignment of X10/1:

X10/1=0V RS232

X10/1=5V RS485

PIN X10	RS232 (Sub D)
1	(Enable RS232) 0V
2	RxD
3	TxD
4	DTR
5	GND
6	DSR
7	RTS
8	CTS
9	+5V

RS485 2-wire

PIN X10	RS485 2-wire Sub D Pin 1 and 9 externally jumpered
1	Enable RS485 (+5V)
2	res.
3	TxD_RxD/
4	res.
5	GND
6	res.
7	TxD_RxD
8	res.
9	+5V

RS485 4-wire

PIN X10	RS485 4-wire Sub D Pin 1 and 9 externally jumpered
1	Enable RS485 (+5V)
2	RxD
3	TxD/
4	res.
5	GND
6	res.
7	TxD
8	RxD/
9	+5V

USB - RS232/RS485 converter

The following USB - RS232 converters were tested:

- ◆ ATEN UC 232A
- ◆ USB GMUS-03 (available under several company names)
- ◆ USB / RS485: **Moxa Uport 1130**
http://www.moxa.com/product/UPort_1130.htm
- ◆ Ethernet/RS232/RS485: **NetCom 113** <http://www.vscom.de/666.htm>

3.7.2. Communication Compax3M

In this chapter you can read about:

PC - PSUP (Mains module)..... 63
 Communication in the axis combination (connector X30, X31) 63
 Adjusting the basic address 64
 Setting the axis function 64

3.7.2.1 PC - PSUP (Mains module)

Connector X3



USB2.0

Connect your PC to the USB sleeve X3 of the mains module via an USB cable (SSK33/03).

3.7.2.2 Communication in the axis combination (connector X30, X31)

The communication in the axis combination is implemented via a SSK28 cable and double RJ45 sleeves on the device top.

Beginning with the PSUP (mains module) the connection is always made from X30 to X31 of the next device. On the first device (X31) and the last device (X30) in the multi-axis combination, a bus termination plug (BUS07/01) is required.

Orientation to the back side



Orientation to the front plate

PSUP (Mains module)	
X30	out
X31	in
res.	factory use
Compax3M (axis)	
X30	out
X31	in
res.	factory use

3.7.2.3 Adjusting the basic address

On the mains module, the basic address of the device combination is set in steps of 16 with the aid of the first three dip switches.

The mains module contains the set basic address while the axes placed at the right in the combination contain the following addresses.



Switch S1

Address setting

Basic addresses

Switch	Value upon ON
1	16
2	32
3	64

Settings:

left: OFF

right: ON

Settable value range: 0, 16, 32, 48, 64, 80, 96, 112

Address of the 1st axis = basic address+1

The addresses of the axis controllers are newly assigned after PowerOn.

Example:

Basic address = 48; mains module with 6 axis controllers in the combination

1. Axis right: Address = 49

2. Axis right: Address = 50

...

6. Axis right: Address = 54

3.7.2.4 Setting the axis function

Switch S10




Function settings for T30 and T40

The value of switch S10 on the axis controller is stored in object O110.1

C3plus.Switch_DeviceFunction and can be evaluated with the aid of a program.

This helps realize a more simple function selection.

3.7.3. DeviceNet connector X23



Pin X23	DeviceNet (Open Plug Phoenix MSTB 2.5/5-GF5.08 ABGY AU)	
1	V-	Mass
2	CAN-	CAN Low
3	Shield	Shield
4	CAN+	CAN High
5	V+	not required, internal supply

A mating plug is included in the delivery.

If Compax3 is used as first or last device in the fieldbus network, a terminal resistance of 121 Ω is required. This is integrated between Pin 2 and Pin 4.

Additional information on the DeviceNet wiring can be found under www.odva.org <http://www.odva.org>.

Please do also heed the instructions in the DeviceNet master manual.

3.7.3.1 Adjusting the bus address

Address setting (NA: Node Address)

Values:

1: 2⁰; 2: 2¹; 3: 2²; ... 6: 2⁵reserved

Settings:

left: OFF

right: ON

(The address is set to 2 in the illustration)

Range of values: 1 ... 63


Address 0 is set internally to address 63.

Data Rate setting (DR):

Data Rate [kBit/s]	S24_7	S24_8
125	left: OFF	left: OFF
250	right: ON	left: OFF
500	left: OFF	right: ON
factory use	right: ON	right: ON

Bear in mind that the maximum cable length depends on the Data rate:

Data Rate	Maximum length
500kbit/s	100m
250kbit/s	250m
125kbit/s	500m



3.7.3.2 Function of the Bus LEDs

LED (red)

No.	Signal	Status	Description
1	off	No Error	The bus is operating
2	Single flash	Warning	at least one of the error counters of the CAN controller has reached the warning level.
3	Double flash	Error	Communication Fault
4	Triple flash	Error	Double Mac ID
5	on	Error	Bus Off

If several errors occur at once, the error with the most significant number is reported.

LED green

Signal	Status	Description
Single flash	On-line Not Connected	Online, not at the master (not allocated)
blinks (permanently)	On-line Connected	Online, at the master (allocated)
on	On-line I/O Connected	I/O Messages allocated

Single flash



Double flash



Triple flash




3.8 Signal interfaces

In this chapter you can read about:

Resolver / feedback (plug X13).....	67
Analogue / encoder (plug X11)	68
Digital inputs/outputs (plug X12)	69

3.8.1. Resolver / feedback (plug X13)



PIN X13	Feedback /X13 High Density /Sub D (depending on the Feedback module)		
	Resolver (F10)	SinCos (F11)	EnDat 2.1 (F12)
1	factory use	factory use	Sense -*
2	factory use	factory use	Sense +*
3	GND	GND	factory use
4	REF-Resolver+	Vcc (+8V)	Vcc (+5V) * max. 350mA load
5	+5V (for temperature sensor)		
6	factory use	factory use	CLKfbk
7	SIN-	SIN-	SIN- / A- (Encoder)
8	SIN+	SIN+	SIN+ / A+ (Encoder)
9	factory use	factory use	CLKfbk/
10	Tmot*	Tmot*	Tmot*
11	COS-	COS-	COS- / B- (Encoder)
12	COS+	COS+	COS+ / B+ (Encoder)
13	factory use	DATAfbk	DATAfbk
14	factory use	DATAfbk/	DATAfbk/
15	REF-Resolver-	GND (Vcc)	GND (Vcc)

*X13 Pin10 Tmot may not be connected at the same time as X15 (on Compaxx3M).

Resolver cables (see on page 360) can be found in the accessories chapter of the device description.

SinCos® cables (see on page 361) can be found in the accessories chapter of the device description.

The **EnDat cable GBK38** (see on page 362) can be found in the accessories chapter of the device description.

PIN X13	Feedback /X13 High Density /Sub D
	Direct drives (F12)
1	Sense -*
2	Sense +*
3	Hall1 (digital)
4	Vcc (+5V)* max. 350 mA load
5	+5 V (for temperature sensors und Hallsensoren)
6	Hall2 (digital)
7	SIN-, A- (Encoder) or analog Hall sensor
8	SIN+, A+, (Encoder) or analog Hall sensor
9	Hall3 (digital)
10	Tmot*
11	COS-, B- (Encoder) or analog Hall sensor
12	COS+, B+ (Encoder) or analog Hall sensor
13	N+
14	N-
15	GND (Vcc)

*X13 Pin10 Tmot may not be connected at the same time as X15 (on Compaxx3M).

Note on F12:


*+5V (Pin 4) is measured and controlled directly at the end of the line via Sense+ and Sense-.

Maximum cable length: 100m

Caution!

- ◆ Pin 4 and Pin 5 must under no circumstances be connected!
- ◆ Plug in or pull out feedback connector only in switched off state (24VDC switched off).

3.8.2. Analogue / encoder (plug X11)





PIN X11	Reference High Density Sub D		
		Encoders	SSI
1	+24V (output) max. 70mA		
2	Ain1 -; analog input - (14Bits; max. +/-10V)		
3	D/A monitor channel 1 (±10V, 8-bit resolution)		
4	D/A monitor channel 0 (±10V, 8-bit resolution)		
5	+5 V (output for encoder) max. 150 mA		
6	- Input: steps RS422 (5V - level)	A/ (Input / -simulation)	Clock-
7	+ Input: steps RS422 (5V - level)	A/ (Input / -simulation)	Clock+
8	+ Input: direction RS422 (5V - level)	B Input / -simulation)	
9	Ain0 +: analog input + (14Bits; max. +/-10V)		
10	Ain1 +: analog input + (14Bits; max. +/-10V)		
11	Ain0 -: analog input- (14Bits; max. +/-10V)		
12	- Input: direction RS422 (5V - level)	B/ input / -simulation)	
13	factory use	N/ input / -simulation)	DATA-
14	factory use	N input / -simulation)	DATA+
15	GND		

Technical Data X11 (see on page 401)

3.8.2.1 Wiring of analog interfaces


Output Input



Perform an **offset adjustment** (see on page 251)!


Structure image of the **internal signal processing of the analog inputs**, Ain1 (X11/10 and X11/2) has the same wiring!

3.8.2.2 Connections of the encoder interface



The input connection is available in triple (for A & /A, B & /B, N & /N)

3.8.3. Digital inputs/outputs (plug X12)



Pin X12	Input/output	High density/Sub D	
1	O	+24 V DC output (max. 400mA)	
2	O0	No Error	Only for "fixed assignment" Functions are available, if "Fixed assignment" was selected for the I/O assignment in the configuration wizard
3	O1	Position / speed / gear synchronization attained (max. 100 mA)	
4	O2	Power stage without current (max.) 100 mA)	
5	O3	Axis energized with a setpoint of 0 (max. 100 mA)	
6	I0="1":	Quit (positive edge) / Axis enable	
	I0="0"	Axis disable with delay	
7	I1	no Stop	
8	I2	JOG +	
9	I3	JOG -	
10	I4	Reg input	
11	I	24V input for the digital outputs Pins 2 to 5	
12	I5	Limit switch 1	
13	I6	Limit switch 2	
14	I7	Machine zero initiator	
15	O	GND24V	

All inputs and outputs have 24V level.

Maximum capacitive loading of the outputs: 30nF (max. 2 Compax3 inputs can be connected)

Input-/Output extension

Optimization window display

The display of the digital inputs in the optimization window of the C3 ServoManager does not correspond to the physical status (24Volt=on, 0Volt=off) but to the logic status: if the function of an input or output is inverted (e.g. limit switch, negatively switching), the corresponding display (LED symbol in the optimization window) is OFF with 24Volts at the input and ON with 0 Volts at the input.


In operation via DeviceNet the inputs I0 ... I3 as well as the outputs O0 ... O3 can be freely assigned as an option.

Configurable via the C3 ServoManager (configuration: Operating mode / I/O assignment)

3.8.3.1 Connection of the digital Outputs/Inputs

Wiring of digital outputs


Compax3



The circuit example is valid for all digital outputs!
The outputs are short circuit proof; a short circuit generates an error.

Status of digital inputs

Compax3



The circuit example is valid for all digital inputs!
Signal level:
♦ > 9.15V = "1" (38.2% of the control voltage applied)
♦ < 8.05V = "0" (33.5% of the control voltage applied)

F1: Delayed action fuse

F2: Quick action electronic fuse; can be reset by switching the 24 VDC supply off and on again.

3.8.3.2 Logic proximity switch types

Type	1	2	3	4
Transistor switch	PNP	PNP	NPN	NPN
Logic	(N.O.) "active high"	(N.C.) "active low"	(N.O.) "active low"	(N.C.) "active high"
Description of logic	Compax3 sees a logical "1" upon activation	Compax3 sees a logical "0" upon activation	Compax3 sees a logical "0" upon activation	Compax3 sees a logical "1" upon activation
Fail safe logic	no	yes	Only conditional ¹⁾	no
Instruction for pull up resistor in the initiator	-	-	R _{min} =3k3 R _{max} =10k ²⁾	R _{min} =3k3 R _{max} =10k ²⁾
Connections				

¹⁾ When the connection between transistor emitter of the initiator and X12/15 (GND24V of the Compax3) is lost, it can not be guaranteed, that the Compax3 detects a logical „0“.

²⁾ The INSOR NPN types INHE5212 and INHE5213 manufactured by Schönbuch Electronic do correspond to this specification.

3.9 Installation and dimensions Compax3

In this chapter you can read about:


Mounting and dimensions Compax3S.....71
 Mounting and dimensions PSUP/C3M.....75
 Mounting and dimensions C3H.....77

3.9.1. Mounting and dimensions Compax3S

3.9.1.1 Mounting and dimensions Compax3S0xxV2

Mounting:

3 socket head screws M5



Stated in mm


Please respect an appropriate mounting gap in order to ensure sufficient convection:

- ◆ At the side: 15mm
- ◆ At the top and below: at least 100mm

3.9.1.2 Mounting and dimensions Compax3S100V2 and S0xxV4

Mounting:

3 socket head screws M5



Stated in mm


Please respect an appropriate mounting gap in order to ensure sufficient convection:

- ◆ At the side: 15mm
- ◆ At the top and below: at least 100mm

3.9.1.3 Mounting and dimensions Compax3S150V2 and S150V4

Mounting:

4 socket head screws M5




Please respect an appropriate mounting gap in order to ensure sufficient convection:

- ◆ At the side: 15mm
- ◆ At the top and below: at least 100mm

3.9.1.4 Mounting and dimensions Compax3S300V4

Mounting:

4 socket head screws M5



Stated in mm

Please respect an appropriate mounting gap in order to ensure sufficient convection:

- ◆ At the side: 15mm
- ◆ At the top and below: at least 100mm

Compax3S300V4 is force-ventilated via a fan integrated into the heat dissipator!

3.9.2. Mounting and dimensions PSUP/C3M

Ventilation: During operation, the device radiates heat (power loss). Please provide for a sufficient mounting distance below and above the device in order to ensure free circulation of the cooling air. Please do also respect the recommended distances of other devices. Make sure that the mounting plate is not exhibited to other temperature influences than that of the devices mounted on this very plate. The devices must be mounted vertically on a level surface. Make sure that all devices are sufficiently fixed.

3.9.2.1 Mounting and dimensions PSUP10/C3M050D6, C3M100D6, C3M150D6


The devices are force-ventilated via a ventilator fan fixed to the lower part of the heat dissipator!

Mounting spacing: At the top and below: at least 100mm

Information on PSUP10D6/C3M050D6, C3M100D6, C3M150D6

Mounting:

2 socket head screws M5




Tolerances: DIN ISO 2768-f

3.9.2.2 Mounting and dimensions PSUP20/PSUP30/C3M300D6

Information on PSUP20/PSUP30/C3M300D6

Mounting:


4 socket head screws M5



3.9.2.3 With upper mounting, the housing design may be different

Mounting:


3 socket head screws M5



3.9.3. Mounting and dimensions C3H

The devices must be mounted vertically on a level surface in the control cabinet.

Dimensions:




(1): Electronics
(2): Head dissipator

	H	H1	D	W	W1
C3H050V4	453mm	440mm	245mm	252mm	150mm
C3H090V4	668.6mm	630mm	312mm	257mm	150mm
C3H1xxV4	720mm	700mm	355mm	257mm	150mm

Mounting:4 screws M6

Ventilation: During operation, the device radiates heat (power loss). Please provide for a sufficient mounting distance below and above the device in order to ensure free circulation of the cooling air. Please do also respect the recommended distances of other devices. Make sure that the mounting plate is not exhibited to other temperature influences than that of the devices mounted on this very plate. If two or more devices are combined, the mounting distances are added.


3.9.3.1 Mounting distances, air currents Compax3H050V4



in mm

	I	J	K	L	M
C3H050V4	15	5	25	70	70


3.9.3.2 Mounting distances, air currents Compax3H090V4



in mm

	I	J	K	L	M
C3H090V4	0	0	25	70	70

3.9.3.3 Mounting distances, air currents Compax3H1xxV4



in mm

	I	J	K	L	M
C3H1xxV4	0	0	25	70	70

3.10 Safety function - STO (=safe torque off)

In this chapter you can read about:

General Description.....	80
STO (= safe torque off) with Compax3S	83
STO (= safe torque off) with Compax3m (Option S1).....	95

3.10.1. General Description

In this chapter you can read about:

Important terms and explanations	80
Intended use	81
Advantages of using the "safe torque off" safety function.	81
Devices with the STO (=safe torque off) safety function	82

The present documentation assumes a basic knowledge of our drive controllers as well as an understanding of safety-oriented machine design. References to standards and other regulations are only rudimentarily expressed.

For complementary information, we recommend the respective technical literature.

3.10.1.1 Important terms and explanations

Term	Explanation
Safety category 3 in accordance with EN ISO 13849-1	<p>Definition according to standard: Circuit with safety function against individual errors. Some, but not all errors are detected. An accumulation of errors may lead to a loss of the safety function. The remaining risk is accepted. The determination of the safety category required for an application (risk analysis) lies within the responsibility of the machine manufacturer. It can take place according to the method described in EN ISO 13849-1, appendix A.</p>
"Safe torque off" or abbreviated: STO=Safe torque off	<p>With the "safe torque off", the energy supply of the drive is safely interrupted according to EN 1037, paragraph 4.1. The drive is not to be able to produce a torque and thus dangerous movements (see EN 1037, paragraph 5.3.1.3). The standstill position must not be monitored. If an external force effect, e.g. a drop of hanging loads, is possible with the "safe torque off", additional measures to safely prevent those must be provided (e.g. additional mechanical brakes). The following measures are appropriate for a "safe torque off": Contactor between mains and drive system (mains contactor) Contactor between power section and motor (motor contactor) Safe blocking of the power semiconductor control (start inhibitor)</p>
Start inhibitor	<p>Safe blocking of the power semiconductor control. With the aid of this function, you can obtain a "safe torque off".</p>

Stop categories according to EN60204-1 (9.2.2)

Stop category	Safety function	Requirement	System behavior	Remark
0	Safe torque off (STO)	Stopping by immediately switching off the energy supply of the machine drive elements	Uncontrolled stop	Uncontrolled stop is the stopping of a machine movement by switching off the energy of the machine drive elements. Available brakes and/or other mechanical stopping components are applied.
1	Safe stop 1 (SS1)	Stop where the energy of the machine drive elements is maintained in order to reach a stop. The energy supply is only interrupted, if the standstill is attained.	Controlled stop	Controlled stop is the stopping of a machine movement by for instance resetting the electrical command signal to zero, as soon as the stop signal has been detected by the controller, the electrical energy for the machine drive elements remains however during the stopping procedure.
2	Safe stop 2 (SS2)	Stop where the energy to the machine drive elements is maintained.	Controlled stop	This category is not covered.

3.10.1.2 Intended use

The Compax3 drive controller supports the "safe torque off" (STO) safety function, with protection against unexpected startup according to the requirements of EN ISO 13849-1, category 3 to PLe and EN 1037.

Together with the external safety control device, the "safe stop 1" (SS1) safety function according to the requirements of EN ISO 13849-1 category 3 can be used. As the function is however realized with the aid of an individually settable time delay on the safety switching device, you must take into account that, due to an error in the drive system during the active braking phase, the axis trundles to a stop unguided or may even accelerate actively in the worst case until the expiry of the preset switch-off time.

According to a risk evaluation which must be carried out according to the machine standard 98/37/EG and 2006/42/EG or EN ISO 12100, EN ISO 13849-1 and EN ISO 14121-1, the machine manufacturer must project the safety system for the entire machine including all integrated components. This does also include the electrical drives.

Qualified personnel

Projecting, installation and setup require a detailed understanding of this description.

Standards and accident prevention regulation associated with the application must be known and respected as well as risks, protective and emergency measures.

3.10.1.3 Advantages of using the "safe torque off" safety function.

Safety category 3 in accordance with EN ISO 13849-1

Requirements performance feature	Use of the safe torque off function	Conventional solution: Use of external switching elements
Reduced switching overhead	Simple wiring, certified application examples Grouping of drive controllers on a mains contactor is possible.	Two safety-oriented power contactors in series connection are required.
Use in the production process High operating cycles, high reliability, low wear	Extremely high operating cycles thanks to almost wear-free technology (low-voltage relay and electronic switch). The "safe torque off" status is attained due to the use of wear-free electronic switches (IGBTs).	This performance feature cannot be reached with conventional technology.
Use in the production process High reaction speed, fast restart	Drive controller remains performance- and control-oriented in connected state. No significant waiting times due to restart.	When using power contactors in the supply, a long waiting time for the energy discharge of the DC link circuit is required. When using two power contactors on the motor side, the reaction times may increase, you must however take into consideration other disadvantages: a) Securing that switching takes only place in powerless state (Direct current! Constant electric arcs must be prevented). b) Increased overhead for EMC conform wiring.
Emergency-stop function	According to the German version of the standard: Permitted without control of mechanical power switching elements 1)	Switch-off via mechanical switching elements is required

1) According to the preface of the German version of the EN 60204-1/11.98, electronic equipment for emergency-stop devices are also permitted, if they comply with the safety categories as described in EN ISO 13849-1.

3.10.1.4 Devices with the STO (=safe torque off) safety function

Safety function - STO (=safe torque off):

Compax3 technology function

◆ I10T10, I11T11, I12T11

◆ I11T30, I20T30, I21T30, I22T30, I30T30, I31T30, I32T30,
I11T40, I20T40, I21T40, I22T40, I30T40, I31T40, I32T40

◆ I20T11, I21T11, I22T11, I30T11, I31T11, I32T11

◆ C10T11, C10T30, C10T40,

C13T11, C13T30, C13T40,

C20T11, C20T30, C20T40

with the device power / series

S025V2, S063V2, S100V2, S150V2, S015V4, S038V4, S075V4, S150V4,
S300V4

M050D6, M100D6, M150D6, M300D6,

and is only valid with the stated conditions of utilization.

3.10.2. STO (= safe torque off) with Compax3S

In this chapter you can read about:

STO Principle (= Safe Torque Off) with Compax3S.....	83
Conditions of utilization STO (=safe torque off) Safety function.....	85
Notes on the STO function.....	85
STO application example (= safe torque off).....	87
Technical Characteristics STO Compax3S	94

3.10.2.1 STO Principle (= Safe Torque Off) with Compax3S

To ensure safe protection against a motor starting up unexpectedly, the flow of current to the motor and thus to the power output stage must be prevented.

This is accomplished for Compax3S with two measures independent of each other (Channel 1 and 2), without disconnecting the drive from the power supply:

Channel 1:

Activation of the power output stage can be disabled in the Compax3 controller by means of a digital input or with a fieldbus interface (depending on the Compax3 device type) (deactivation of the energize input).


Channel 2:

The power supply for optocouplers and drivers of power output stage signals is disconnected by a safety relay activated by the enable input "ENAIN"(X4/3) and equipped with force-directed contacts. This prevents control signals from being transferred to the power output stage.



**The STO (= Safe Torque Off) safety function in accordance with EN ISO 13849-1: 2008 PLd or PLe, Kat.3 is only possible when using both channels via an external safety switching device
Please note the application examples!**


Circuit diagram illustrating working principle:



Notes

- ◆ In normal operation of Compax3, 24VDC of power is supplied to the "Enable" input (X4/3). The control of the drive takes then place via the digital inputs/outputs or via the fieldbus.

STO delay times



The deceleration time $t_{deceleration}$ depends on the configuration of the Compax3. It must be configured so that oscillation free bringing to standstill is possible, depending on the mechanical load. The delay time t_{delay_time} must be set in the safety control device UE410 so that $t_{delay_time} > t_{deceleration}$.

Only after the elapsing of the relay delay $t_{delay_relay_ch2}$, the STO function is completely activated. The relay delay time $t_{delay_relay_ch2}$ is 15 ms.

3.10.2.2 Conditions of utilization STO (=safe torque off) Safety function

- ◆ STO can only be implemented in Compax3 with a corresponding safety switching device considering the application examples.
- ◆ Safety functions must be tested 100%.
- ◆ The Compax3S and the safety switching device used must be mounted in a protected way (IP54 mounting cabinet).
- ◆ Only qualified staff members are permitted to install the STO (=safe torque off) function and place it in service.
- ◆ For all applications in which the first channel of the “Safe torque off” is implemented by means of a PLC, care must be taken that the part of the program that is responsible for current flowing to or not flowing to the drive is programmed with the greatest possible care. The Safe Torque off application example of Compax3 with fieldbus should be considered.
The designer and operator responsible for the system and machine must refer programmers who are involved to these safety-related points.
- ◆ Terminal X4/2 (GND 24 V and at the same time the reference point for the safety relay bobbin) must be connected with the PE protective lead. This is the only way to ensure protection against incorrect operation through earth faults (EN60204-1 Section 9.4.3)!
- ◆ All conditions necessary for CE-conform operation must be observed.
- ◆ When using an external safety switching device with adjustable delay time, (as illustrated in the STO application example), it must be ensured that the delay time cannot be adjusted by persons not authorized to do so (for example by applying a lead seal). With the UE410-MU3T5 safety switching device, this is not necessary, if the anti manipulation measures are respected.
- ◆ The adjustable delay time on the safety switching device must be set to a value greater than the duration of the braking ramp controlled by the Compax3 with maximum load and maximum speed.
If the setting range for the specified Emergency power-off module is not sufficient, the Emergency power-off module must be replaced by another equivalent module.
- ◆ All safety-related external leads (for example the control lead for the safety relay and feedback contact) must absolutely be laid so they are protected, for example in a cable duct. Short circuits and crossed wires must be reliably excluded!
- ◆ If there are external forces operating on the drive axes, additional measures are required (for example additional brakes). Please note in particular the effects of gravity on suspended loads!

3.10.2.3 Notes on the STO function

- ◆ It should be noted in connection with the STO (= safe torque off) application example illustrated here that after the Emergency stop switch has been activated, no galvanic isolation in accordance with EN 60204-1 Section 5.5 is guaranteed. This means that the entire system must be disconnected from the mains power supply with an additional main switch or mains power contactor for repair jobs. Please note in this regard that even after the power is disconnected, dangerous electrical voltages may still be present in the Compax3 drive for about 10 minutes.
- ◆ During the active braking phase of Stop category 1 (controlled bringing to a stop with safely monitored delay time according to EN60204-1) or safe stop 1, faulty function must be expected. If an error in the drive system or mains failure occurs during the active braking phase, the axis may trundle to a stop unguided or might even actively accelerate until the expiry of the defined switch-off time.
- ◆ Please note that the control of the drive via Energize (Energize input or fieldbus interface) is not executed in all operating conditions. The following restrictions apply when the set-up window of the C3 ServoManager is used:
 - ◆ If the setup mode is switched on, the fieldbus interface and the energize input are blocked.
 - ◆ the energize input can be ignored if the input simulator is activated (depending on the settings).

Note on error switch-off

If the "safe torque off" function of Compax3 is required or used for a machine or system, the two errors:

- ◆ "Motor_Stalled" (Motor stalled) and
- ◆ "Tracking" (following error)

are not to be switched off (see on page 140, see on page 154).

3.10.2.4 STO application example (= safe torque off)

In this chapter you can read about:

Circuit layout overview.....	87
Safe torque off layout with bus.....	91


The application example described here corresponds to Stop Category 1 as defined by EN60204-1.

Together with the external safety switching device, the "Safe Stop 1"(SS1) safety function can also be implemented.

A Stop Category 0 in accordance with EN 60204-1 can be implemented, for example by setting the delay time on the Emergency power-off module as well as on the Compax3 (delay time for "switch to currentless") to 0. The Compax3M will then be turned off immediately in 2 channels and will therefore not be able to generate any more torque. Please take into consideration that the motor will not brake and a coasting down of the motor may result in hazards. If this is the case, the STO function in stop category 0 is not permitted.

Circuit layout overview

- ◆ 2 Compax3 devices (the circuit example is also valid for one or multiple devices, if it is adapted accordingly)
- ◆ 1 Emergency Power-off module (UE410-MU3T5 manufactured by Sick)
With adjustable delayed deactivation of the Compax3 enable input ENAi.
The time must be set so that all axes are at a standstill before the Compax3 controllers are deactivated.
- ◆ The operating instructions of the UE410-MU3T5 safety switching device must be observed.
- ◆ 1 emergency power-off switch
- ◆ Hazardous area accessible via a safety door with safety door switch S6.
- ◆ 1 pushbutton per Compax3
- ◆ For the Energize input on Compax3, a debouncing time > 3 ms must be configured
- ◆ 1 relay per Compax3
The relay must be dimensioned so that it has a lifetime of at least 20 years, taking the cycle time into consideration. If this is not the case, the relays must be exchanged for new relays after expiration of the lifetime.



Energize = I0 (X12/6) Quit = I2 (X12/8)

Instead of the safety switching device manufactured by Sick mentioned above, you may use other safety switching devices.

The safety switching device must however provide the following features:

- ◆ 1 normally open contact is required for switching off channel 1 (as an alternative, a safe semiconductor output is possible)
- ◆ 1 off-delayed normally open safety contact is required for switching off channel 2 (as an alternative, a safe semiconductor output with adjustable delay time for the high_to_low_edge is possible).
- ◆ 1 one-channel monitoring circuit where the feedback contacts of channels 1 and 2 can be integrated for simultaneous monitoring, is required.
At the same time it must be possible to integrate a one-channel start button for activation of the safety switching device into the circuit.
A new start may only be successful, if it is ensured, that channels 1 and 2 are switched off.
- ◆ 1 two-channel connection for emergency power off and/or safety door contacts with cross fault monitoring is required.
- ◆ The safety switching device must feature performance PL e. The I/Os must at least correspond to category 3.

Switches and buttons:

1 N/C (S4, S5) per device:	Guide Device to a currentless state
S6:	closed when the safety door is closed
S2:	Activate safety switching device

Caution! Module UET410-MU3T5 modulates regularly test switching signals (OSSD) on outputs Q3 and Q4.
We recommend to use a filter > 3 ms for signal Q3 in the PLC.

Safe torque off description

In this chapter you can read about:

Basic functions:93
Access to the hazardous area94

In this chapter you can read about:

Safe torque off basic function89
Access to the hazardous area90

Safe torque off basic function

Compax3 devices disabled by:

- Channel 1: Energize input to "0" by safety switching device output Q3
- Channel 2: Enable input ENAI to "0" by safety switching device output Q4

Activate safety switching device

Before the Compax3 can be placed into operation, the safety switching device must be activated by a pulse to Input S2.

Prerequisite:

- ◆ S2 closed
- ◆ Safety door closed
- ◆ K1 and K2 energized
 - ◆ K1: receives current if Compax3 Device 1 is currentless (output = "1" in currentless state) = Channel 1 feedback
 - ◆ K2: receives current if Compax3 device 2 is currentless (output = "1" in the currentless state) = channel 1 feedback
- ◆ The feedback contact of all Compax3 devices must be closed (channel 2).

Energize Compax3 (Motor and power output stage)

- ◆ With the safety switching device, the Compax3 devices are enabled via the energize input and the Enable input ENAI. (If an error is still present in the Compax3, it must be acknowledged - the ackn function depends on the Compax3 device type)
- ◆ The motors are energized with current.

Summary: Compax3 is only energized if the feedback functions are capable of functioning via two channels.

Access to the hazardous area

Actuate emergency power-off switch

Due to the interruption on two channels at the emergency power-off switch, the safety switching device is deactivated - output Q3 is immediately "0".

Channel 1: Via the Energize input, the Compax3 devices receive the command to guide the drive to a currentless state (using the ramp configured in the C3 ServoManager for "drive disable").

Channel 1 feedback 1: The "Controller Feedback" Compax3 outputs supply current to Relays K1 and K2.

Channel 2: After the delay time set in the safety switching device, (this time must be set so that all drives are stopped after it has elapsed) the output Q4 = "0", which in turn deactivates the Enable inputs ENAin of the Compax3 devices.

Channel 2 feedback: Via the series circuit of all feedback contacts, the "Safe Torque-off" status (all Compax3 devices without current) is reported.

Only if the drives are all at a standstill, the safety door may be opened and the hazardous area may be accessed.

If the safety door is opened during operation and the emergency-power-off switch was not triggered before, the Compax3 drives will also trigger the stop ramp.



Caution! The drives may still move.

If danger to life and limb of a person entering cannot be excluded, the machine must be protected by additional measures (e.g. a safety door locking).

Technical Characteristics STO Compax3S

Safety technology Compax3S

<p>Safe torque-off in accordance with EN ISO 13849: 2008, Category 3, PL d/e Certified. Test mark IFA 1003004</p>	<ul style="list-style-type: none"> ◆ For implementation of the "protection against unexpected start-up" function described in EN1037. ◆ Please note the circuitry examples (see on page 80).
---	---

Compax3S STO (=safe torque off)

Nominal voltage of the inputs	24 V
Required isolation of the 24V control voltage	Grounded protective extra low voltage, PELV
Protection of the STO control voltage	1 A
Grouping of safety level	<p>STO switch-off via internal safety relay & digital input: PL e, PFHd=2.98E-8</p> <p>STO switch-off via internal safety relay & fieldbus: PL d, PFHd=1.51E-7</p> <p>A MTTFd=15 of the external PLC and STO cycles/year < 500 000 are assumed.</p>


Safe torque off layout with bus

- ◆ 2 Compax3 devices (the circuit example is also valid for one or multiple devices, if it is adapted accordingly)
- ◆ 1 Emergency Power-off module (UE410-MU3T5 manufactured by Sick)
With adjustable delayed deactivation of the Compax3 enable input ENAi.
The time must be set so that all axes are at a standstill before the Compax3 controllers are deactivated.
- ◆ The operating instructions of the UE410-MU3T5 safety switching device must be observed.
- ◆ 1 emergency power-off switch
- ◆ Hazardous area accessible via a safety door with safety door switch S6.
- ◆ 1 pushbutton per Compax3

Circuit:

control: **Control word** (see on page 318)

status: **Status word** (see on page 321)



Instead of the safety switching device manufactured by Sick mentioned above, you may use other safety switching devices.

The safety switching device must however provide the following features:

- ◆ 1 normally open contact is required for switching off channel 1 (as an alternative, a safe semiconductor output is possible)
- ◆ 1 off-delayed normally open safety contact is required for switching off channel 2 (as an alternative, a safe semiconductor output with adjustable delay time for the high_to_low_edge is possible).
- ◆ 1 one-channel monitoring circuit where the feedback contacts of channels 1 and 2 can be integrated for simultaneous monitoring, is required.
At the same time it must be possible to integrate a one-channel start button for activation of the safety switching device into the circuit.
A new start may only be successful, if it is ensured, that channels 1 and 2 are switched off.
- ◆ 1 two-channel connection for emergency power off and/or safety door contacts with cross fault monitoring is required.
- ◆ The safety switching device must feature performance PL e. The I/Os must at least correspond to category 3.

Switches and buttons:

1 N/C (S4, S5) per device:	Guide Device to a currentless state
S6:	closed when the safety door is closed
S2:	Activate safety switching device

Caution! Module UET410-MU3T5 modulates regularly test switching signals (OSSD) on outputs Q3 and Q4.
We recommend to use a filter > 3 ms for signal Q3 in the PLC.

Safe torque off description

Basic functions:

Compax3 devices disabled by:

Channel 1: Energize deactivated by PLC and safety switching device output Q3.

Channel 2: Enable input to "0" by safety switching device output Q4.

Activate safety switching device

Before the Compax3 can be placed into operation, the safety switching device must be activated by a pulse to Input S2.

Prerequisite:

- ◆ S2 closed
- ◆ Safety door closed: only then the safety door monitor will enable the safety switching device on two channels
- ◆ Feedback activated via PLC (Controller feedback channel 1: motor not energized)
- ◆ The feedback contact of all Compax3 devices must be closed (channel 2).

Energize Compax3 (Motor and power output stage)

- ◆ The PLC enables the Compax3 devices by means of the control word and the safety switching device enables the Compax3 devices by means of the Enable input. (If an error is still present on the Compax3, it must be acknowledged before)
- ◆ The motors are energized with current.

Summary: Compax3 is only energized if the feedback functions are capable of functioning via two channels.

Access to the hazardous area

Actuate emergency power-off switch

Due to the interruption on two channels at the emergency stop switch, the safety switching device is deactivated - output Q is immediately "0".

The PLC evaluates this and responds as follows:

Channel 1: The Compax3 devices receive via the control word the command to guide the drive to currentless state (via the ramp for "deenergizing" configured in the C3 ServoManager).

Channel 1 feedback: The Compax3 feedback via the status word is evaluated by the PLC and passed on to the safety switching device via the Compax3 Feedback (X4.4 and X4.5).

Channel 2: After the delay time set in the safety switching device, (this time must be set so that all drives are stopped after it has elapsed) the output Q4 = "0", which in turn deactivates the Enable inputs ENAiN of the Compax3 devices.

Channel 2 feedback: Via the series circuit of all feedback contacts, the "Safe Torque-off" status (all Compax3 devices without current) is reported.

Only if the drives are all at a standstill, the safety door may be opened and the hazardous area may be accessed.

If the safety door is opened during operation and the emergency-power-off switch was not triggered before, the Compax3 drives will also trigger the stop ramp.



Caution! The drives may still move.

If danger to life and limb of a person entering cannot be excluded, the machine must be protected by additional measures (e.g. a safety door locking).

3.10.2.5 Technical Characteristics STO Compax3S

Safety technology Compax3S

Safe torque-off in accordance with ISO 13849: 2008, Category 3, PL d/e Certified. Test mark IFA 1003004	<ul style="list-style-type: none"> ◆ For implementation of the "protection against unexpected start-up" function described in EN1037. ◆ Please note the circuitry examples (see on page 80).
--	---

Compax3S STO (=safe torque off)

Nominal voltage of the inputs	24 V
Required isolation of the 24V control voltage	Grounded protective extra low voltage, PELV
Protection of the STO control voltage	1 A
Grouping of safety level	STO switch-off via internal safety relay & digital input: PL e, PFHd=2.98E-8 STO switch-off via internal safety relay & fieldbus: PL d, PFHd=1.51E-7 A MTTFd=15 of the external PLC and STO cycles/year < 500 000 are assumed.

3.10.3. STO (= safe torque off) with Compax3m (Option S1)

In this chapter you can read about:


Safety switching circuits	95
Safety notes for the STO function in the Compax3M.....	96
Conditions of utilization for the STO function with Compax3M.....	96
STO delay times	97
Compax3M STO application description	98
STO function test	102
Technical details of the Compax3M S1 option.....	104

3.10.3.1 Safety switching circuits

The current flow in the motor windings is controlled by a power semiconductor bridge (6-fold IGBT). A processor circuit and PWM circuit will switch the IGBT with rotary field orientation. Between control logic and power module, optocouplers are used for potential separation.

On the Compax3M drive controller with S1 option, the X14 (STO) connector can be found on the front plate. 2 optocouplers are controlled on two channels via the STO1/ and STO2/ terminals of this connector. When requesting the STO via an external safety switching device, the two auxiliary voltage supply channels of the power stage control circuits are switched off on two channels. Therefore the power transistors (IGBTs) for the motor current can not longer be switched on.

The hardware monitor detects the failure of the optocoupler circuit of a channel by always checking both channels for similarity. If the hardware monitor detects a discrepancy for a defined time (ax. 20s), the error will be stored in the hardware memory. The processor signals this error externally via the 0x5493 error code. An activation of the coupler supply can then only take place via a hardware reset (switching off and on again) of the device.



* Potential separation with optocoupler.

3.10.3.2 Safety notes for the STO function in the Compax3M

- ◆ It should be noted in connection with the STO application examples illustrated here that after the Emergency stop switch has been activated, no galvanic isolation in accordance with EN 60204-1 Section 5.5 is guaranteed. This means that the entire system must be disconnected from the mains power supply with an additional main switch or mains power contactor for repair jobs. Please note in this regard that even after the power is disconnected, dangerous electrical voltages may still be present in the Compax3 drive for about 10 minutes.
- ◆ During the active braking phase of Stop category 1 (controlled bringing to a stop with safely monitored delay time according to EN60204-1) or safe stop 1, faulty function must be expected. If an error in the drive system occurs during the active braking phase, the axis may trundle to an unguided stop or might even actively accelerate until the expiry of the defined switch-off time.
- ◆ For synchronous motors operated in the field weakening range, the operation of the STO function may lead to over speed and destructive, life-threatening over voltages as well as explosions in the servo drive. Therefore, NEVER use the STO function with synchronous drives in the field-weakening range.
- ◆ It is important to note that if the drive is being activated (Energize) by the USB / RS485 interface, it may not be possible to execute switch-off by a controlled braking ramp. For example, this is true when the set-up window of the C3 ServoManager is used. If set-up mode is turned on or with the input simulator, the digital I/O interface and fieldbus interface are automatically disabled.


Maintenance

When using the S1 option, a protocol describing the orderly working of the safety function must be made upon the setup and in defined maintenance intervals (see protocol proposal).

3.10.3.3 Conditions of utilization for the STO function with Compax3M

- ◆ The STO safety function must be tested and protocolled **as described** (see on page 102). The safety function must be requested at least once a week. In safety door applications, the weekly testing interval must not be observed, as you can assume that the safety doors will be opened several times during the operation of the machine.
- ◆ The Compax3M with integrated STO safety function as well as the utilized safety switching devices must be mounted protected (IP54 control cabinet).
- ◆ Only qualified staff members are permitted to install the STO function and place it in service.
- ◆ The X9/2 (GND24V) terminal on the PSUPxx mains module must be connected to the PE protective lead. This is the only way to ensure protection against incorrect operation through earth faults (EN60204-1 Section 9.4.3)!
- ◆ When using an external safety switching device with adjustable delay time, (as illustrated in the STO application example), it must be ensured that the delay time cannot be adjusted by persons not authorized to do so (for example by applying a lead seal). With the UE410-MU3T5 safety switching device, this is not necessary, if the anti manipulation measures are respected.
- ◆ The adjustable delay time on the safety switching device must be set to a value greater than the duration of the braking ramp controlled by the Compax3 with maximum load and maximum speed.
- ◆ All conditions necessary for CE-conform operation must be observed.
- ◆ If there are external forces operating on the drive axes, additional measures are required (for example additional brakes). Please note in particular the effects of gravity on suspended loads! This must be respected above all for vertical axes without self-locking mechanical devices or weight balance.
- ◆ When using synchronous motors, a short movement over a small angle is possible, if two errors occur simultaneously in the power section. This depends on the number of pole pairs of the motor (rotary types: 2 poles = 180°, 4 poles = 90°, 6 poles = 60°, 8 poles = 45°, Linear motors: 180° electrically).

3.10.3.4 STO delay times




3.10.3.5 Compax3M STO application description

In this chapter you can read about:

- STO function with safety switching device via Compax3M inputs 98
- STO function with safety switching device for T11 applications with fieldbuses 99
- Emergency stop and protective door monitoring without external safety switching device.101

STO function with safety switching device via Compax3M inputs



Recommendation Energize = I0 (X12/6) (debounceable digital input)

The acknowledgement S2 via the safety control UE410-MU3T5 is only necessary, if after the disabling of the STO function, a danger to any person or to the machine could arise by automatic starting. During the **Configuration des Compax3M** (see on page 135) you must see to a debouncing time >3ms being configured for the Energize input.

The operating instructions of the UE410-MU3T5 safety control must be observed.

The Compax3M devices and the UE410-MU3T5 safety control must be mounted in the same control cabinet.


1 N.C. (S3, S4) per device	Guide Device to a currentless state
S1	closed when the safety door is closed
S2	Activate safety switching device

STO function with safety switching device for T11 applications with fieldbuses

In this chapter you can read about:

Energize and deenergize circuitry.....99
 Function description for fieldbus applications with T11 devices:..... 100

Energize and deenergize circuitry



*** With Profibus I20T11:**

Status change in:	
0 -> 1	SB1 (speed) SC1 (positioning)
1 -> 0	SA2

*** for T11 devices with CANopen, DeviceNet, Ethernet Powerlink or Ethercat:**

Status change in:	
0 -> 1	Operation enable
1 -> 0	Switch on disabled

The operating instructions of the UE410-MU3T5 safety control must be observed.
 The Compax3M devices and the UE410-MU3T5 safety control must be mounted in the same control cabinet.

Caution!

Module UET410-MU3T5 modulates regularly test switching signals (OSSD) on outputs Q3 and Q4.

We recommend to use a filter > 3 ms for signal Q3 in the PLC.

Function description for fieldbus applications with T11 devices:

When opening the safety door or after actuating the emergency power-off switch, it is ensured via output Q3 and the external control that the Compax3M servo drives will enter the following state immediately:

- ◆ "SA2"
(for Profibus) or (braking ramp followed by software switch-off)
- ◆ "Switched On Disabled"
for fieldbusses based on the CANopen profile

In the programmable Compax3 devices (T30, T40), this switch-off is realized with the MC_power function module. Then after the delay time set on the UE410-MU3T5 safety control, the STO function in the drives is triggered via the Q4 output. The servo drives are afterwards in safe torqueless state. The delay time must be set on the safety control so that the braking ramp in the drives has run off and the drives are at standstill when the delay time has elapsed.

The application example described here corresponds to Stop Category 1 as defined by EN60204-1. Together with the external safety switching device, the "Safe Stop 1" safety function can be implemented.

A Stop Category 0 in accordance with EN 60204-1 can be implemented, for example by setting the delay time on the safety switching device to 0. The Compax3M will then be turned off immediately in 2 channels and will therefore not be able to generate any more torque. Please take into consideration that the motor will not brake and a coasting down of the motor may result in hazards. If this is the case, the STO function in stop category 0 is not permitted.


The acknowledgement via the safety control UE410-MU3T5 is only necessary, if after the disabling of the STO function, a danger to any person or to the machine could arise due to automatic startup.

Emergency stop and protective door monitoring without external safety switching device.

With Compax3M, a 2-channel protective door monitoring switch or a 2 channel emergency power-off switch can be directly connected. The figure below visualizes an application with 2 channel protective door monitoring switch.

The Compax3M drive modules with PSUPxx mains rectifier must be located in a protected area (IP54 control cabinet). Outside this protected area, the line guiding to the external switches must be separated channelwise or must be especially protected (blinded).

It is also permitted to use one acknowledgement switch for both servo drives at a time. In both cases the acknowledgement does only correspond to category B, therefore this acknowledgement should not be used if there is any possibility of stepping in the dangerous area. In this case, an external acknowledgement device must be used.



3.10.3.6 STO function test

The STO function must be checked in the event of:

- ◆ Commissioning
- ◆ After each exchange of any equipment within the system
- ◆ After each intervention into the system wiring
- ◆ In defined maintenance intervals (at least once per week) and after a longer standstill of the machine

If the STO function was triggered by opening a protective door and if this door is opened several times a week, the weekly testing interval is not required.

The check must be made by qualified personnel adhering to all necessary safety precautions.

The following testing steps must be performed:

STO Test	Action, activity	Expected reaction and effect
1	24V DC voltage on terminal X14.1 and X14.3	
2	Switch on power and 24V supply voltage	No error must be present
3	Configuring the device	No error must be present
4	Testing active STO on terminal X14.1 and X14.3: Remove 24V DC on terminal X14.1 and X14.3 at the same time	Error message 0x5492 must be present 1)
5	Re-apply 24V DC voltage on terminals X14.1 and X14.3 and then acknowledge error	No error must be present
6	Then switch off and on again 24V voltage supply	No error must be present

1) In order to automate the test, it is sufficient here to monitor the general error output with an external logic.

A manual check of the torqueless drive is here also sufficient.

The triggering of the STO can also be made by actuating the emergency stop switch. During the automated test, the STO can also be triggered via the contacts of an external relay

Following the test steps

The performance of the individual test steps of the STO function must be logged. A protocol specimen can be found in the following section.

Depending on the machine version, additional or other test steps may be required.

STO test protocol specimen

General information:

Project/machine:

Servo axis:

Name of the tester:

STO function test:

Test specification according to the
Compax3 release:

STO function test steps 1-6: successfully tested

Acknowledgement safety switching device: successfully tested
 is not used

Safe stop 1: successfully tested
 is not used

Initial acceptance on:

Repeat check on:

Signature of the tester

Signature of the tester

3.10.3.7 Technical details of the Compax3M S1 option

Safety technology Compax3M

Safe torque-off in accordance with EN ISO 13849-1: 2007, Category 3, PL=e Certified. Test mark MFS 09029	◆ Please respect the stated safety technology on the type designation plate (see on page 13) and the circuitry examples (see on page 95)
---	---

Compax3M S1 Option: Signal inputs for connector X14

Nominal voltage of the inputs	24V
Required isolation of the 24V control voltage	Grounded protective extra low voltage, PELV
Protection of the STO control voltage	1A
Number of inputs Signal inputs via optocoupler	2 Low = 0...7V DC or open High = 15...30V DC I_{in} at 24V DC: 8mA
STO1/	Low = STO activated High = STO deactivated Reaction time max. 3ms
STO2/	Low = STO activated High = STO deactivated Reaction time max. 3ms
Switch-off time with unequal input statuses (max. reaction time)	20 seconds
Grouping of safety level	Category 3 PL=e (according to table 4 in EN ISO 13849-1 this corresponds to SIL 3) PFHd=4.29E-8

4. Setting up Compax3

In this chapter you can read about:

Configuration	105
Configuring the signal Source	157
Load control	161
Optimization	166

4.1 Configuration

In this chapter you can read about:

Test commissioning of a Compax3 axis	107
Selection of the supply voltage used	107
Motor selection	107
Optimize motor reference point and switching frequency of the motor current	108
Ballast resistor	111
General drive	111
Defining the reference system	112
Defining jerk / ramps	136
Limit and monitoring settings	139
Encoder simulation	142
I/O Assignment	142
Position mode in reset operation	144
Reg-related positioning / defining ignore zone	146
Write into set table	147
Motion functions	148
Error response	154
Configuration name / comments	155
Dynamic positioning	155

The general proceeding in order to operate an empty-running motor is described [here](#) (see on page 107).

Configurations sequence:

Installation of the C3 ServoManager

The Compax3 ServoManager can be installed directly from the Compax3 DVD. Click on the corresponding hyperlink resp. start the installation program "C3Mgr_Setup_V.....exe" and follow the instructions.

PC requirements

Recommendation:

Operating system:	MS Windows XP SP2 / MS Windows 2000 as from SP4 / (MS Vista)
Browser:	MS Internet Explorer 6.x
Processor:	Intel Pentium 4 / Intel Core 2 Duo / AMD Athlon class as from >=2GHz
RAM memory:	>= 1024MB
Hard disk:	>= 20GB available memory
Drive:	DVD drive
Monitor:	Resolution 1024x768 or higher
Graphics card:	on onboard graphics (for performance reasons)
Interface:	USB

Minimum requirements:

Operating system:	MS Windows XP SP2 / MS Windows 2000 as from SP4
Browser:	MS Internet Explorer 6.x
Processor:	>=1.5GHz
RAM memory:	512MB
Hard disk:	10GB available memory
Drive:	DVD drive
Monitor:	Resolution 1024x768 or higher
Graphics card:	on onboard graphics (for performance reasons)
Interface:	USB

Note:

- ◆ For the installation of the software you need administrator authorization on the target computer.
- ◆ Several applications running in parallel, reduce the performance and operability.
- ◆ Especially customer applications, exchanging standard system components (drivers) in order to improve their own performance, may have a strong influence on the communication performance or even render normal use impossible.
- ◆ Operation under virtual machines such as Vware Workstation 6/ MS Virtual PC is not possible.
- ◆ Onboard graphics card solutions reduce the system performance by up to 20% and cannot be recommended.
- ◆ Operation with notebooks in current-saving mode may lead, in individual cases, to communication problems.

Connection between PC and Compax3

Your PC is connected with Compax3 via a RS232 cable (**SSK1** (see on page 383)).

Cable **SSK1** (see on page 383) (COM 1/2-interface on the PC to X10 on the Compax3 or via adapter SSK32/20 on programming interface of Compax3H).

Start the Compax3 ServoManager and make the setting for the selected interface in the "**Options Communication settings RS232/RS485...**" menu.

Device Selection

In the menu tree under device selection you can read the device type of the connected device (Online Device Identification) or select a device type (Device Selection Wizard).

Configuration

Then you can double click on "Configuration" to start the configuration wizard. The wizard will lead you through all input windows of the configuration.

Input quantities will be described in the following chapters, in the same order in which you are queried about them by the configuration wizard.

4.1.1. Test commissioning of a Compax3 axis

In the device online help, we show you at this place an animation of a test setup with the aim to move an unloaded motor.

- ◆ Simple and independent of the Compax3 device variant*
- ◆ Without overhead for configuration
- ◆ Without special knowledge in programming

* for device specific functions, please refer to the corresponding device description.

Due to continuous optimization, individual monitor displays may have changed. This does however hardly influence the general proceeding.

4.1.2. Selection of the supply voltage used

Please select the mains voltage for the operation of Compax3. This influences the choice of motors available.

4.1.3. Motor selection

The selection of motors can be broken down into:

- ◆ Motors that were purchased in Europe and
- ◆ Motors that were purchased in the USA.
- ◆ You will find non-standard motors under "Additional motors" and
- ◆ under "User-defined motors" you can select motors set up with the C3 MotorManager.

For motors with holding brake SMHA or MHA brake delay times can be entered. For this see **Brake delay times** (see on page 292).

Please note the following equivalence that applies regarding terms concerning linear motors:

- ◆ **Rotary motors / linear motors**
- ◆ **Revolutions \equiv Pitch**
- ◆ **Rotation speed (velocity) \equiv Speed**
- ◆ **Torque \equiv Power**
- ◆ **Moment of inertia \equiv Load**

Notes on direct drives (see on page 348) (Linear and Torque - Motors)

4.1.4. Optimize motor reference point and switching frequency of the motor current

Optimization of the motor reference point

The motor reference point is defined by the reference current and the reference (rotational) speed.

Standard settings are:

- ◆ Reference current = nominal current
- ◆ Reference (rotational) speed = nominal (rotational) speed

These settings are suitable for most cases.

The motors can, however, be operated with different reference points for special applications.

- ◆ By reducing the reference (rotational) speed, the reference current can be increased. This results in more torque with a reduced speed.
- ◆ For applications where the reference current is only required cyclically with long enough breaks in between, you may use a reference current higher than I_0 . The limit value is however reference current = max. $1.33 \cdot I_0$. The reference (rotational) speed must also be reduced.

The possible settings or limits result from the respective motor characteristics.

Caution!

Wrong reference values (too high) can cause the motor to switch off during operation (because of too high temperature) or even cause damage to the motor.



Optimization of the switching frequency

The switching frequency of the power output stage is preset to optimize the operation of most motors.

It may, however, be useful to increase the switching frequency especially with direct drives in order to reduce the noise of the motors. Please note that the power output stage must be operated with reduced nominal currents in the case of increased switching frequencies.

The switching frequency may only be increased.

Caution!

By increasing the motor current switching frequency, the nominal current and the peak current are reduced.

This must already be observed in the planning stage of the plant!



The preset motor current switching frequency depends on the performance variant of the Compax3 device.

The respective Compax3 devices can be set as follows:

Resulting nominal and peak currents depending on the switching frequency

Compax3S0xxV2 at 1*230VAC/240VAC

Switching frequency*		S025V2	S063V2
16kHz	I_{nom}	2.5A _{rms}	6,3A _{rms}
	$I_{peak} (<5s)$	5.5A _{rms}	12,6A _{rms}
32kHz	I_{nom}	2.5A _{rms}	5.5A _{rms}
	$I_{peak} (<5s)$	5.5A _{rms}	12,6A _{rms}

Compax3S1xxV2 at 3*230VAC/240VAC

Switching frequency*		S100V2	S150V2
8kHz	I_{nom}	-	15A _{rms}
	$I_{peak} (<5s)$	-	30A _{rms}
16kHz	I_{nom}	10A _{rms}	12.5A _{rms}
	$I_{peak} (<5s)$	20A _{rms}	25A _{rms}
32kHz	I_{nom}	8A _{rms}	10A _{rms}
	$I_{peak} (<5s)$	16A _{rms}	20A _{rms}

Compax3S0xxV4 at 3*400VAC

Switching frequency*		S015V4	S038V4	S075V4	S150V4	S300V4
8kHz	I_{nom}	-	-	-	15A _{rms}	30A _{rms}
	$I_{peak} (<5s)$	-	-	-	30A _{rms}	60A _{rms}
16kHz	I_{nom}	1.5A _{rms}	3.8A _{rms}	7.5A _{rms}	10.0A _{rms}	26A _{rms}
	$I_{peak} (<5s)$	4.5A _{rms}	9.0A _{rms}	15.0A _{rms}	20.0A _{rms}	52A _{rms}
32kHz	I_{nom}	1.5A _{rms}	2.5A _{rms}	3.7A _{rms}	5.0A _{rms}	14A _{rms}
	$I_{peak} (<5s)$	3.0A _{rms}	5.0A _{rms}	10.0A _{rms}	10.0A _{rms}	28A _{rms}

Compax3S0xxV4 at 3*480VAC

Switching frequency*		S015V4	S038V4	S075V4	S150V4	S300V4
8kHz	I_{nom}	-	-	-	13.9A _{rms}	30A _{rms}
	$I_{peak} (<5s)$	-	-	-	30A _{rms}	60A _{rms}
16kHz	I_{nom}	1.5A _{rms}	3.8A _{rms}	6.5A _{rms}	8.0A _{rms}	21.5A _{rms}
	$I_{peak} (<5s)$	4.5A _{rms}	7.5A _{rms}	15.0A _{rms}	16.0A _{rms}	43A _{rms}
32kHz	I_{nom}	1.0A _{rms}	2.0A _{rms}	2.7A _{rms}	3.5A _{rms}	10A _{rms}
	$I_{peak} (<5s)$	2.0A _{rms}	4.0A _{rms}	8.0A _{rms}	7.0A _{rms}	20A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

Resulting nominal and peak currents depending on the switching frequency

Compax3HxxxV4 at 3*400VAC

Switching frequency*		H050V4	H090V4	H125V4	H155V4
8kHz	I_{nom}	50A _{rms}	90A _{rms}	125A _{rms}	155A _{rms}
	$I_{peak} (<5s)$	75A _{rms}	135A _{rms}	187.5A _{rms}	232.5A _{rms}
16kHz	I_{nom}	33A _{rms}	75A _{rms}	82A _{rms}	100A _{rms}
	$I_{peak} (<5s)$	49.5A _{rms}	112.5A _{rms}	123A _{rms}	150A _{rms}
32kHz	I_{nom}	19A _{rms}	45A _{rms}	49A _{rms}	59A _{rms}
	$I_{peak} (<5s)$	28.5A _{rms}	67.5A _{rms}	73.5A _{rms}	88.5A _{rms}

Compax3HxxxV4 at 3*480VAC

Switching frequency*		H050V4	H090V4	H125V4	H155V4
8kHz	I_{nom}	43A _{rms}	85A _{rms}	110A _{rms}	132A _{rms}
	$I_{peak} (<5s)$	64.5A _{rms}	127.5A _{rms}	165A _{rms}	198A _{rms}
16kHz	I_{nom}	27A _{rms}	70A _{rms}	70A _{rms}	84A _{rms}
	$I_{peak} (<5s)$	40.5A _{rms}	105A _{rms}	105A _{rms}	126A _{rms}
32kHz	I_{nom}	16A _{rms}	40A _{rms}	40A _{rms}	48A _{rms}
	$I_{peak} (<5s)$	24A _{rms}	60A _{rms}	60A _{rms}	72A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

Resulting nominal and peak currents depending on the switching frequency

Compax3MxxxD6 at 3*400VAC

Switching frequency*		M050D6	M100D6	M150D6	M300D6
8kHz	I_{nom}	5A _{rms}	10A _{rms}	15A _{rms}	30A _{rms}
	$I_{peak} (<5s)$	10A _{rms}	20A _{rms}	30A _{rms}	60A _{rms}
16kHz	I_{nom}	3.8A _{rms}	7.5A _{rms}	10A _{rms}	20A _{rms}
	$I_{peak} (<5s)$	7.5A _{rms}	15A _{rms}	20A _{rms}	40A _{rms}
32kHz	I_{nom}	2.5A _{rms}	3.8A _{rms}	5A _{rms}	11A _{rms}
	$I_{peak} (<5s)$	5A _{rms}	7.5A _{rms}	10A _{rms}	22A _{rms}

Compax3MxxxD6 at 3*480VAC

Switching frequency*		M050D6	M100D6	M150D6	M300D6
8kHz	I_{nom}	4A _{rms}	8A _{rms}	12.5A _{rms}	25A _{rms}
	$I_{peak} (<5s)$	8A _{rms}	16A _{rms}	25A _{rms}	50A _{rms}
16kHz	I_{nom}	3A _{rms}	5.5A _{rms}	8A _{rms}	15A _{rms}
	$I_{peak} (<5s)$	6A _{rms}	11A _{rms}	16A _{rms}	30A _{rms}
32kHz	I_{nom}	2A _{rms}	2.5A _{rms}	4A _{rms}	8.5A _{rms}
	$I_{peak} (<5s)$	4A _{rms}	5A _{rms}	8A _{rms}	17A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

4.1.5. Ballast resistor

If the regenerative brake output exceeds the **amount of energy that can be stored by the servo controller** (see on page 402), then an error will be generated. To ensure safe operation, it is then necessary to either

- ◆ reduce the accelerations resp. the decelerations,
- ◆ or to use an **external ballast resistor** (see on page 365).

Please select the connected ballast resistor or enter the characteristic values of your ballast resistor directly.

Please note that with resistance values greater than specified, the power output from the servo drive can no longer be dissipated in the braking resistor.

4.1.6. General drive


External moment of inertia / load

The external moment of inertia is required for adjusting the servo controller. The more accurately the moment of inertia of the system is known, the better is the stability and the shorter is the settle-down time of the control loop.


It is important to specify the minimum and maximum moment of inertia for best possible behavior under varying load.

If you do not know the moment of inertia, click on "Unknown: using default values". You have then the possibility to determine the moment of inertia by means of automatic **load identification** (see on page 248).

Minimum moment of inertia / minimum load



Maximum moment of inertia / maximum load



Enter minimum = maximum moment of inertia when the load does not vary.

4.1.7. Defining the reference system

The reference system for positioning is defined by:

- ◆ a unit,
- ◆ the travel distance per motor revolution,
- ◆ a machine zero point with true zero,
- ◆ positive and negative end limits.

4.1.7.1 Measure reference

You can select from among the following for the unit:

Unit

- ◆ mm,
- ◆ increments *
- ◆ angle degrees or
- ◆ Inch.

The unit of measure is always [mm] for linear motors.


*

The unit "increments" is valid only for position values!

Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

Travel distance per motor revolution / pitch

The measure reference to the motor is created with the value: "travel distance per motor revolution / pitch" in the selected unit.




Input as numerator and denominator

You can enter the "travel distance per motor revolution" as a fraction (numerator divided by denominator). This is useful in the case of continuous operation mode or in reset mode if the value cannot be specified as a rational number. This makes it possible to avoid long-term drifts.

Example 1:

Rotary table control



Unit: Grade

Gear transmission ratio 70:4 => 4 load revolutions = 70 motor revolutions

Travel distance per motor revolution = $4/70 * 360^\circ = 20.571\ 428\ 5 \dots^\circ$ (number cannot be represented exactly)


Instead of this number, you have the option of entering it exactly as a numerator and denominator:

Travel distance per motor revolution = 144/7

This will not result in any drift in continuous operation mode or in reset mode, even with relatively long motion in one direction.

Example 2:

Conveyor belt



Unit: mm

Gear transmission ratio 7:4 => 4 load revolutions = 7 motor revolutions

Number of pinions: 12

Tooth separation: 10mm

Travel path per motor revolution = $4/7 * 12 * 10\text{mm} = 68.571\ 428\ 5 \dots \text{mm}$ (this number cannot be expressed exactly)

Instead of this number, you have the option of entering it exactly as a numerator and denominator:

Travel distance per motor revolution = 480/7 mm

For "travel distance per motor revolution" that can be represented exactly, enter 1 as the denominator.

Travel distance per motor revolution /-pitch

Numerator

Unit: Unit	Range: depends on the unit selected	Standard value: depends on the unit selected
Resolution: 0.000 000 1 (7 decimal places)		
Unit	Division	Standard value
Increments*	10 ... 1 000 000	1024
mm	0.010 000 0 ... 2000.000 000 0	1.000 000 0
Grade	0.010 000 0 ... 720.000 000 0	360.000 000 0
Inch	0.010 000 .. 2000.000 000	1.000 000

Denominator

Unit: -	Range: 1 ... 1 000 000	Standard value: 1
Integer value		

*

The unit "increments" is valid only for position values!

Speed, acceleration and jerk are specified in this case in revolutions/s, revolutions/s² and revolutions/s³ (resp. pitch/s, pitch/s², pitch/s³ for linear motors).

Invert Motor Rotation/Direction Polarity

Unit: -	Range: no / yes	Standard value: no
Reverse direction inverts the sense of rotation, i.e. the direction of movement of the motor is reversed in the case of equal setpoint.		


Reset mode

Reset mode is available for applications in which the positioning range repeats; some examples are: Rotary table applications, belt conveyor. ...

After the reset travel distance (exactly specifiable as **numerator and denominator** (see on page 112)) the position values in Compax3 are reset to 0.

Example:

Conveyor belt (from the "Conveyor belt" example) with reset path



A reset path of 300 mm can be entered directly with numerator = 300 mm and denominator = 1.

Reset mode is not possible for linear motors.

Reset distance

Numerator

Unit: Unit	Range: depends on the unit selected	Standard value: depends on the unit selected
Unit	Division	Standard value
Increments	10 ... 1 000 000	0
mm	1 ... 2000	0
Grade	1 ... 720	0

Denominator

Unit: -	Range: 1 ... 1 000 000	Standard value: 0
Integer value		

Turn off reset mode

Reset mode is turned off for numerator = 0 and denominator = 0.

4.1.7.2 Machine Zero

In this chapter you can read about:

Positioning after homing run	116
Absolute encoder	117
Operation with MultiTurn emulation	117
Machine zero modes overview	118
Homing modes with home switch (on X12/14)	120
Machine zero modes without home switch.....	126
Adjusting the machine zero proximity switch.....	131
Machine zero speed and acceleration	131

The Compax3 machine zero modes are adapted to the CANopen profile for Motion Control CiADS402.

Position reference point

Essentially, you can select between operation with or without machine reference. The reference point for positioning is determined by using the machine reference and the machine reference offset.

Machine reference run

In a homing run the drive **normally** (see on page 116) moves to the position value 0 immediately after finding the home switch. The position value 0 is defined via the homing offset.

A machine reference run is required each time after turning on the system for operation with machine reference.



Please note:


During homing run the software end limits are not monitored.

Positioning after homing run


The positioning made after the home switch has been found can be switched off. For this enter in the “machine zero” window in the configuration wizard “no” under “approach MN point after MN run”.

Example Homing (MN) mode 20 (Home on homing (MN) switch) with T40 by homing offset 0

With positioning after homing run The motor stands then on 0:



Without positioning after homing run The position reached is not exactly on 0, as the drive brakes when detecting the home and stops:



If the homing mode is active, there will always be a homing run with the first start after each configuration download (with the aid of the C3 ServoManager) **Homing run** (see on page 147).

Absolute encoder

Using a SinCos® or EnDat Multiturn absolute value sensor as feedback system, the absolute position can be read in over the entire travel range when switching on the Compax3. This means that a machine zero run is not necessary after the switching on (feedback may not be shifted by the absolute range while switched off).

In this case the reference only needs to be established once

- ◆ at initial commissioning time
- ◆ after an exchange of motor / feedback system
- ◆ after a mechanical modification and
- ◆ after an exchange of device (Compax3); does not apply for the "Store absolute position in feedback" function.
- ◆ after a configuration download

by carrying out a machine zero run.

The homing mode 35 "**MN at the current position** (see on page 126)" is appropriate for this, because it is therewith possible to operate without proximity switch, but any other homing mode is possible too - if the hardware prerequisites are fulfilled.

When you have once re-established the reference, reset the machine zero run mode to "without machine zero run".

Operation with MultiTurn emulation

You can simulate the function of a Multiturn over the entire travel distance by the aid of a Multiturn emulation. A resolver or a SinCos® / EnDat Singleturn feedback is sufficient as a feedback signal from the motor.

It differs from the physical Multiturn in the way that the motor may not be moved by more than half a turn if Compax3 (24VDC) is switched off - unless the absolute position is lost.

Besides that, the Multiturn emulation offers the same function as the physical Multiturn feedback.

You can switch on the Multiturn emulation directly in the wizard.

You can assign the maximum permissible motor angle via the Multiturn validity window

If Compax3 states after switching on that this value is not exceeded, then das "Referenziert" gesetzt (Zustandswort Bit 12 oder Ausgang M.A8) is applied.

Compax3 restores nevertheless the absolute position, the motor angle is correct, the absolute position may however not be correct, if the motor was moved by more than the validity window while currentless.

Attention: In this case, the drive is considered "not referenced" and the software end limit monitoring is inactive!

Machine reference run For a unique machine zero run the same conditions apply as for the use of an absolute encoder (Multiturn).

Machine zero modes overview


Selection of the machine zero modes (MN-M)

Machine home switch on X12/14: MN-M 3 ... 14, 19 ... 30	Without motor reference point MN-M 19 ...30	without direction reversal switches: MN-M 19, 20 (see on page 120), MN-M 21, 22 (see on page 121)
		with reversal switches: MN-M 23, 24, 25, 26 (see on page 122), MN-M 27, 28, 29, 30 (see on page 122)
	With motor reference point MN-M 3 ... 14 (possibly an initiator adjustment (see on page 131) is required)	without direction reversal switches: MN-M 3, 4 (see on page 123), MN-M 5, 6 (see on page 124)
		with reversal switches: MN-M 7, 8, 9, 10 (see on page 125), MN-M 11,12,13, 14 (see on page 125)
Without machine zero initiator on X12/14: MN-M 1, 2, 17, 18, 33 .. 35, 128, 129, 130 ... 133	Without motor reference point MN-M 17, 18, 35, 128, 129	MN-M 35: on the actual position (see on page 126)
		MN-M 128, 129: by moving to block (see on page 126)
		With limit switch as machine zero: MN-M 17, 18 (see on page 127)
		Only motor reference: MN-M 33, 34 (see on page 128), MN-M 130, 131 (see on page 128)
		With limit switch as machine zero: MN-M 1, 2 (see on page 130), MN-M 132, 133 (see on page 130)

Definition of terms / explanations:

Motor zero point	Zero pulse of the feedback Motor feedback systems such as resolvers or SinCos® / EnDat give one pulse per revolution. Some motor feedback systems of direct drives do also have a zero pulse, which is generated once or in defined intervals. By interpreting the motor zero point (generally in connection with the machine zero initiator) the machine zero can be defined more exactly.
Machine zero initiator:	For creating the mechanical reference Has a defined position within or on the edge of the travel range.
Direction reversal switches:	Initiators on the edge of the travel range, which are used only with a machine zero run in order to detect the end of the travel range. In some cases, the function "direction reversal via Stromschwelle" is also possible, then you will need no initiator, Compax3 detects the end of the travel range via the threshold. Please observe the respective notes. During operation, the direction reversal switches are often used as limit switches.

Example axis with the initiator signals



- 1: Direction reversal / end switch on the negative end of the travel range (the **assignment of the reversal / end switch inputs** (see on page 135) to travel range side can be changed).
- 2: Machine zero initiator (can, in this example, be released to 2 sides)
- 3: Direction reversal / end switch on the positive end of the travel range (the **assignment of the reversal / end switch inputs** (see on page 135) to travel range side can be changed).
- 4: Positive direction of movement
- 5: Signals of the motor zero point (zero pulse of the motor feedback)
- 6: Signal of the machine zero initiator (**without inversion of the initiator logic** (see on page 135)).
- 7: Signal of the direction reversal resp. end switch on the positive end of the travel range (without inversion of the initiator logic).
- 8: Signal of the direction reversal / resp. end switch on the negative end of the travel range (without inversion of the initiator logic).
- 9: Signal of the machine zero initiator (**with inversion of the initiator logic** (see on page 135)).
- 10: Signal of the direction reversal resp. end switch on the positive end of the travel range (with inversion of the initiator logic).
- 11: Signal of the direction reversal / end switch on the negative end of the travel range (with inversion of the initiator logic).
- 12: Logic state of the home switch (independent of the inversion)
- 13: Logic state of the direction reversal resp. end switch on the positive end of the travel range (independent of the inversion)
- 14: Logic state of the direction reversal resp. end switch on the negative end of the travel range (independent of the inversion)

The following principle images of the individual machine zero modes always refer to the logic state (12, 13, 14) of the switches.

Homing modes with home switch (on X12/14)

In this chapter you can read about:

Without motor reference point..... 120
 With motor reference point..... 123

Without motor reference point

In this chapter you can read about:

Without direction reversal switches..... 120
 With direction reversal switches..... 121

Without direction reversal switches

MN-M 19,20: MN-Initiator = 1 on the positive side


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (left of the MN initiator) and one range with activated MN initiator (right of the MN initiator).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the positive travel direction.

Without motor zero point, without direction reversal switches

MN-M 19: The negative edge of the MN proximity switch is taken directly as MN (the motor zero point remains without consideration).

MN-M 20: The positive edge of the MN proximity switch is used directly as MN (the motor zero point remains without consideration).



1: logic state

MN-M 21,22: MN Initiator = 1 on the negative side


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (positive part of the travel range) and one range with activated MN initiator (negative part of the travel range).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the negative travel direction.

Without motor zero point, without direction reversal switches

MN-M 21: The negative edge of the MN proximity switch is taken directly as MN (the motor zero point remains without consideration).

MN-M 22: The positive edge of the MN proximity switch is used directly as MN (the motor zero point remains without consideration).



1: logic state

With direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.

The **assignment of the direction reversal switches** (see on page 135) can be changed.

Function Reversal via Stromschwelle

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function "direction reversal via Stromschwelle".

The drive drives against the mechanical end stop.

When the adjustable Stromschwelle is reached, the drive is decelerated and changes the direction of movement.


	<p>Caution!</p> <p>Wrong settings can cause hazard for man and machine.</p>
--	--

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.
In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).

MN-M 23...26: Direction reversal switches on the positive side

Without motor zero point, with direction reversal switches




1: Logic state of the home switch

2: Logic state of the direction reversal switch

MN-M 27...30: Direction reversal switches on the negative side

Without motor zero point, with direction reversal switches



1: Logic state of the home switch

2: Logic state of the direction reversal switch

With motor reference point

In this chapter you can read about:

Without direction reversal switches 123
 With direction reversal switches..... 124

Without direction reversal switches

MN-M 3,4: MN-Initiator = 1 on the positive side


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (left of the MN initiator) and one range with activated MN initiator (right of the MN initiator).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the positive travel direction.

With motor zero point, without direction reversal switches

MN-M 3: The 1st motor zero point at MN initiator = "0" is used as MN.

MN-M 4: The 1st motor reference point with MN initiator = "1" is used as the MN.



- 1: Motor zero point
- 2: Logic state of the home switch

MN-M 5,6: MN-Initiator = 1 on the negative side


The MN initiator can be positioned at any location within the travel range. The travel range is then divided into 2 contiguous ranges: one range with deactivated MN initiator (positive part of the travel range) and one range with activated MN initiator (negative part of the travel range).

When the MN initiator is inactive (signal = 0) the search for the machine reference is in the negative travel direction.

With motor zero point, without direction reversal switches

MN-M 5: The 1st. motor zero point with MN proximity switch = "0" is used as MN.

MN-M 6: The 1st motor reference point with MN initiator = "1" is used as the MN.



1: Motor zero point

2: Logic state of the home switch

With direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.

The **assignment of the direction reversal switches** (see on page 135) can be changed.

Function Reversal via Stromschwelle

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function "direction reversal via Stromschwelle".

The drive drives against the mechanical end stop.

When the adjustable Stromschwelle is reached, the drive is decelerated and changes the direction of movement.

	<p>Caution!</p> <p>Wrong settings can cause hazard for man and machine.</p>
---	--


It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.
In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).

MN-M 7...10: Direction reversal switches on the positive side

With motor zero point, with direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.




- 1: Motor zero point
- 2: Logic state of the home switch
- 3: Logic state of the direction reversal switch

MN-M 11...14: With direction reversal switches on the negative side

With motor zero point, with direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.



- 1: Motor zero point
- 2: Logic state of the home switch
- 3: Logic state of the direction reversal switch

Machine zero modes without home switch

In this chapter you can read about:

Without motor reference point..... 126
 With motor reference point..... 128

Without motor reference point

MN-M 35: MN (machine zero) at the current position

The current position when the MN run is activated is used as an MN.



Please note: Due to encoder noise it is possible that a value $\neq 0$ is set when teaching to 0. If end limits = 0, an end limit error may occur during homing run.

MN-M 128/129: Stromschwelle while moving to block

Without a MN (machine zero) initiator, an end of travel region (block) is used as MN (machine zero).

For this the Stromschwelle is evaluated if the drive pushes against the end of the travel region. When the adjusted current is exceeded, the Homing is set. During the homing run (MN), the error reaction "following error" is deactivated.

Please observe:

The machine zero offset must be set so that the zero point (reference point) for positioning lies within the travel range.

MN-M 128: Travel in the positive direction to the end of the travel region




MN-M 129: Travel in the negative direction to the end of the travel region



	<p>Caution! Wrong settings can cause hazard for man and machine.</p>
---	--

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.
 In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).

MN-M 17,18: Limit switch as machine zero

1: Logic state of the direction reversal switch

Function Reversal via Stromschwelle

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function “direction reversal via Stromschwelle”.

The drive drives against the mechanical end stop.

When the adjustable Stromschwelle is reached, the drive is decelerated and changes the direction of movement.

**Caution!**

Wrong settings can cause hazard for man and machine.

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.
In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).

With motor reference point

In this chapter you can read about:

Machine zero only from motor reference..... 128
 With direction reversal switches..... 129

Machine zero only from motor reference


MN-M 33,34: MN at motor zero point

The motor reference point is now evaluated (no MN initiator):

Without home switch

MN-M 33: For a MN run, starting from the current position, the next motor zero point in the negative travel direction is taken as the MN.

MN-M 34: For a MN run, starting from the current position, the next motor zero point in the positive travel direction is taken as the MN.



1: Motor zero point

MN-M 130, 131: Acquire absolute position via distance coding

Only for motor feedback with distance coding (the absolute position can be determined via the distance value).

Compax3 determines the absolute position from the distance of two signals and then stops the movement (does not automatically move to position 0).



1: Signals of the distance coding

With direction reversal switches

Machine zero modes with a home switch which is activated in the middle of the travel range and can be deactivated to both sides.

The **assignment of the direction reversal switches** (see on page 135) can be changed.

Function Reversal via Stromschwelle

If no direction reversal switches are available, the reversal of direction can also be performed during the machine zero run via the function "direction reversal via Stromschwelle".

The drive drives against the mechanical end stop.

When the adjustable Stromschwelle is reached, the drive is decelerated and changes the direction of movement.

**Caution!**


Wrong settings can cause hazard for man and machine.

It is therefore essential to respect the following:

- ◆ Choose a low machine zero speed.
- ◆ Set the machine zero acceleration to a high value, so that the drive changes direction quickly, the value must, however, not be so high that the limit threshold is already reached by accelerating or decelerating (without mechanical limitation).
- ◆ The mechanical limitation as well as the load drain must be set so that they can absorb the resulting kinetic energy.
- ◆ With a bad feedback signal or high controller gain (fast controller or high inertia or mass) the machine zero might not be detected.
In this case it is necessary to use the control signal filter (O2100.20) or the velocity filter (O2100.10).


MN-M 1,2: Limit switch as machine zero

End switch on the negative side



- 1: Motor zero point
- 2: Logic state of the direction reversal switch

End switch on the positive side:




- 1: Motor zero point
- 2: Logic state of the direction reversal switch

MN-M 132, 133: Determine absolute position via distance coding with direction reversal switches

Only for motor feedback with distance coding (the absolute position can be determined via the distance value).

Compax3 determines the absolute position from the distance of two signals and then stops the movement (does not automatically move to position 0).




- 1: Signals of the distance coding
- 2: Logic state of the direction reversal switches

Adjusting the machine zero proximity switch

This is helpful in some cases with homing modes that work with the home switch and motor reference point.

If the motor reference point happens to coincide with the position of the MN initiator, there is a possibility that small movements in the motor position will cause the machine reference point to shift by one motor revolution (to the next motor reference point).

Via status value "Distance MN sensor - motor zero", (O1130.13) you can check if the distance between machine home sensor and motor zero point is too short.




- 1: Motor zero point
- 2: Logic state of the home switch

A solution to this problem is to move the MN initiator by means of software. This is done using the value initiator adjustment.

Initiator adjustment

Unit: Motor angle in degrees	Range: -180 ... 180	Standard value: 0
Move the machine reference initiator using software As an aid you can use the status value "distance MN sensor - motor zero" in the "Positions" chapter under "status values"		

Machine reference offset



- 1: Machine reference offset

The machine reference offset is used to determine the actual reference point for positioning.

That is: Zero point = Machine zero + Machine zero offset

Note: If the machine zero proximity switch is at the positive end of the travel range, the machine zero offset must be = 0 or negative.

A change in the machine reference offset does not take effect until the next machine reference run.

Machine zero speed and acceleration

With these values you can define the motion profile of the machine zero run.

4.1.7.3 Travel Limit Settings

Software end limits

The error reaction when reaching the software end limits can be set:


Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

If "no reaction" was set, no software limits must be entered.

Software end limits:

The travel range is defined via the negative and positive end limits.




1: negative end limit

2: positive end limit

Software end limit in absolute operating mode

The positioning is restricted to the range between the travel limits.

A positioning order aiming at a target outside the travel range is not executed.



1: negative end limit

2: positive end limit

The reference is the position reference point that was defined with the machine reference and the machine reference offset.

Software end limits in reset mode

The reset mode does not support software end limits

Software end limit in continuous mode

Each individual positioning is confined within the travel limits.

A positioning order aiming at a target outside the software end limits is not executed.

The reference is the respective current position.

Error when disregarding the software end limits

A software end limit error is triggered, if the position value exceeds an end limit. For this, the position setpoint value is evaluated in energized state; in currentless state, the actual position value is evaluated.

Hysteresis in disabled state:

If the axis stands currentless at an end limit, another error may be reported due to position jitter after acknowledging the end limit error. To avoid this, a hysteresis surrounding the end limits was integrated (size corresponds to the size of the positioning window).

Only if the distance between axis and the end limits was larger than the positioning window, another end limit error will be detected

Error codes (see on page 342) of the end limit errors:

0x7323 Error when disregarding the positive software end limit.

0x7324 Error when disregarding the negative software end limit.

Activating / deactivating the end limit error:

In the C3 ServoManager under configuration: End limits, the error can be (de)activated.

For IEC-programmable devices with the "C3_ErrorMask" module.

Behavior after the system is turned on

The end limits are not active after switching on. The end limits do not refer to the position reference point until after a machine reference run.

During homing run the end limits are not monitored.

With a Multiturn encoder or with active Multiturn emulation, the limit is valid immediately after switching on.

Behavior outside the travel range


1. If the software end limit errors are deactivated, all movements are possible.

2. If the software end limit errors are activated:

After disregarding the software end limits, an error is triggered. First of all, this error must be acknowledged.

Then a direction block is activated: only motion commands in the direction of the travel range are executed. These will not trigger another error.

Motion commands inciting a movement in the opposite direction of the travel range are blocked and will trigger another error.



1: negative end limit

2: positive end limit

Notes on special feedback systems (Feedback F12)

During automatic commutation, the end limit monitoring is deactivated!

Behavior with software end limits of a referenced axis

	Position within target outside	Position outside target outside and aiming in the opposite direction of the travel range	Position outside target within and aiming in the direction of the travel range
JOG +/-	<ul style="list-style-type: none"> ◆ Positioning up to the end limits ◆ No Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ No Error 	<ul style="list-style-type: none"> ◆ Positioning
MoveAbs, MoveRel, RegSearch, RegMove	<ul style="list-style-type: none"> ◆ No positioning ◆ Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ Error 	<ul style="list-style-type: none"> ◆ Positioning
Gearing	<ul style="list-style-type: none"> ◆ Positioning up to the end limits ◆ Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ Error
Velocity	<ul style="list-style-type: none"> ◆ Positioning up to the end limits ◆ Error 	<ul style="list-style-type: none"> ◆ No positioning ◆ Error 	<ul style="list-style-type: none"> ◆ Positioning

Hardware end limits

The error reaction when reaching the hardware end limits can be set:

Possible settings for the error reaction are:


- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

Hardware end limits are realized with the aid of end switches.

These are connected to X12/12 (input 5) and X12/13 (input 6) and can be (de)activated separately in the C3 ServoManager under Configuration: End limits.

After a limit switch has been detected, the drive decelerates with the ramp values set for errors (error code 0x54A0 at X12/12 active, 0x54A1 at X12/13 active) and the motor is switched to currentless.

Please make sure that after the detection of the end switch there is enough travel path left up to the limit stop.



- 1: Limit switch E5 (X12/12)
- 2: Limit switch E6 (X12/13)
- 3: Limit switch position E5 (X12/12)
- 4: Limit switch position E6 (X12/13)

The **assignment of the end switches** (see on page 135) can be changed!

Please note: The limit switches must be positioned so that they cannot be released towards the side to be limited.

**Limit switch /
direction reversal
switch**

Limit switches functioning as direction reversal switches during homing run, will not trigger a limit switch error.

**Behavior in the case
of an active limit
switch**

The error can be acknowledged with activated limit switch.

The drive can then be moved out of the end switch range with a normal positioning.

The direction of the movement is verified in the event of fixed I/O assignment.

Only the direction towards the travel range is allowed.

Debouncing: Limit switch, machine zero and input 0

A majority gate is used for debouncing.

The signal is sampled every 0.5ms

The debounce time determines the number of scans the majority gate will perform. If the level of more than half of the signals was changed, the internal status will change.

The debounce time can be set in the configuration wizard within the range of 0 ... 20ms.

The value 0 deactivates the debouncing.

If the debouncing time is stated, the input I0 can be debounced as well (checkbox below).

4.1.7.4 Change assignment direction reversal / limit switches

If this function is not activated, the direction reversal / end switches are assigned as follows:

Direction reversal / limit switch on I5 (X12/12): negative side of the travel range

Direction reversal / limit switch on I6 (X12/13): positive side of the travel range

**Change assignment
of direction reversal
/ limit switch is
activated**

If this function is activated, the direction reversal / limit switches are assigned as follows:

Direction reversal / limit switch on **I5** (X12/12): **positive side** of the travel range

Direction reversal / limit switch on **I6** (X12/13): **negative side** of the travel range

4.1.7.5 Change initiator logic

The initiator logic of the limit switches (this does also apply for the direction reversal switches) and the machine zero initiator can be changed separately.

- ◆ Limit switch E5 low active
- ◆ Limit switch E6 low active
- ◆ Home switch E7 low active

In the basic settings the inversion is deactivated, so that the signals are "high active".

With this setting the inputs I5 to I7 can even be switched within their logic, if they are not used as direction reversal/limit switches or machine zero.

4.1.8. Defining jerk / ramps

In this chapter you can read about:

Speed for positioning and velocity control	136
Acceleration for positioning and velocity control	136
Acceleration / deceleration for positioning	136
Jerk limit for positioning.....	136
Ramp upon error and de-energize	138
Jerk for STOP, MANUAL and error	138

4.1.8.1 Speed for positioning and velocity control

Standard speed for all positionings and motion functions.

The value can be changed during operation via the bus or via the motion sets.

This setting is not relevant for the "rotation speed" operating mode.

4.1.8.2 Acceleration for positioning and velocity control

Standard acceleration for all positionings and motion functions.

The value can be changed during operation via the bus or via the motion sets.

4.1.8.3 Acceleration / deceleration for positioning

Standard deceleration for all positionings and motion functions.

The value can be changed during operation via the bus or via the motion sets.

If "0" is entered, the acceleration value is accepted as deceleration.

4.1.8.4 Jerk limit for positioning

Standard jerk for all positionings and motion functions.

The value can be changed during operation via the bus or via the motion sets.

In the operating modes:

- ◆ Speed control
- ◆ Velocity and
- ◆ Gearing

the jerk is not limited.

Description of jerk

Jerk

The jerk (marked with "4" in the drawing below) describes the change in acceleration (derivation of the acceleration)

The maximum change in acceleration is limited via the jerk limitation.

A motion process generally starts from a standstill, accelerates constantly at the specified acceleration to then move at the selected speed to the target position. The drive is brought to a stop before the target position with the delay that has been set in such a manner as to come to a complete stop at the target position. To reach the set acceleration and deceleration, the drive must change the acceleration (from 0 to the set value or from the set value to 0).


This change in speed is limited by the maximum jerk.

**Without jerk
according to
VDI2143**

According to VDI2143 the jerk is defined (other than here) as the jump in acceleration (infinite value of the jerk function).

This means that positionings with Compax3 are without jerk according to VDI2143, as the value of the jerk function is limited.

Motion sequence



- 1: Position
- 2: Speed
- 3: Acceleration
- 4: Jerk


High changes in acceleration (high jerks) often have negative effects on the mechanical systems involved. There is a danger that mechanical resonance points will be excited or that impacts will be caused by existing mechanical slack points. You can reduce these problems to a minimum by specifying the maximum jerk.

Jerk

Unit: Unit/s ³	Range: 0 ... 10 000 000	Standard value: 1 000 000
---------------------------	-------------------------	------------------------------

STOP delay

After a STOP signal, the drive applies the brakes with the delay that is set (2).




Please observe:

The configured STOP ramp is limited. The STOP ramp will not be smaller than the deceleration set in the last motion set.

NO STOP: control.3 = "0" (Quick Stop: Transition 11 of the **State machine** (see on page 327))

4.1.8.5 Ramp upon error and de-energize

Ramp (delay) upon error and "De-energize"




3: Deceleration on error (status.3 = "1"), Disable Voltage (control.1 = "0" transition 9 of the status machine) and Enable Operation (CW.3 = "0" transition 5 of the status machine).

Please observe:

The configured error ramp is limited. The error ramp will not be smaller than the deceleration set in the last motion set.

Manual acceleration/deceleration and speed control

You can set the motion profile for moving with JOG+ or JOG- here.



1: Manual acceleration / Deceleration

2: Manual speed control

+: Manual+ (control.4 = "1")

-: Manual- (control.5 = "1")

Only in "Manual operating mode" (DeviceNet-No.C3-Objekt-Class Instanz 1100 Attribut 5 = -1)

4.1.8.6 Jerk for STOP, MANUAL and error

The jerk set here applies for:

- ◆ the STOP ramp
- ◆ Manual motion
- ◆ The ramp for the machine reference run

Description of jerk (see on page 136)

Jerk

Unit: Unit/s ³	Range: 0 ... 10 000 000	Standard value: 1 000 000
---------------------------	-------------------------	------------------------------

4.1.9. Limit and monitoring settings

In this chapter you can read about:

Current (Torque) Limit.....	139
Positioning window - Position reached.....	139
Following error limit.....	140
Maximum operating speed.....	141

4.1.9.1 Current (Torque) Limit

The current required by the speed controller is limited to the current limit.

4.1.9.2 Positioning window - Position reached


Position reached indicates that the target position is located within the position window.

In addition to the position window, a position window time is supported. If the actual position goes inside the position window, the position window time is started. If the actual position is still inside the position window after the position window time, "Position reached" is set.

If the actual position leaves the position window within the position window time, the position window time is started again.

When the actual position leaves the position window with Position reached = "1", Position reached is immediately reset to "0".

Position monitoring is active even if the position leaves the position window because of measures taken externally.



1: Position Window

2: In Position Window Time

3: Setpoint position reached (state / status word 1 Bit 10 = "1") and O1 (X12/3)

Linkage to the setpoint value

The signal "position reached" can be linked to the setpoint value.

In addition, the internal setpoint value generation is evaluated.

It applies: **The positioning window is only evaluated with a constant internal setpoint value.**

Position reached
GeWith

Signal "position reached" monitors synchronicity.

RegSearch /
RegMove

Signal "position reached" is set if

- ◆ RegSearch was terminated without a reg being found
- or
- ◆ Reg was found and RegMove executed.

Velocity Signal "position reached" turns into "velocity reached".

STOP Signal "position reached" shows that the drive is at a standstill.

4.1.9.3 Following error limit

The error reaction upon a following error can be set:

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

The following error is a dynamic error.

The dynamic difference between the setpoint position and the actual position during a positioning is called the following error. Do not confuse this with the static difference which is always 0; the target position is always reached exactly.


The change of position over time can be specified exactly using the parameters jerk, acceleration and speed. The integrated Setpoint value generator calculates the course of the target position. Because of the delay in the feedback loop, the actual position does not follow the target position exactly. This difference is referred to as the following error.

Disadvantages caused by a following error When working with a number of servo drives (for example Master controller and slave controller), following errors lead to problems due to the dynamic position differences, and a large following error can lead to positioning overshoot.

Error message If the following error exceeds the specified following error limit, the "following error time" then expires. If the following error is even greater than the following error limit at the end of the following error time, an error is reported.

If the following error falls short of the following error limit, a new following error time is then started.

Minimizing the following error The following error can be minimized with the help of the extended (advanced) control parameters, in particular with the feed forward parameters.



1: Following error limit

2: Following Error Time

ERROR: Malfunction (state - / status word 1 Bit 3) and O0 (X12/2)

ACKN: Control word 1 Bit 7 or I0 (X12/6)

4.1.9.4 Maximum operating speed

The speed limitation is deduced from the maximum operating speed. In order to ensure control margins, the speed is limited to a higher value.

The speed setpoint value is actively limited to 1.1 times the given value.

If the speed actual value exceeds the preset maximum speed by 21% (= "switching off limit speed"), error 0x7310 is triggered.

4.1.10. Encoder simulation

You can make use of a permanently integrated encoder simulation feature to make the actual position value available to additional servo drives or other automation components.

- Caution!**
- ◆ The encoder simulation is not possible at the same time as the encoder input<ohne_SSI_t> resp. the step/direction input.
The same interface is used here.
 - ◆ A direction reversal configured in the C3 ServoManager does not affect the encoder simulation.
The direction of rotation of the encoder simulation can, however, be changed via the feedback direction in the MotorManager.

Simulated Encoder Output Resolution

Unit: Increments per revolution / pitch	Range: 4 - 16384	Standard value: 1024
Any resolution can be set		
Limit frequency: 620kHz (track A or B) i.e. , with:		
Increments per revolution	max. Velocity	
1024	36000 rpm	
4096	9000 rpm	
16384	2250 rpm	

4.1.10.1 Encoder bypass with Feedback module F12 (for direct drives)

If the feedback module F12 is used, the encoder signals can be placed directly (Bypass) to the encoder interface (X11: same assignment as encoder simulation) for further use. Sine/Cosine signals are directly converted into encoder signals, however no additional zero pulse is generated; an available zero pulse will be transmitted.


The advantage is, that the limit frequency is 5MHz instead of 620kHz (track A or B).

The direction of rotation is only defined via the encoder wiring; a direction inversion configured in the C3 ServoManager does not have any consequence.

4.1.11. I/O Assignment

- ◆ For intra-device inputs I0 .. I3 as well as the outputs O0 ... O3 you can choose between fixed or free assignment (see below).
- ◆ Control via DeviceNet does not require an M option (M10 / M12).
- ◆ If an M option is available, 12 inputs/outputs (ports) are freely assignable. These can be configured as inputs or outputs by groups of four and be activated resp. read via Object 121.2 and Object 133.3.
- ◆ The signal inputs I4 ... I7 are fixedly assigned
If the respective functions are not needed, these inputs can also be used for control.
I5 and I6 can, for example, be used as free inputs if the limit switch function is deactivated.

Assignment of the intra-device inputs and outputs



Pin X12	Input/output	High density/Sub D	
1	O	+24 V DC output (max. 400mA)	
2	O0	No Error	Only for "fixed assignment" Functions are available, if "Fixed assignment" was selected for the I/O assignment in the configuration wizard
3	O1	Position / speed / gear synchronization attained (max. 100 mA)	
4	O2	Power stage without current (max.) 100 mA)	
5	O3	Axis energized with a setpoint of 0 (max. 100 mA)	
6	I0="1":	Quit (positive edge) / Axis enable	
	I0="0"	Axis disable with delay	
7	I1	no Stop	
8	I2	JOG +	
9	I3	JOG -	
10	I4	Reg input	
11	I	24V input for the digital outputs Pins 2 to 5	
12	I5	Limit switch 1	
13	I6	Limit switch 2	
14	I7	Machine zero initiator	
15	O	GND24V	

All inputs and outputs have 24V level.

Maximum capacitive loading of the outputs: 30nF (max. 2 Compax3 inputs can be connected)

Input-/Output extension

Optimization window display

The display of the digital inputs in the optimization window of the C3 ServoManager does not correspond to the physical status (24Volt=on, 0Volt=off) but to the logic status: if the function of an input or output is inverted (e.g. limit switch, negatively switching), the corresponding display (LED symbol in the optimization window) is OFF with 24Volts at the input and ON with 0 Volts at the input.

For intra-device inputs I0 .. I3 as well as the outputs O0 ... O3 you can choose between fixed or free assignment.

With fixed assignment of the intra-device inputs I0 ... I3, the respective functions can either be triggered via the inputs or via DeviceNet
It applies:

With "guiding via interface" (control word 1 bit 11 = "0")

- ◆ Enable Voltage: I0 ="1" **UND** Control word 1 Bit 1 ="1"
- ◆ Ackn is triggered via control word 1 bit 7 - ackn via I0 is not possible.
- ◆ Stop is active, if I1 = "0"
- ◆ Manual+ and Manual- Inputs I2, I3 do not have a function.

With " No guiding via interface" (control word 1 bit 11 = "1")

Control word is not effective:

- ◆ Energize motor / ackn: I0 ="1"
- ◆ Stop is active, if I1 = "0"
- ◆ Manual+ and Manual- via Inputs I2, I3.

Status word

- ◆ The status word is always updated
- ◆ O0 corresponds to status word 1 Bit 3
- ◆ O1 corresponds to status word 1 bit 10
- ◆ O3 corresponds to the status "operation enable"

4.1.12. Position mode in reset operation

In this chapter you can read about:

Examples in the help file145

In reset operation (activated by the configured reset distance), additional positioning functions are possible for absolute positionings (can be set under configuration in the "Positioning options / positioning profiles" window only in bus mode "Positioning" or "Profile selection"):

All directions	Standard positioning mode
Positive direction	Positioning only in positive direction
Shortest path	Positioning on the shortest path
Negative direction	Positioning only in negative direction
Actual direction	Positioning by keeping the actual direction of travel

Dynamic positioning

In dynamic positioning, a decision concerning the positioning travel is not taken on the basis of the actual position, but on the basis of the braking position resulting from the motion parameters.

Please observe:

- ◆ **In the event of positioning specifications below zero and higher than or equal to the reset distance, this function is deactivated.**
The positioning target must for instance be in the range between 0..359.999999° for a reset distance of 360°.
- ◆ The positioning functions are neither effective in test movements nor in an automatic positioning after homing travel (if this was not deactivated in the configuration).
- ◆ In the event of "shortest path", the motion is not defined for a positioning by a travel of half the reset distance.

4.1.12.1 Examples in the help file

In the help file you can find examples for the functioning of the individual positioning modes.

4.1.13. Reg-related positioning / defining ignore zone

These settings are only required in connection with the function “**reg-related positioning** (see on page 149)“.

Within the reg window a reg signal will be ignored.

The reg window is defined by

- ◆ Beginning of the ignore zone
- ◆ End of the ignore zone

Beginning and end of the ignore zone are absolute values and therefore are also valid with negative position values.


This reg window is valid for all reg position sets.

Allow higher deceleration for RegMove

If the deceleration set in the RegMove motion set is too high, the target position is not reached. **Compax3 reports error** (see on page 152).

By allowing for a higher deceleration, Compax3 sets the jerk and the deceleration so that the target is reached without direction reversal.

Function



Start	Start signal for reg positioning
RegSearch:	Positioning for reg search
RegMove:	Positioning according to reg
StartIgnore:	Reg window: Beginning of the ignore zone
StopIgnore:	Reg window: End of the ignore zone
Reg:	Reg signal (I4 on X12/10)
Regf	Signal: Reg detected (Statuswort 1 Bit 15)
POS:	Signal: Position reached (Ausgang A1: X12/3 oder Zustandswort 1 Bit 9)

4.1.14. Write into set table

The motion sets are stored in a set table.

The table rows define always one motion set, in the columns the respective motion parameters of a motion set are stored.

	Motion parameters				
Machine reference run					
Set 1					
Set 2					
...					
Set 31					

Exact description (see on page 317).

31 motion sets are possible.

The motion set to be executed is selected via Statuswort 2.

For the motion sets different motion functions with different motion parameters are available:

- ◆ **Empty:** empty motion set
- ◆ **MoveAbs (see on page 148):** absolute positioning
- ◆ **MoveRel (see on page 148):** relative Positioning
- ◆ **Gearing (see on page 153):** electronic gearbox
- ◆ **RegSearch (see on page 149):** Registration mark-related positioning (uses 2 motion sets: RegSearch and RegMove)
- ◆ **Velocity (see on page 154):** Velocity control
- ◆ **Stop:** Stop movement

For each motion set you can define programmable status bits (PSBs), which will then be put out after the termination of the motion set.

Homing run A start signal at address = 0 (motion set 0) triggers a machine zero run.

4.1.14.1 Programmable status bits (PSBs)

The successful execution of a motion set can be queried via the PSBs.

PSBs: Bit 12, 13 and 14 of status word 2.

Definition of the pattern:

The settings for the PSBs are made in the respective motion set

You can set 3 assignments for the respective bits:

- X: no change Output / Bit is not influenced
- 0: Inactive Output / Bit is set to 0
- 1: Active Output / Bit is set to 1 resp. 24VDC

Storage of the **PSBs** (see on page 317).

Jerk Jerk in unit/s³

You can optimize the motion profile data with the "**ProfilViewer**" (see on page 290) software tool!

4.1.15.2 Reg-related positioning (RegSearch, RegMove)

For registration mark-related positioning, 2 motions are defined.

RegSearch Search movements: Relative Positioning in order to search for an external signal - of a reg
This may, for example, be a reg on a product.


RegMove The external signal interrupts the search movement and the second movement by the predefined offset follows without transition. The drive comes to a standstill at the position of the mark signal + the configured offset.

Accuracy of the reg detection : <1µs

Please note:


The reg restriction window is the same for all reg motion sets!

Example 1: Reg comes after the reg restriction window



- Start** Start signal for reg positioning (Steuerwort 1 Bit 4)
- RegSearch:** Positioning for reg search
- RegMove:** Positioning according to reg
- StartIignore:** **Reg ignore window:** (see on page 146) Beginning of the ignore zone
- StopIignore:** Reg ignore window: End of the ignore zone
- Reg:** Reg signal (I4 on X12/10)
- Regf:** Signal: Reg detected (Statuswort 1 Bit 15)
- POS:** Signal: Position reached (Ausgang A1: X12/3 oder Zustandswort 1 Bit 9)
- 1** Programmable status bits of RegSearch (only for positioning with set selection)
- 2** Programmable status bits of RegMove (only for positioning with set selection)


Example 2: Reg within the reg restriction window



- Start** Start signal for reg positioning (Steuerwort 1 Bit 4)
- RegSearch:** Positioning for reg search
- RegMove:** Positioning according to reg
- Startignore:** **Reg ignore window:** (see on page 146) Beginning of the ignore zone
- Stopignore:** Reg ignore window: End of the ignore zone
- Reg:** Reg signal (I4 on X12/10)
- Regf:** Signal: Reg detected (Statuswort 1 Bit 15)
- POS:** Signal: Position reached (Ausgang A1: X12/3 oder Zustandswort 1 Bit 9)
- 1** Programmable status bits of RegSearch (only for positioning with set selection)
- 2** Programmable status bits of RegMove (only for positioning with set selection)

The reg is ignored; the drive moves to the target position from the RegSearch motion set.


Example 3: Reg is missing or comes after termination of the RegSearch motion set



Start	Start signal for reg positioning (Steuerwort 1 Bit 4)
RegSearch:	Positioning for reg search
RegMove:	Positioning according to reg
StartIgnore:	Reg ignore window: (see on page 146) Beginning of the ignore zone
StopIgnore:	Reg ignore window: End of the ignore zone
Reg:	Reg signal (I4 on X12/10)
Regf:	Signal: Reg detected (Statuswort 1 Bit 15)
POS:	Signal: Position reached (Ausgang A1: X12/3 oder Zustandswort 1 Bit 9)
1	Programmable status bits of RegSearch (only for positioning with set selection)
2	Programmable status bits of RegMove (only for positioning with set selection)

The drive moves to the target position from the RegSearch motion set


Example 4: Reg comes before the reg restriction window



Start	Start signal for reg positioning (Steuerwort 1 Bit 4)
RegSearch:	Positioning for reg search
RegMove:	Positioning according to reg
StartIgnore:	Reg ignore window: (see on page 146) Beginning of the ignore zone
StopIgnore:	Reg ignore window: End of the ignore zone
Reg:	Reg signal (I4 on X12/10)
Regf:	Signal: Reg detected (Statuswort 1 Bit 15)
POS:	Signal: Position reached (Ausgang A1: X12/3 oder Zustandswort 1 Bit 9)
1	Programmable status bits of RegSearch (only for positioning with set selection)
2	Programmable status bits of RegMove (only for positioning with set selection)

As from the mark, the drive moves on relatively by the offset defined in RegMove and then stops at that position (same behavior as in example 1).

Example 5: The registration mark comes after the reg restriction window, registration mark can, however, not be reached without direction reversal



- Start** Start signal for reg positioning (Steuerwort 1 Bit 4)
- RegSearch:** Positioning for reg search
- RegMove:** Positioning according to reg
- StartIignore:** **Reg ignore window:** (see on page 146) Beginning of the ignore zone
- StopIignore:** Reg ignore window: End of the ignore zone
- Reg:** Reg signal (I4 on X12/10)
- Regf:** Signal: Reg detected (Statuswort 1 Bit 15)
- POS:** Signal: Position reached (Ausgang A1: X12/3 oder Zustandswort 1 Bit 9)
- 1** Programmable status bits of RegSearch (only for positioning with set selection)
- 2** Programmable status bits of RegMove (only for positioning with set selection)
- Error** Ausgang A0: X12/2 oder Statuswort 1 Bit 3

Position reached can be activated for a short period, if the position window was not linked to the command value.

With "**Allow higher deceleration for RegMove** (see on page 146)", Compax3 sets the required deceleration.


4.1.15.3 Electronic gearbox (Gearing)

The motion function “Gearing” (electronic gearbox) moves Compax3 synchronously with a leading axis.

A 1:1 synchronism or any transmission ratio can be selected via the gear factor.

A negative sign - which means reversal of direction - is permitted.

Function Electronic gearbox (Gearing)



The position of a master axis can be detected via:

- ◆ +/-10V analog input
- ◆ Step / direction input (X11/6, 7, 8, 12)
- ◆ the encoder input (X11/6, 7, 8, 12) or
- ◆ HEDA, if Compax3 is used as master drive.

The master signal detection is configured under synchronization.

Settings of the “Gearing” motion function

**Gearing numerator /
Gearing
denominator:**

Transmission ratio slave / master

The transmission ratio (gear factor) can be entered in “Gearing numerator” (at “Gearing denominator” = 1).

You will obtain an exact image of a non-integral transmission ratio by entering the value integrally as a fraction with numerator and denominator. This helps to avoid long-term drifts

That is:

$$\frac{\text{Sub}}{\text{Master}} = \frac{\text{Gearing numerator}}{\text{Gearing denominator}}$$

Acceleration

Here you can define the acceleration for the drive to reach the desired synchronism.

- Dynamic change of the gear factor** You can switch dynamically between 2 gearing motion sets with different gear factors.
The set acceleration counts as deceleration if the gear factor is reduced.
- Dynamic switching between the gearing motion function and positioning functions (MoveAbs, MoveRel, RegSearch) is possible.
- Synchronicity:** With the "Gear reached" signal(Ausgang A1: X12/3 oder Zustandswort 1 Bit 9), the reaching of the synchronicity is displayed.
The signal "Gear reached" is reset if the synchronicity is exited.
The programmable status bits (PSBs) are activated via the signal "Gear reached".
- Limiting effects** If the synchronicity is lost temporarily due to limitations, the resulting position difference is made up afterwards.

Note: Jerk is not limited.

4.1.15.4 Speed specification (Velocity)

This motion function is defined by velocity and acceleration.

An active motion set is interrupted by:

- ◆ Stop or
- ◆ Start of a different set.

As soon as the setpoint speed is reached, "speed reached" (Ausgang A1: X12/3 oder Zustandswort 1 Bit 9) as well as the defined status bits (PSBs) are activated.

Note: Position control is active, i.e. the following error caused by limitations will be made up.
Jerk is not limited.

4.1.15.5 Stop command (Stop)

The Stop set interrupts the current motion set (Stop with interruption).

This motion function is defined by the deceleration and the jerk of the drive when coming to a standstill.

As soon as the drive is at standstill "position reached" (Ausgang A1: X12/3 oder Zustandswort 1 Bit 9) as well as the defined status bits (PSBs) are activated.

Note: The stop command (as motion function) is not effective during the machine zero run.

4.1.16. Error response

Under "configuring: Error reaction" you can change the error reaction for individual **errors** (see on page 342) (the error no. which can be influenced is displayed).

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

Note on Compax3H:

The error reaction upon the "low voltage DC" error (0x3222) is fixed to "downramp/deenergize" for Compax3H.

4.1.17. Configuration name / comments

Here you can name the current configuration as well as write a comment.
 Then you can download the configuration settings or, in T30 or T40 devices, perform a complete Download (with IEC program and curve).

	<p>Caution! Deactivate the drive before downloading the configuration software!</p> <p>Please note! Incorrect configuration settings entail danger when activating the drive. Therefore take special safety precautions to protect the travel range of the system.</p>
---	--


	<p>Mechanical limit values! Observe the limit values of the mechanical components! Ignoring the limit values can lead to destruction of the mechanical components.</p>
---	---

4.1.18. Dynamic positioning

You can change over to a new motion set during a positioning process.
 All motion parameters of the new data record become valid

Hint The new motion set address must not equal 0.

Example: MoveAbs (Target position POS1) is interrupted by a new MoveAbs with target position (POS 5)



The following dynamic transitions are supported:

Motion function in progress	Possible dynamic change to the motion function:
MoveAbs, MoveRel, RegSearch, RegMove, Velocity	MoveAbs, MoveRel, Velocity, RegSearch, Gearing
Gearing	MoveAbs, MoveRel, RegSearch, Gearing (other gearing factor)
Stop	-

Prerequisite: Prerequisite for dynamic positioning is:
Control word 1 Bit 5 = "1" (Change set immediately)

4.2 Configuring the signal Source

In this chapter you can read about:

Signal source of the load feedback system 157
 Select signal source for Gearing 157

4.2.1. Signal source of the load feedback system

Configuration of the **load control** (see on page 161) (Dual Loop Option)

4.2.2. Select signal source for Gearing

In this chapter you can read about:

Signal source HEDA 158
 Encoder A/B 5V, step/direction or SSI feedback as signal source 158
 +/-10V analog speed setpoint value as signal source 160

Here the signal source is configured for the motion function "Gearing" (electronic gearbox).

Available are:

Gearing input signal source

- ◆ The HEDA real-time bus (M10 or M11 option) directly from a Compax3 master axis
- ◆ an encoder signal A/B 5V
- ◆ a step/direction signal 5V or
- ◆ a velocity as analog value +/-10V

HEDA operating mode HEDA as Master


Under signal source gearing "not configured" must be set!

If an existing HEDA option (M10 or M11) is not used as signal source, you can transmit the following signals for a slave axis via HEDA:

- ◆ Process - setpoint position (Object 2000.1)
- ◆ Process - actual position (Object 2200.2)
- ◆ Position as from external Setpoint value (Object 2020.1)

Signal read into the master via Analogkanal 0 (X11/9 und X11/11), Encoder input or step/direction input .

Principle:





Attention in the case of a configuration download with master-slave coupling (electronic gearbox, cam)

Switch Compax3 to currentless before starting the configuration download: Master and Slave axis

4.2.2.1 Signal source HEDA

Signal source is a Compax3 master axis in which the HEDA operating mode "HEDA master" is set.

Please enter besides the desired error reaction an individual HEDA axis address in the range from 1 ...32.

The dimensional reference to the master is established via the following settings:

- ◆ Travel distance per motor revolution (or pitch for linear motors) master axis numerator
With denominator = 1 the value can be entered directly.
Long-term drift can be avoided by entering non-integral values integrally as a fraction with numerator and denominator.
- ◆ Travel per motor revolution (or pitch of linear motors) master axis denominator
If required the direction of rotation of the master axis read in can be changed.

4.2.2.2 Encoder A/B 5V, step/direction or SSI feedback as signal source

Caution!

- ◆ The encoder simulation is not possible at the same time as the encoder input<ohne_SSI_t> resp. the step/direction input.
The same interface is used here.
- ◆ A direction reversal configured in the C3 ServoManager does not affect the encoder simulation.
The direction of rotation of the encoder simulation can, however, be changed via the feedback direction in the MotorManager.

The dimensional reference to the master is established via the following settings:

- ◆ Travel distance per motor revolution (or pitch for linear motors) master axis numerator
With denominator = 1 the value can be entered directly.
Long-term drift can be avoided by entering non-integral values integrally as a fraction with numerator and denominator.
- ◆ Travel per motor revolution (or pitch of linear motors) master axis denominator
- ◆ Increments per revolution of the master axis

If required the direction of rotation of the master axis read in can be changed.

Example: Electronic gearbox with position detection via encoder

Reference to master axis

The reference to the master axis is established via the increments per revolution and the travel path per revolution of the master axis (corresponds to the circumference of the measuring wheel).

That is:

$$\text{MasterPos} = \frac{\text{Master_I}}{\text{I_M}} * \frac{\text{Travel Distance per Master Axis revolution (M_Units/rev)}}{\text{Travel Distance per Master Axis revolution - Denominator}} \quad (1)$$

MasterPos: Master Position

Master_I: master increments read in

I_M: Increments per revolution of the master axis

External signal source Encoder with 1024 increments per master revolution and a circumference of the measuring wheel of 40mm.

Settings: Travel path per revolution of the master axis numerator = 40
 Travel path per revolution of the master axis denominator = 1
 Increments per revolution of the master axis = 1024

Configuration wizard: Reference system of Slave axis: Unit of measure [mm]
 Travel path per revolution numerator = 1
 Travel path per revolution denominator = 1

Gearing: Gearing numerator = 2
 Gearing denominator = 1

This results in the following interrelations:

If the measuring wheel moves by 40mm (1 master revolution), the slave axis will move by 80mm.


$$\text{Slave unit} = \text{MasterPos} * \frac{\text{Gearing numerator}}{\text{Gearing denominator}} \quad (2)$$

(1) set into (2) and with numerical values results with 1024 increments read in (=1 Master revolution):

$$\text{Slave unit} = 1024 * \frac{1}{1024} * \frac{40\text{mm}}{1} * \frac{2}{1} = 80\text{mm}$$

Master - Position = +40mm => Slave - Position = +80mm

Structure:



Detailed structure image

with:

$$\text{MD} = \frac{Z1}{N1} * \frac{\text{Travel Distance per Master Axis revolution (M_Units/rev)}}{\text{Travel Distance per Master Axis revolution - Denominator}}$$

Entry in the "configuration of the signal source" wizard

$$\text{SD} = \frac{Z2}{N2} * \frac{\text{Travel path per revolution slave axis numerator}}{\text{Travel path per revolution slave axis denominator}}$$

Entry in the "configuration of the signal source" wizard

MD: Feed of the master axis

SD: Feed of the slave axis

4.2.2.3 +/-10V analog speed setpoint value as signal source


Via Analogkanal 0 (X11/9 und X11/11) the speed of the master is read in.

From this value a position is internally derived, from which then the motion of the drive is derived with reference to the transmission ratio.

Without limitation effect applies:

Velocity of the master * (Gearing numerator / gearing denominator) = velocity of the slave

Signal processing of the analog input 0



B: **Continuative structure image** (see on page 241)

The reference to the master is established with the velocity at 10V.


If required the direction of rotation of the master axis read in can be changed.

Zeitraster Signalquelle Master

Averaging and a following filter (interpolation) can help to avoid steps caused by discrete signals.

If the external signal is analog, there is no need to enter a value here (Value = 0).

For discrete signals e.g. from a PLC, the scanning time (or cycle time) of the signal source is entered.



This function is only available if the analog interface +/-10V is used!

4.3 Load control

In this chapter you can read about:

Configuration of load control 163
 Error: Position difference between load mounted and motor feedback too high 164
 Load control signal image 164

The load control can be activated via an additional feedback system for the acquisition of the actual position of the load.

This helps for example compensate the slip between material and roller or non-linearities of the mechanic parts.

The load position is set to the demand position.

Please note:

- ◆ This function is not available in the C3I10T10 and C3I11T11 devices.
- ◆ As a sensor signal, **Encoder** (see on page 408) with A/B track, Step/Direction signal or SSI - sensor is supported.
- ◆ This controller structure improves the stationary precision at the load after the decay of all control movements.
 An increase of the dynamic precision (faster transient response) can in general not be reached with the "load control" structure variant.

Notes on the SSI sensor

- ◆ With Multiturn: Number of sensor rotations with absolute reference
- ◆ Word length: Gives the telegram length of the sensor.
- ◆ Baud rate/step: Max. transmission rate of the path measurement system.
- ◆ Gray code: Sensor gray code coded yes/no (if no binary coded).


Note:

The absolute position is not evaluated!

It is available in the objects 680.24 (load position) and 680.25 (master position) (C3T30, C3T40).

General requirements for supported SSI feedbacks

- ◆ Baud rate: 350k ... 5Mbaud
- ◆ Word length: 8 ... 32 Bit
- ◆ Binary or gray code (start value = 0)
- ◆ Initialization time after PowerOn: < 1.1s
- ◆ Signal layout:



The most significant bit must be transmitted the first!

Caution! Feedback systems, transmitting data containing error or status bits are not supported!

◆ Examples of supported SSI feedback systems:

- ◆ IVO / GA241 SSI;
- ◆ Thalheim / ATD 6S A 4 Y1;
- ◆ Hübner Berlin / AMG75;
- ◆ Stegmann / ATM60 & ATM90;
- ◆ Inducoder / SingleTurn: EAS57 & Multiturn: EAMS57

4.3.1. Configuration of load control

Configuration in the "configure signal source" wizard under "load feedback system":

- ◆ The selection of the feedback signal activates the acquisition and the signals are available as **status values** (see on page 164).
- ◆ Rotatory or linear feedback systems are supported.
- ◆ Input values for rotatory feedback systems:
 - ◆ Increments per feedback revolution (physical, without quadruplication)
 - ◆ Direction reversal

Attention!With wrong sense of direction and active load control, you will get a positive feedback; the motor will accelerate in an uncontrolled way
Solution: Before the load control is activated, the signals must be checked with the aid of the **status values** (see on page 164) and secured against wrong sense of direction by configuring a "maximum difference to motor position" (O410.6).
 - ◆ Load travel per feedback revolution: Is used for establishing the measure reference between load- and motor position.
The value can be configured very precisely by entering numerator and denominator.
- ◆ Input values for linear feedback system
 - ◆ Feedback resolution (physical, without quadruplication)
Position difference, which corresponds to a cycle duration of the feedback signal.
 - ◆ Direction reversal

Attention!With wrong sense of direction and active load control, you will get a positive feedback; the motor will accelerate in an uncontrolled way
Solution: Before the load control is activated, the signals must be checked with the aid of the **status values** (see on page 164) and secured against wrong sense of direction by configuring a "maximum difference to motor position" (O410.6).
 - ◆ Scaling factor for an additional adaptation of the feedback signal (is normally not required = 1)
 - ◆ Maximum difference to the motor position
Upon exceeding this value, Compax3 will report **error 7385hex** (see on page 164) (29573dec)
 - ◆ Intervention limitation (=2201.13 in % of the reference velocity or reference speed);
only active with position controller I component switched off (O2200.25=0)
You can use this specification in order to limit position correction intervention, i.e. to limit the velocity correction factor resulting from the position difference. This can be especially sensible during the acceleration phase, if the material slips because of too high corrective velocities.
- ◆ Activate / Deactivate load control

Attention!

**The load control is immediately active after the configuration download!
Please do only activate after checking the load position signal (scaling, direction, value).**

4.3.3.1 Object for the load control (overview)

No.	Object name	Object	Format	PD	Valid beginning
410.6	C3.LimitPosition_LoadControlMaxPosDiff	Position difference load-motor (error threshold)	C4_3	no	VP
680.23	C3.StatusPosition_LoadControlActual	Actual position of the load	C4_3	no	-
680.20	C3.StatusPosition_LoadControlDeviation	Position difference load-motor (unfiltered)	C4_3	no	-
680.22	C3.StatusPosition_LoadControlDeviationFiltered	Position difference load-motor (filtered)	C4_3	no	-
680.21	C3.StatusPosition_LoadControlDeviationMax	Maximum position difference load-motor	C4_3	no	-
681.20	C3.StatusSpeed_LoadControl	Speed of the load feedback (unfiltered)	C4_3	no	-
681.21	C3.StatusSpeed_LoadControlFiltered	Speed of the load feedback (filtered)	C4_3	no	-
2201.2	C3Plus.LoadControl_Command	Load control command mode	I16	no	immediately
2201.1	C3Plus.LoadControl_Enable	Activate Load control	I16	no	immediately
2201.11	C3Plus.LoadControl_FilterDenominator	Time constant of position difference filter	U32	no	VP
2201.3	C3Plus.LoadControl_Status	Load control status bits	I16	no	-
2201.12	C3Plus.LoadControl_VelocityFilter	Time constant of the load-speed filter for the load feedback	I16	no	VP

4.3.3.2 Objects for load control

Detailed information on the topic of "objects for load control" can be found in the online help of the device.

4.4 Optimization

In this chapter you can read about:

Optimization window	167
Scope	168
Controller optimization	176
Signal filtering with external command value	241
Input simulation	244
Setup mode	246
Load identification.....	248
Alignment of the analog inputs.....	251
C3 ServoSignalAnalyzer.....	253
ProfileViewer for the optimization of the motion profile.....	290
Turning the motor holding brake on and off.....	292

- ◆ Select the entry "**Optimization**" in the tree.
- ◆ Open the optimization window by clicking on the "**Optimization Tool**" button.

4.4.1. Optimization window

Layout and functions of the optimization window

Segmentation

Window 1:

Window 2:

Window 3:

Window 4:

Functions (TABs)

◆ **Oscilloscope** (see on page 168)

◆ Optimization: Controller optimization

◆ **D/A Monitor** (see on page 341): Output of status values via 2 analog outputs

◆ Scope Settings

◆ Status Display

◆ Compax3 Error History

◆ Status values

◆ Commissioning: **Setup mode** (see on page 246) with **load identification** (see on page 248)

◆ Parameters for commissioning, test movements (relative & absolute) and for load identification.

The screenshot displays the optimization window interface with four numbered callouts:

- 1**: Points to the Oscilloscope window, which shows a grid and a scale of 500 us / DIV (4 smp).
- 2**: Points to the 'Übersicht Optimierungsobjekte' (Overview of optimization objects) table.
- 3**: Points to the 'Statusanzeige' (Status display) window, which shows a list of status values and a 'Statusanzeige' label.
- 4**: Points to the 'Statuswerte' (Status values) window, which shows a list of status values and a 'Kein Statuswert ausgewählt' (No status value selected) message.

Optimierungs-Objekt	Wert	Einheit
Führungsverhalten (Vorsteuerung)		
Drehzahlvorsteuerung [2010.1]	100	%
Beschleunigungsvorsteuerung [2010.2]	100	%
Stromvorsteuerung [2010.4]	0	%
Ruckvorsteuerung [2010.5]	0	%
EMK-Vorsteuerung [2010.20]		%
Schwert-/Störverhalten (Reglerdynamik)		
Steifigkeit [2100.2]	100	%
Dämpfung [2100.3]	100	%
Trägheitsmoment [2100.4]	100	%
D-Anteil Drehzahlregler [2100.7]	0	%
Stellsignalfilter (Geschwindigkeitsregler) [2100.20]	44	us
Stellsignalfilter 2 (Geschwindigkeitsregler) [2100.1]	0	us
Filter Beschleunigungsiswert [2100.21]	44	us

4.4.2. Scope

In this chapter you can read about:


Monitor information	168
User interface	169
Example: Setting the Oscilloscope	174

The integrated oscilloscope function features a 4-channel oscilloscope for the display and measurement of signal images (digital and analog) consisting of a graphic display and a user interface.

Special feature:

In the single mode you can close the ServoManager after the activation of the measurement and disconnect the PC from Compax3 and upload the measurement into the ServoManager later.

4.4.2.1 Monitor information



- 1: Display of the trigger information
- 2: Display of the operating mode and the zoom setting
 - ◆ 2a: Green indicates, that a measurement is active (a measurement can be started or stopped by clicking here).
 - ◆ 2b: Active channel: The active channel can be changed sequentially by clicking here (only with valid signal source).
- 3: Trigger point for Single and Normal operating mode
- 4: Channel information: Type of display and trigger setting
- 5: X-DIV: X deviation set
- 6: Single channel sources

Cursor modes -functions

Depending on the operating mode, different cursor functions are available within the osci monitor.

The functions can be changed sequentially by pressing on the right mouse button.


Cursor Symbol	Function
	Set Marker 1 the measurement values of the active channel as well as the Y difference to marker 2 are displayed
	Set Marker 2
	Delete and hide marker
	Move offset of the active channel. The yellow symbol indicates that the scrolling is active.
	Set trigger level and pretrigger

In the ROLL operating mode, marker functions and set trigger level positions are not available.

4.4.2.2 User interface

In this chapter you can read about:

- Oscilloscope operating mode switch:.....
- Setting the time basis XDIV.....
- Settings for channels 1..4.....
- Trigger settings.....
- Special functions.....



- 1: **Operating mode switch** (see on page 170) (Single / Normal / Auto / Roll)
- 2: **Setting the time basis** (see on page 170)
- 3: Starting / Stopping the measurement (prerequisites are valid channel sources and if necessary valid trigger settings.)
- 4: **Setting channel** (see on page 171) (Channels 1 ...4)
- 5: **Special functions** (see on page 172) (Color settings; memorizing settings and measurement values)
- 6: Loading a measurement from Compax3: in the single mode you can close the ServoManager after the activation of the measurement and disconnect the PC from Compax3 and upload the measurement later.
- 7: **Setting triggering** (see on page 172)
- 8: Copy osci display to clipboard
- 9: Zoom of the osci display (1, 2, 4, 8, 16 fold) with the possibility to shift the zoom window (<,>)

Oscilloscope operating mode switch:

Oscilloscope operating mode switch:



Selection of the desired operating mode: SINGLE, NORMAL; AUTO and ROLL by clicking on this button.

Changing the operating mode is also permitted during a measurement. The current measurement is interrupted and started again with the changed settings.

The following operating modes are possible:

Operating mode	Short description
SINGLE	Single measurements of 1-4 channels with trigger on a freely selectable channel
NORMAL	Like Single, but after each trigger event, the measurement is started again.
AUTO	No Trigger. Continuous measuring value recording with the selected scanning time or XDIV setting
ROLL	Continuous measuring value recording of 1 .. 4 channels with selectable scanning time and a memory depth of 2000 measuring values per channel.

With SINGLE / NORMAL / AUTO, the measurement is made in Compax3 and is then loaded into the PC and displayed.

With ROLL, the measuring values are loaded into the PC and displayed continuously.

Setting the time basis XDIV

Setting the time basis XDIV



Depending on the selected operating mode, the time basis can be changed via the arrow keys.

For the operating modes SINGLE, NORMAL and AUTO, the following XDIV time settings are possible:


XDIV	Mode	Scanning time	Samples DIV/TOTAL	Measuring time
0.5ms	1	125us	4/40	5ms
1.0ms	2	125µs	8/80	10ms
2.0ms	3	125µs	16/160	20ms
5.0ms	4	125µs	40/400	50ms
10.0ms	5	125µs	80/800	100ms
20.0ms	6	250µs	80/800	200ms
50.0ms	7	625µs	80/800	500ms
100.0ms	8	1.25ms	80/800	1s
200.0ms	9	2.50ms	80/800	2s
500.0ms	10	6.25ms	80/800	5s
1s	11	12.50s	80/800	10s
2s	12	25.00ms	80/800	20s
5s	13	62.50ms	80/800	50s
10s	14	125.00ms	80/800	100s

For the operating ROLL, the following XDIV time settings are possible:

XDIV	Mode	Scanning time	Samples DIV/TOTAL
2 ms	54	125us	200/2000
2ms	54	125µs	200/2000
4ms	55	125µs	200/2000
10ms	56	125µs	200/2000
20ms	57	125µs	200/2000
40ms	58	125µs	200/2000
100ms	59	250µs	200/2000
200ms	60	625µs	200/2000

Changing the time basis is also permitted during an OSCI measuring sequence. This means, however, that the current measurement is interrupted and started again with the changed settings.

Settings for channels 1..4



1: Select channel color

2: Open menu for channel-specific settings

- ◆ **Resetting channel CH 1..4:** All channel settings are deleted.
Please note: Channels can only be filled with sources one after the other. It is, for example, not possible to start a measurement which has only a signal source for channel 2!
- ◆ **Select channel color:** Here you can change the color of the channel.
- ◆ **Show/hide channel:** Hide/show display of the channel.
- ◆ **Change logic display mask:** Mask bits in logic display.
- ◆ **Autoscale:** Calculating YDIV and offset: The program calculates the best settings for YDIV and channel offset in order to display the complete signal values optimally.

3: Set signal source with object name, number and if necessary unit

- ◆ **Define source:** Draw the desired status object with the mouse (drag & drop) from the "Status value" window (right at the bottom) into this area.
Multiple oscilloscope in Compax3M: select device in addition to the object.

4: Set Channel offset to 0


5: Select channel display (GND, DC, AC, DIG)

- ◆ **DC:** Display of the measurement values with constant component
- ◆ **AC:** Display of the measurement values without constant component
- ◆ **DIG:** Display of the individual bits of an INT signal source.
The displayed bits can be defined via the logic display mask.
- ◆ **GND:** A straight line is drawn on the zero line.

6: Set Y-amplification (YDIV)

Change of the Y amplification YDIV in the stages 1, 2, 5 over all decades.
Arrow upwards increases YDIV, arrow downwards diminishes YDIV.
The standard value is 1 per DIV.
The measurement value of the channel at the cursor cross is displayed.

Trigger settings



Select trigger channel: Buttons C1, C2, C3, C4

Select trigger mode: DC, AC, DG

Selecting the trigger edge: Rising_/ or falling \.

The pretrigger as well as the trigger level are set by clicking on the trigger cursor



) directly in the OSC1 display.

Special functions



Menu with special oscilloscope functions such as memorizing or loading settings.

Functions:

- ◆ **Select background color:** Adapt background color to personal requirements.
- ◆ **Select grid color:** Adapt grid color to personal requirements.
- ◆ **Memorize OSCI settings in file:** The settings can be memorized in a file on any drive. The file ending is *.OSC.
- ◆ The format corresponds to an INI file and is presented in the appendix.
- ◆ **Open OSCI settings from file:** Loading a memorized set of settings. The file ending is *.OSC.
- ◆ **Memorizing OSCI settings in the project:** Up to four sets of OSCI settings can be memorized in the current C3 ServoManager project. .
- ◆ **Open OSCI settings from project:** If settings were memorized in the project, they can be read in again.
- ◆ **Memorize OSCI measurement in file:** Corresponds to memorizing the setting; the measurement values of the measurement are stored in addition. Thus it is possible to memorize and read measurements completely with settings. The file ending is *.OSM.
- ◆ **Export measure samples to csv file:** e.g. for reading into Excel.

4.4.2.3 Example: Setting the Oscilloscope

SINGLE measurement with 2 channels and logic trigger on digital inputs

The order of the steps is not mandatory, but provides a help for better understanding.

As a rule, all settings can be changed during a measurement. This will lead to an automatic interruption of the current measurement and to a re-start of the measurement with the new settings:

Assumption: A test movement in the commissioning mode is active.

1.) Select OSCI operating mode



2.) Select Time basis XDIV



3.) Select channel 1 signal source digital inputs 120.2 from status tree with the aid of Drag & Drop

4.) Select channel 2 (filtered actual speed) via "Drag and drop" from the status tree

5.) Set trigger to channel 1 and DG.

Input of the mask in HEX

Triggering a rising edge to input I1.

BIT 0 (value 1) = I0

BIT 1 (value 2) = I1

BIT 2 (value 4) = I2 etc.

Trigger to input	I0	I1	I2	I3	I4	I5	I6	I7
Trigger mask in hex	1	2	4	8	10	20	40	80

The masks can also be combined so that the trigger is only active, if several inputs are active. Example: Triggering to I2 and I5 and I6 -> 4h + 20h + 40h = 64h

The mask for input I1 is in this case 2.

Select rising edge.

NOTE: If the trigger mask DG (digital) is selected for a channel, the display mode of the trigger channel is automatically set to DIG display.

6.) Start measurement

7.) Set pretrigger in the OSCI window

Note: There is no level for the DIG trigger. The the event limit determines the mask
If a trigger event occurs, the measurement values are captured until the measurement is completed.


Afterwards, the measurement values are read from the Compax3 and displayed.

The display mask of trigger channel 1 was not yet limited, therefore it shows all 16 bit tracks (b0...b15). In order to limit it to 8 bit tracks, you must call up the menu for channel 1 via [CH1] and select "change logic of display mask [H].

Limit the display mask to 8 bit tracks with Mask FFh.

In the display the bit tracks b0 to b7 are now shown:

Example: Only b0 and b1 are to be displayed: Set display mask to 03



4.4.3. Controller optimization

In this chapter you can read about:

Introduction176
 Configuration179
 Automatic controller design197
 Setup and optimization of the control209

4.4.3.1 Introduction


In this chapter you can read about:

Basic structure of the control with Compax3 176
 Proceeding during configuration, setup and optimization 176
 Software for supporting the configuration, setup and optimization 177

Basic structure of the control with Compax3

Compax3 is an intelligent servo drive for different applications and dynamic motion sequences.


Basic structure of a control with the Compax3e servo drive



As shown in the above figure, the programmed motion sequences are generated by the internal Compax3 setpoint generator. The setpoint position as well as the other status values of the feedforward control are made available to the position controller in order to keep the following error as small as possible.

For the control, Compax3 requires on the one hand the actual position and on the other hand the commutation position, which represents the reference between the mechanic feedback position and the motor magnet.

Proceeding during configuration, setup and optimization



Overview of the processes during configuration and setup of the Compax3 drive system

The controller default settings are calculated from the configured motor and application parameters with the aid of the automatic controller design which runs in the background.

These controller presettings provide normally for a stable and robust control. Due to continually rising application requirements, this presetting is often not sufficient, so that further optimization of the control behavior is necessary.


This manual describes the setup and optimization procedure for Compax3.

In order to better understand the correlations and interactions, we will describe in the first step the individual correlations and physical values, that are required for the configuration and the prespecification of the control loops. In the following, the manual will then describe the function blocks for the optimization implemented in the servo drive as well as the setup tool.

Software for supporting the configuration, setup and optimization

In this chapter you can read about:

Application parameters 178



The entry of the motor and application parameters is made with the C3 ServoManager2 (C3Mgr2.exe):


The configuration requires:

Application parameters

The wizard guided entry of the application parameters takes place directly in the ServoManager.

Carefully verify the entries and default values in order to detect entry errors in the run-up.

After the configuration download, the drive can be set up and be optimized if needs be. For this, please open the optimization window of the ServoManager:




4.4.3.2 Configuration

In this chapter you can read about:

Control path..... 179
 Motor parameters relevant for the control 180
 Mass inertia..... 180
 Nominal point data 181
 Saturation values..... 182
 Quality of different feedback systems 183
 Typical problems of a non optimized control 184
 Feedback error compensation 185
 Commutation settings..... 186
 I²t - monitoring of the motor 186
 Relevant application parameters 189
 Asynchronous motors..... 193

Control path

For the motors, the knowledge of the mathematical model is a prerequisite.
 Mathematically idealized model of the control path:



U:	Control voltage
U _{EMK} :	electromagnetically generated voltage in the motor
T:	electric time constant of the motor winding
L:	Winding Inductance
R:	Winding Resistance
M _A :	Drive torque of the motor
M _L :	Load torque
M _B :	Acceleration torque
I:	Actual current r.m.s. (torque-producing)
K _T :	Torque constant
J _{mot} :	Motor mass moment of inertia
J _{ext} :	external mass moment of inertia
J _{total} :	Total mass moment of inertia
a:	Acceleration
n:	Velocity

Explanation:

The motor is controlled by the servo drive with control voltage U . During motion of the motor, an internal back e.m.f. U_{EMC} is induced. This antagonizes the control voltage and is therefore deduced in the motor model. The difference is available for the acceleration of the motor.

The first order delay component represents the delaying property of the motor winding with the time constant $T=L/R$. According to Ohm's Law, a current $I=U/R$ results.

The drive torque of the motor is calculated by multiplying the current with the motor torque constant K_T . This is antagonized by the load torque of the machine.

The remaining acceleration torque accelerates the motor.

The resulting acceleration depends on the total mass moment of inertia (= motor + load moment of inertia).

The integration of the acceleration (sum of the acceleration over time) results in the velocity of the motor, which influences the amplitude of the induced EMC voltage.

Motor parameters relevant for the control

All motor parameters relevant for the control quality will be explained below.

Wizard guided entry of the motor parameters in the MotorManager.

Electromotoric countercheck EMC

A non-energized synchronous motor induces an induction voltage, the so-called EMC voltage during an armature movement.

The EMC constant (motor EMC) states the value of the induced voltage subject to velocity.

The EMC constant corresponds to the motor torque constant K_T , which represents the correlation between the torque-producing current and the drive torque, however in a different unit.

The EMC voltage antagonizes the control voltage of the servo drive.

As the control voltage of the drive is not unlimited, it must be taken into consideration that the drive may approach the voltage limit at high velocities and therefore high EMC voltages.

The EMC constant is important with respect to the velocity control design.

The motor EMC is entered in the "motor characteristics" wizard window of the MotorManager. You may choose between different units. Please note the information on the motor type specification plate.

Mass inertia

The mass moment of inertia (moment of inertia) is also an important motor parameter for the design of the velocity control loop. For the velocity control design, this parameter is effective in correlation with the external mass moment of inertia of the load. The external load is entered in the C3 ServoManager. With the "load identification" function of the C3 ServoManager, the mass inertia can be determined, if it is not yet known.

Nominal point data


In this chapter you can read about:

- Motor characteristic line of a synchronous servo motor (torque via velocity) 181
- Calculation of the reference current from the characteristic line..... 181

The nominal point data can be found in the velocity characteristic line of the motor. The prespecified nominal point can be changed in the 2nd wizard page of the C3 ServoManager configuration with the aid of "activate change of reference point" via the reference velocity and the reference current.

Motor characteristic line of a synchronous servo motor (torque via velocity)

SMH 60 30 1.4 ...2ID...4: 3000rpm at 400VAC



[Motorkennlinie.emf /.jpg]

- 1: Nominal point
- 2: Forbidden range

Calculation of the reference current from the characteristic line.

$$I = \frac{M[Nm]}{EMK} \cdot 85,5 = \frac{M[Nm]}{K_T}$$

or for linear motors

$$I = \frac{M[Nm]}{EMK_v} \cdot \frac{\sqrt{2}}{\sqrt{3}} = \frac{M[Nm]}{K_f}$$

In the MotorManager, a motor can be defined for different operating modes (230V, 400V and 480V) without having to create several entities.


Additional parameters of a motor are:

- ◆ Standstill current [mA_{rms}]
- ◆ Pulse current [in % of the nominal current]
 The pulse current can be provided by the Compax3 for the duration of the pulse current time (as far as the device current permits). The thermal pulse load of the motor rises due to the pulse current. This pulse load is monitored by the i²t monitoring in the Compax3.

Saturation values

A motor may show a saturation behavior at higher currents due to iron saturation. This results in the reduction of the winding inductance at higher currents. As the inductance value of the winding enters directly into the P term of the current controller, the saturation at higher currents will result in too fast current control. This behavior can be counter steered with saturation values (entered in the "motor characteristics" wizard window of the MotorManager).

Consideration of the saturation values with the aid of a linear characteristic line



L 100%	Entered value of the nominal inductance
Lmin	Minimum winding inductance [% of the nominal inductance]. Value to which the inductance of the winding sinks at Ifinal.
Ibeg	End of the saturation [% of the nominal inductance].
Ifinal	Beginning of the saturation [% of the nominal inductance].

For the determination of the saturation values please see chapter 0 (see on page 241, see on page 241, see on page 242).

Quality of different feedback systems

In this chapter you can read about:

Interface	183
Resolution	183
Noise	183

The controller quality depends to a great extent on the signal quality of the position feedback and its signal acquisition. It is therefore important to select a suitable measurement system for the individual application.

In the rotary range, a resolver is mostly used for reasons of economics. The single pole resolver provides one sine/cosine period per revolution. In very demanding applications, the performance of the resolver is often not satisfactory, so that a SinCos feedback with a higher resolution must be used. The typical resolution of a SinCos feedback is 1024 periods/revolution.

Other position feedbacks which are often used in the linear range, differ with respect to the reading principle. High-quality optical position measuring systems offer the highest resolution and accuracy.

Interface

An additional distinctive feature is the electric interface between servo drive and feedback. Analog sine/cosine signals or digital encoder signals (RS422 standard) are used to transmit the incremental position information. Due to the high interpolation rate (approx. 14 bits) of the Compax3 servo controller, an analog sine/cosine signal is in most cases preferable to digital encoder signals.


Resolution

The less precise the resolution, the higher the quantization noise on the velocity signal.


Noise

The feedbacks have different levels of analog noise, which have a negative effect on the control. The noise can be dampened with the aid of filters in the actual value acquisition, however at the cost of the controller bandwidth.

For comparison, the noise of the actual velocity value at standstill of two different feedbacks is displayed.



Resolver: 1 period/revolution



SinCos: 1024periods/revolution


Typical problems of a non optimized control

In this chapter you can read about:

Too high overshoot on velocity 184
 Increased following error 184
 Instable behavior 184

Upon first setup of a control, the controller is normally not able to meet all application requirements at once. Typical problems may be:


Too high overshoot on velocity



- 1) Actual velocity
- 2) Setpoint velocity


Increased following error

Increased following error when approaching the target position or the reduction of the following error takes too long



- 1) Following error
- 2) Setpoint velocity
- 3) Actual velocity

Instable behavior




- 1) Setpoint velocity
- 2) Actual velocity
- 3) Following error

Feedback error compensation

Feedbacks with sine/cosine tracks may have different errors. The feedback error compensation supported by Compax3 eliminates offset and gain errors on both tracks online.


The feedback error compensation is activated in the MotorManager: "Feedback system" wizard under "feedback error compensation".

Without compensation



top: Actual current value
bottom: Actual speed value

With compensation



Scale:
Current = 50mA/Div
Speed = 0.2mm/s/Div
Time = 3.8ms/Div

Type of motor: Parker LMDT 1200-1 ironless linear motor
Linear encoder: Renishaw RGH 24B with 20 μ m resolution
Servo drive: Compax3

In order to accept the changes in the MotorManager in the project, the individual configuration pages must be clicked through. In order to make the changes made in the MotorManager effective in the device, the configuration download in the C3Manager must be executed.

In the event of formal errors, the feedback error compensation may however be disadvantageous; therefore it is switched off as a default.

Commutation settings

Another prerequisite for a good control quality is the correct motor commutation. This comprises several settings.

- ◆ The commutation angle describes the relation of the feedback position with respect to the motor pole pair position.
- ◆ Commutation direction reversal describes the correlation between the position of the feedback and the commutation position.
- ◆ Feedback direction reversal describes the direction correlation between the defined positive direction of the drive and the feedback position.
- ◆ If the commutation direction does not match the defined direction of rotation, this will result in a subsequent error with the error message "following error" or "motor stalled".
- ◆ A faulty commutation angle value results in increased current and following error. Therefore the voltage limit is reached faster. If the value of the commutation error exceeds 90°, the motor will spin due to the positive feedback effect.

These 3 settings can be automatically acquired with the MotorManager.

With the aid of the automatic commutation acquisition, the commutation settings can be determined and plausibility checks can be made. You will be guided through the individual wizard pages and the MotorManager will issue a prompt to define the positive direction of the drive. The wizard pages supporting the user depend on the feedback system as well as from the motor type (linear or rotary).

This function is activated in the MotorManager:

"Feedback system" wizard under "automatic commutation settings".

Hint The motor should be operated without load (=> no load torque e.g. weight force of a z-axis).

Additional setting of the commutation for incremental feedback:

This function is activated in the MotorManager:

"Feedback system" wizard under "feedback resolution".

In the event of an incremental feedback (Sine/cosine or RS424 encoder) the commutation must be defined in addition, in order to find the position reference to the winding.

- ◆ Automatic commutation with movement
- ◆ Commutation with digital hall sensors

I²t - monitoring of the motor

In this chapter you can read about:

Motor continuous usage	187
Motor pulse usage	188
Reference point 2: Increased torque thanks to additional cooling.....	189

With the I²t - monitoring, the motor is protected against overload or thermal destruction. For this, knowledge on the load bearing capacity of the motor is required. This information can be taken from the manufacturer documentation (motor parameters). Compax3 monitored:

- ◆ Continuous usage of the motor (motor usage)
- ◆ Pulse usage of the motor (motor pulse usage)

Motor continuous usage


In this chapter you can read about:

Linearized motor characteristic lien for different operating points 187

This kind of monitoring watches over the continually deliverable torque (continuous current). This continuous current depends on the velocity and is acquired online from the linearization of the motor characteristic line.

Linearized motor characteristic lien for different operating points


Nominal point



- I_0 : Standstill current
- 1: Nominal point
- I_N : Nominal current (defined in the MotorManager)
- n_N : Nominal Speed
- 2: Forbidden range

For monitoring the continuous utilization, the linearized characteristic line between I_0 and I_N / n_N is used as a threshold.

Reference point 1: higher velocity at reduced torque



- I_0 : Standstill current
- rp1: Reference point 1 (defined in the C3 ServoManager)
- I_1 : Reference current to reference point 1
- n_1 : Reference velocity to reference point 1
- 2: Forbidden range

For monitoring the continuous usage, the linearized characteristic line between I_0 and I_1 / n_1 is used as a threshold.


Motor pulse usage

This monitoring watches over the duration of the defined pulse current. The permitted duration for the pulse current is defined by the pulse current time constant.


If the acceleration current exceeds the nominal current for a defined time t_1 , a sufficient break time t_2 is required. If the current remains in average above the nominal current, the "monitoring motor pulse usage" [0x7180] error is triggered.

Upon a high pulse usage, the error will occur almost without delay.

Current cycle:



Reference point 2: Increased torque thanks to additional cooling



- I_0 : Standstill current
- 1: Nominal point
- rp2: Reference point 2 (defined in the C3 ServoManager)
- I_2 : Reference current to reference point 2
- n_2 : Reference velocity to reference point 2
- 2: Forbidden range

In order to monitor the continuous usage, the velocity-independent current limit I_2 is used.

If a r.m.s. current over the valid straight flows continually in the motor, the I^2t monitoring will issue the "effective motor current monitoring" error message [0x5F48]. The period of time until the error occurs depends on the thermal time constant of the motor defined in the motor parameters. The electronic temperature monitoring simulates approximately the temperature behavior of the motor. By defining a reference point different from the motor nominal data, the I^2t monitoring of the motor can be adapted to changed thermal ambient conditions (e.g. air stream caused by a ventilator fan).

Relevant application parameters

In this chapter you can read about:

Switching frequency of the motor current / motor reference point..... 190
 External Moment of Inertia..... 192
 Limit and monitoring settings 192

Application parameters relevant for the control (C3 ServoManager)

Compax3 is configured with the aid of the C3 ServoManager. Here you can make application dependant settings. Among these are also parameters, that are relevant for the control. They will be explained below.

Switching frequency of the motor current / motor reference point


In this chapter you can read about:

Following Error (Position Error)..... 190
 Reduction of the current ripple..... 190
 Motor parameters 191
 Changing the switching frequency and the reference point 192

The higher the switching frequency, the better the quality of the current control. The higher switching frequency reduces the dead time of the current control path as well as the current control noise. Furthermore, thermal losses caused by current ripple are reduced at higher switching frequencies.

Following Error (Position Error)


Too high following error (position error) during a movement



- 1) Setpoint Position
- 2) Position deviation = following error
- 3) Effective position

Reduction of the current ripple

Reduction of the current ripple of the phase current due to the higher switching frequency



- 1: Current ripple
- 2: Phase current
- 3: PWM control

Hint Please note that a high switching frequency means also high switching losses in the power output stage of the controller. For this reason, you must consider derated data of the servo controller for the drive design with higher switching frequencies.


Motor parameters

In this chapter you can read about:

Parker Motor..... 191
 Other motor 191
 Motor types supported..... 192


Parker Motor

If a Parker motor is used for the application, the parameters are already contained in the installed software. You can just select one of the available motors from the first configuration page.



Other motor

When using a motor from a different manufacturer, you will have to enter the relevant data. This process is supported by the MotorManager software tool, which can be called up from the ServoManager:



After double clicking on "new", the individual motor parameters are queried by the MotorManager.

Be careful to respect the units of the individual parameters when making your entries!

Furthermore you can use the MotorManager to edit motors already available. In addition, the import and export of motor data entities in XML format is supported.

Motor types supported

Compax3 supports the following motor types:

- ◆ Permanently excited synchronous rotary motors
- ◆ Permanently excited synchronous linear motors
- ◆ Asynchronous rotary motors

In general, rotary and linear motors do have the same signal flow chart. The difference consists solely in the basic physical values, which refer to circular movement resp. the linear motion laws of physics. For this, the following analogies can be established:

Rotary drive [unit]		Linear drive [unit]	
Travel x	[rev]	Path x	[m]
Mass moment of inertia J	[kgm ²]	Mass m	[kg]
Velocity n	[rps]	Velocity v	[m/s]
Angular velocity ω	[1/s]		
Torque constant Kt	[Nm/Arms]	Force constant KF	[N/Arms]
Torque M	[Nm]	Force F	[N]

For reasons of clarity, we will in the following refer to the rotary motor, which will represent both drive types.

An asynchronous motor is set up in the same way as a synchronous motor. The only differences are varying motor parameters.

Changing the switching frequency and the reference point

The switching frequency and the reference point are activated in the ServoManager: "Motor reference point" wizard

A reference point differing from the nominal data may also be entered on the wizard page displayed above.

Please activate "activate changing the reference point", then you may enter the new reference velocity as well as the new reference current.

Motor reference point

A reference point differing from the nominal data may also be entered on the wizard page displayed above.

Please activate "activate changing the reference point", then you may enter the new reference velocity as well as the new reference current.

External Moment of Inertia

The external mass moment of inertia is set against the moment of inertia of the rotor to form the total moment of inertia. The total moment of inertia is used for the controller design.

If you do not know or have only a vague knowledge of the external mass moment of inertia, the mass inertia can be determined via the load identification.

Configuration of an unknown external mass inertia:

The load identification is activated in the ServoManager: Wizard "External moment of inertia" "unknown: Using default values".


The correct values can be determined later via the load identification!

Limit and monitoring settings

On the "limit and monitoring settings" wizard page, you can set among others the current and velocity limits in % of the nominal values. The nominal values are

motor parameters resulting from the motor library or from shifting the reference point on the "motor reference point" wizard page.

Limit and Monitoring Settings wizard page:



1: Current (Torque) Limit

2: Velocity limit

Asynchronous motors

In this chapter you can read about:


Type specification plate data 193
 Replacement switching diagram - data for a phase..... 193
 Slip Frequency 194
 Saturation behavior 195
 Cut-off frequency for the field weakening range 195
 Rotor time constant 196
 Determination of the commutation settings 196
 Asynchronous motors: Extension of the controller structure..... 196

Type specification plate data

On the 2nd. wizard page of the Compax3 MotorManager, the type specification plate data must be entered.

Replacement switching diagram - data for a phase

This data can be obtained from the manufacturer or be determined by measurement.



U1:	Nominal phase voltage
R1:	Stator leg resistance
$X1\sigma=2\pi fL1\sigma$:	Leak reactance (for f=50Hz mains frequency)
L1 σ :	Stator leakage inductance
$X_n=2\pi fL_n$:	Main reactance (for f=50Hz mains frequency)
LH:	Main field inductance
$X2\sigma'=2\pi fL2\sigma$:	Referenced leak reactance (for f=50Hz mains frequency)
L2 σ :	Rotor leak inductance
R_2' :	Referenced carriage resistance
I_{mR} :	Magnetization Current

Slip Frequency

The slip frequency is stated in [Hz electrical] or in [%] and can be determined as follows

$$f_2[\text{mHz (electrical)}] = (f_s \cdot 60 - N_{\text{Nominal}} \cdot P/2) / N$$

$$f_2[\text{mHz}(el.)] = \frac{f_s \cdot 60 - N_{\text{Nenn}} \cdot \frac{P}{2}}{f_s \cdot 60} \cdot f_s \cdot 1000 = \left(f_s - N_{\text{Nenn}} \cdot \frac{P}{120} \right) \cdot 1000$$

$$f_2[\text{Pr omille}] = \frac{f_s \cdot 60 - N_{\text{Nenn}} \cdot \frac{P}{2}}{f_s \cdot 60} \cdot 1000$$

$$\frac{f_s \cdot 60 \cdot 2}{N_{\text{Nenn}}}$$

Whereas P = value before the point of the term è

f_s : Synchronous nominal frequency (dimensioning base)


N_{Nom} : Nominal speed in rpm

f_2 : Slip frequency in mHz (electrical)

Saturation behavior

The saturation of the main field inductance can be considered with the help of the following characteristic.

Activate the "consider saturation values" checkbox.



1) Nominal point in the basic speed range


Lhmax: max. main field inductance

Sbeg: Beginning of Saturation

Send: End of Saturation

Cut-off frequency for the field weakening range

The statement of the cut-off speed defines the beginning of the field weakening operation. From the cut-off speed on, the magnetization current and thus the force constant of the motor are reduced inversely proportional to the speed; the motor is operated in the field weakening range. In the field weakening range, the shaft power produced remains constant.



1: Basic speed range

2: Field weakening range

Rotor time constant


If the value of the rotor time constant is not known, it can be approximated automatically.

Determination of the commutation settings

On the last wizard page of the Compax3 MotorManager, the commutation settings (feedback direction reversal and commutation direction reversal) can be determined automatically.

Asynchronous motors: Extension of the controller structure

Structure of the magnetization current controller and determination of the slip frequency:



4.4.3.3 Automatic controller design

In this chapter you can read about:

Dynamics of a control	197
Cascade control	203
Rigidity	204
Automated controller design	207
Controller coefficients	208

Dynamics of a control


In this chapter you can read about:

Structure of a control	197
Oscillating plant	197
Stability, attenuation	197
Velocity, bandwidth	198
Setpoint and disturbance behavior of a control loop	201
Response	203
Limitation behavior	203

A change in the input value of a dynamic transmission element causes a change of its output value. The change of the output value is however not immediately effective, but takes a certain time, the transient response. The course of the transient response is characteristic for certain kinds of transmission behavior.

For this reason, a complete description of the transmission properties of a control comprises the stationary behavior (all setpoint, actual and disturbance values in settled state), as well as the dynamic behavior.

Structure of a control



The basic task of a control is the generation and maintaining of a desired state or sequence in spite of interfering disturbances. It is essential that the effects of the disturbances are balanced with the correct force and at the correct time. In the above figure, the setpoint value W represents the desired state and the disturbance value Z represents the interfering disturbance. The actual value X represents the generated and maintained state.

Oscillating plant

Oscillating control paths are control paths that respond with attenuated or unattenuated oscillation to an abrupt change in the setpoint value. Part of this class are for instance:

- ◆ Linear actuators with toothed belts, as a toothed belt represents an elasticity.
 - ◆ A mechanic shaft with an external mass moment of inertia, as the shaft represents an elasticity due to its torsional properties.
- In general this kind of elasticity is due to a high ratio between J_{Load}/J_{Motor} , as the shaft is normally not designed for this high external load and which may lead to a considerable distortion.

Stability, attenuation

In this chapter you can read about:

Stability problem in the high-frequency range:	198
Stability problem in the low-frequency range:	198


In general, two stability problems may occur in a servo drive control:

Stability problem in the high-frequency range:


The "control structure" figure shows that the reverse effect in the control loop (negative feedback) is a prerequisite for the functioning of a control system. Due to the delay in signal transmission, the effect of the negative feedback is diminished or even compensated. The reason is that the corrective measures of the controller are also delayed in the event of delayed signal transmission. This results in a typical oscillating course of the control variable. In the worst case, the deviation of the control variable and the effect of the corrective measures get in phase, if the delays reach a defined value. The negative feedback passes into positive feedback. If the product of the gain factors of all control loop components is higher than 1, the oscillation amplitude will continually rise.

In this case the control loop is unstable. In the total gain of 1 the oscillation keeps its amplitude and the control loop is within the limits of stability. The transient response can be characterized by the attenuation and the transient time (velocity).


Step response of a stable controller and of a controller approaching the stability limit



Rugged
Well attenuated



Rugged
Poorly attenuated




Stability limit
not attenuated

W: Setpoint value
x: Actual value

Stability problem in the low-frequency range:

In this case the controller was set for a very inert control path, while the actual control path is much more dynamic. The controller reacts to a disturbance variable with a much too strong corrective measure so that the disturbance variable is overcompensated and even an increasing oscillation may be the result. In this case the mechanic system of the control path may be destroyed.

Velocity jerk response (low-frequency stability limit)




1: Setpoint speed value
2: Actual speed value

Velocity, bandwidth


In this chapter you can read about:

P-TE - Symbol 199
 Step response of a delay component 199
 Approximation of a well-attenuated control loop 199
 Frequency response of the P-TE component (value and phase) 201

A well attenuated control loop can, under certain conditions, be approximated in order to simplify the controller design with a first order delay component (P-TE component) with the replacement time constant TE and the total gain Kp. A P-TE component represents a first order delay component and is a simple dynamic basic component.

P-TE - Symbol**Step response of a delay component**

Step response of a first order delay component with $K_p=1$ and $T_E=2.0s$



T: Tangent

S: Input jerk

P-TE: Output value of the P-TE component

TE: Time constant of the P-TE component


The definition of the delay time constant is displayed in the above figure. The time of intersection of the tangent and the jerk function itself is by definition the delay time constant (called filter time constant for filters) of a P-TE component. At this point in time the value of the step response is approx. 63% of the final value. In practice the step response corresponds, for instance, to the voltage charge curve of a capacitor.

Approximation of a well-attenuated control loop

The approximation of a well-attenuated control loop is based on the sameness of the control surface of the ideal first order delay component (P-T1 component) and the approximated system (P-TE component).


The control surface is a measure for the velocity of a system and is defined in the following figure. If the surface of the approximated system corresponds to the surface of the ideal system, the approximated system can be described, up to a certain frequency, with the transmission function of the P-T1 component.

Determination of the control surface from the transmission behavior of a P-TE component.




The velocity of a dynamic system can also be described in the frequency range. In the frequency range, the system behavior is analyzed to sinusoidal inputs signals of different frequencies (frequency response).

Input and output signals of a dynamic transmission component at a defined frequency $f=f_1$



The bode diagram represents the behavior of a dynamic system (in our case of the P-TE component) against the input signal frequency with respect to amplitude and phase.

Frequency response of the P-TE component (value and phase)



$$f_0 = \frac{1}{2\pi \cdot T_E} = 0,0795 Hz$$

The cut-off frequency is the frequency where the input signal is attenuated by 3dB (-3dB attenuation). The phase shift between the output and the input is -45° at this frequency.

Precisely this cut-off frequency is called the bandwidth of a control loop.

Setpoint and disturbance behavior of a control loop


In this chapter you can read about:

Demand behavior201
 Disturbance behavior202
 Test functions202
 Characteristics of a control loop setpoint response202

The setpoint behavior is the behavior of the control loop for the setpoint variable W. We assume that the disturbance variable Z=0.

The disturbance behavior describes the behavior of the control loop for disturbance variable Z. In this case, we assume, in analogy to the setpoint behavior, that the setpoint variable W=0.

Demand behavior




T_{sr} :	Response time. (Time elapsing until the control variable reaches one of the $\pm 5\%$ tolerance limits for the first time)
T_s :	Settling time. (Time elapsing until the control variable ultimately enters the $\pm 5\%$ range)
V_m :	maximum overshoot width
1	Tolerance range $\pm 5\%$
2	Setpoint value

Response

The response of the controller is the behavior of the actual value with respect to the calculated profile of the setpoint generator. The kinematic status variables, speed, acceleration and jerk are fed into the cascade as feedforward signals. The feedforward signals work with calculated factors and contribute to an improved contour constancy due to the minimization of the following error.

Compax3 servo controller structure



- x: Position actual value
- x_w: Setpoint position value
- a_w: Acceleration setpoint value
- n: Actual (rotational) speed
- n_w: Velocity setpoint value
- i: Actual current value
- j_w: Jerk setpoint value

Limitation behavior

Each control variable is limited by the control (actuating) element. If the control variable demanded by the controller is within the linear range (without limitation), the control loop shows the behavior defined by the design. If the controller demands however a higher control variable than permitted by the limitation, the control variable is limited and the controller slows down.

Hint You should therefore make sure that the control variable (output) of the controller does not remain within the limitation or only for a very short time.


Cascade control

In this chapter you can read about:

- Structure of a cascade control 204
- Cascade structure of Compax3..... 204

In drive technology, a cascading structure with several controllers (normally 3) is often used. This improves the control behavior. For this, additional sensors must be fixed within the control path. You will get the structure of a cascade control.

Structure of a cascade control




- W1 Setpoint value (setpoint) for the superposed controller 2
- W2 Setpoint value (setpoint) for the subordinate controller 1
- X2: Actual variable (actual value) for controller 2
- X1: Actual variable (actual value) for controller 1

The cascade control offers the following advantages:

- ◆ Disturbances occurring within the control path, can be compensated in the subordinate control loop. Therefore they must not pass through the entire control path and are thus compensated earlier.
- ◆ The delay times within the path can be reduced for the superposed controller.
- ◆ The limitation of the intermediate variables can be made by the control variable limitation of the superposed controller rather easily.
- ◆ The effects of the non-linearity for the superposed controllers can be reduced by the subordinate control loops.

In the Compax3 servo drive, a triple cascade control is implemented with the following controllers - position controller, velocity controller and current controller.

Cascade structure of Compax3



Rigidity

In this chapter you can read about:

Static stiffness	204
Dynamic stiffness	205
Correlation between the terms introduced.....	206

The stiffness of a drive represents an important characteristic. The faster the disturbance variable can be compensated in the velocity control path and the smaller the oscillation caused, the higher the stiffness of the drive. With regard to stiffness, we distinguish static and dynamic stiffness.

Static stiffness

The static stiffness of a direct drive is comparable with the spring rate D of a mechanical spring, and indicates the excursion of the spring in the event of a constant interference force. It is the ratio between the constant force F_{Dmax} of the motor and a position difference. Due to the I term in the velocity controller, the static stiffness is therefore infinitely high in theory, as the I term is integrated until the control difference vanishes. In a digital control the static stiffness is above all limited by the finite resolution of the position signal (the error must be at least one quantization step, so that it can be detected by the reading system) and by numerical resolution. Additional effects are for instance mechanical stiffness of the mechanic components in the control path (e.g. load connection, guiding system) as well as measurement errors of the measurement system.

Dynamic stiffness

In this chapter you can read about:

Traditional generation of a disturbance torque/force jerk.....205
 Electronic simulation of a disturbance torque jerk with the disturbance current jerk.....205
 Disturbance jerk response206


The dynamic stiffness is described by the ratio between the change in load torque or in load force and the resulting position deviation (following error):

$$\frac{-\Delta M_L}{\Delta x}$$

The higher this ratio (=dynamic stiffness), the higher the necessary change is load torque in order to generate a defined following error.

The dynamic stiffness can be acquired from the disturbance jerk response.

Traditional generation of a disturbance torque/force jerk




In settled state of the control, the motor force F_M corresponds exactly to the load force $F_G = m \times g$.

If the cord is cut through, the load force is eliminated abruptly and the controller must first of all settle to the new situation.

In order to simulate this load jerk electronically, a disturbance current jerk is fed to the Compax3 as a variable proportional to the disturbance torque at the velocity controller output.


Electronic simulation of a disturbance torque jerk with the disturbance current jerk



Feeding in of a disturbance current jerk, which corresponds to a disturbance torque jerk.

The maximum amplitude and the settling time of the following error decline with rising dynamic stiffness. The settling behavior of the following error is furthermore a measure for the attenuation and the bandwidth of the control.

Disturbance jerk response



- 1: Compensation torque of the controller
- 2: Simulated disturbance torque
- 3: Actual speed
- 4: Following error
- 5: Settling Time

Correlation between the terms introduced

The introduced terms:

- ◆ Stability
- ◆ Damping
- ◆ Velocity
- ◆ Bandwidth
- ◆ Setpoint and disturbance behavior
- ◆ Control variable limitation
- ◆ Replacement time constant
- ◆ Rigidity

are related as follows:

- ◆ A well-attenuated control features a stable control behavior.
- ◆ The velocity of a control loop is a measure for the reaction rate of the controller to the disturbance variable (disturbance behavior) as well as to the setpoint variable (setpoint behavior).
- ◆ The faster the control, the higher its bandwidth.
- ◆ The term replacement time constant is an approximation and is only valid in a defined scope¹. In this scope, the control is always stable and well-attenuated.
- ◆ If the controller does not work in the linear range, but the control variable of the controller is within the limitation, the control slows down and the control difference rises.
- ◆ The stiffness represents the bandwidth of the velocity control. The higher the stiffness value of the velocity control, the higher the bandwidth of the velocity controller and the stiffer the drive.

Automated controller design

In this chapter you can read about:

Step response of the velocity loop depending on the optimization parameter "attenuation" and "stiffness"207
 D-term207
 Position loop.....207

The controller design takes place after the configuration immediately before the configuration download into the device. The controller coefficients are preassigned according to the design method of cross-ratios so that a stable control is achieved.

The automatic, robust controller design calculates the P and I terms of the individual controllers (current, velocity, position) on the basis of the configured motor and application parameters.

Please observe:

Faulty motor and application parameters may lead under certain circumstances to instable controllers.

The controller parameters are not directly available for the optimization. Instead, they can be changed with the aid of the following optimization parameters:


- | | |
|--|--------------------------------------|
| Optimization of the current controller dynamics: | ◆ Current loop bandwidth in % |
| | ◆ "Attenuation of current loop" in % |
| Optimization of the velocity loop dynamics: | ◆ "Stiffness" in % |
| | ◆ "Attenuation" in % |
| | ◆ Velocity loop - "D" term in % |

The bandwidth parameter states the actually effective % of the calculated default velocity. The default bandwidth of the current controller is fixed to approx. fGR=531Hz. In reverse this signifies that each motor delivers the same step response. The prerequisite is, of course, that you keep out of the control signal limitation (voltage limitation). The attenuation characterizes the controller's tendency to oscillate with respect to an excitation signal (see below). The stiffness (of the velocity loop, corresponds to the bandwidth of the current loop) describes the velocity of the velocity loop (see below).

Step response of the velocity loop depending on the optimization parameter "attenuation" and "stiffness"

Attenuation = 100%

Stiffness = 100%



- 1: Setpoint value
- 2: Actual value (stiffness = 200%)
- 3: Actual value (stiffness = 100%)
- 4: Actual value (stiffness = 50%)
- 5: Actual value (attenuation = 500%)
- 6: Actual value (attenuation = 100%)
- 7: Actual value (attenuation = 50%)

D-term

The D-term parameter (of the velocity loop) activates existing control oscillations of drives with elastic coupling (e.g. toothed belt drives). The D-term is not automatically designed and must therefore be set manually.

Position loop

The position controller is automatically adapted depending on the stiffness of the velocity loop.

Controller coefficients

In this chapter you can read about:

Velocity Loop P Term	208
D-term of the KD velocity controller	208
P-term KV position loop	208

Dependence of the controller coefficients from the optimization objects

The controller coefficients are influenced by the optimization objects such as "stiffness" and/or "attenuation". The dependency is displayed below.

I-term KI in the velocity loop

$$K_I = \frac{St[\%]}{100 \cdot T_{EGD}}$$

$$\Rightarrow K_I \sim St$$

T_{EGD} : The replacement time constant of the closed velocity loop.
 St Rigidity

Velocity Loop P Term

$$K_{PV} = \frac{St[\%]}{100 \cdot T_{EGD}} \cdot \frac{Tm[\%]}{100} \cdot T_N \cdot \frac{100}{EMK[\%]} \cdot \frac{30 + 0,14 \cdot Dp[\%]}{20}$$

$$\Rightarrow K_{PV} \sim St \wedge K_{PV} \sim Tm/EMK \wedge K_{PV} = f_{LIN}(Dp)$$

T_{EGD} : The replacement time constant of the closed velocity loop.
 T_N : The mechanical integration time constant of the motor.
 $f_{LIN}()$: Linear function (straight) between attenuation and KPV
 Tm Moment of Inertia
 St Rigidity
 Dp Damping

D-term of the KD velocity controller

$$K_D = \frac{Dterm[\%]}{100} \cdot K_{D_100\%}$$

$$\Rightarrow K_D \sim Dterm$$

$KD_100\%$ The defined 100% coefficient

$Dterm$ D term

P-term KV position loop

$$K_V = \frac{St[\%]}{100 \cdot T_{EGD}} \cdot \frac{20}{30 + 0,14 \cdot Dp[\%]} \cdot T_X$$

$$\Rightarrow K_V \sim St[\%] \wedge K_V = f_{LIN}(1/Dp[\%])$$

T_{EGD} : The replacement time constant of the closed velocity loop.
 T_X : The position integration time constant of the motor.
 St Rigidity
 Dp Damping
 $f_{LIN}()$: Linear function (straight) between 1/attenuation and KV

4.4.3.4 Setup and optimization of the control


In this chapter you can read about:

Standard 209
 Advanced 215
 Commissioning window 230
 Proceeding during controller optimization 232

For the setup and optimization of the control loops, the optimization window is available.

The Compax3 control functionality is divided into 2 sections, standard and advanced; the advanced functionality does however incorporate the entire standard functionality. The switching can be made in the optimization window.

Switching between standard and advanced




Standard

In this chapter you can read about:

Standard cascade structure 210
 Standard optimization parameters 211
 Control signal limitations 211
 Feedforward channels 213
 Control signal filter / filter of actual acceleration value 215

Standard cascade structure



The framed objects are coupling objects for Compax3 - Compax3 coupling via HEDA.

Please note that the corresponding controller components must be deactivated for the coupling:

When coupling the velocity (O2219.14): O100.1 or O100.2=1063 (see object description)

When coupling via current (O2220.2): O100.1 or O100.2=1031 (see object description)

O100.1 is only copied into O100.2 upon activation of the controller, the controller can be influenced in active state with the aid of O100.2

Caution! Changing objects O100.1 and O100.2 may cause the control to be deactivated!
Protect dangerous areas!

External command value

During external setpoint specification, please respect the structure images for electronic cams or gearboxes for **signal filtering with external setpoint specification** (see on page 241) !

Complementary structure for **load control** (see on page 164).

Compax3 **controller structures** (see on page 210, see on page 216, see on page 217).

Symbol	Description
	Proportional term signal is multiplied with K_p
	First order delay component (P-T1 term)
	Integration block (I-block)
	PI-block
	Limitation block (signal limitation)
	Notch filter (band elimination filter)
	Addition block
blue description	Optimization objects (simple pointer line)
red description	Status objects (pointer line with vertical stroke)

Standard optimization parameters

Overview optimization objects		
Optimization object	Value	Unit
Reference reaction (Feed-Forward)		
Velocity feed-forward [2010.1]	100	%
Acceleration feed-forward [2010.2]	100	%
Current feed-forward [2010.4]	100	%
Jerk feed-forward [2010.5]	100	%
Setpoint-/Disturbance reaction (Dynamics)		
Stiffness [2100.2]	100	%
Damping [2100.3]	100	%
Velocity loop - "D" term [2100.7]	0	%

The above figure shows the parameters for the standard group. With the aid of these parameters, you can optimize the standard cascade structure.

Control signal limitations

In this chapter you can read about:

- Limitation of the setpoint velocity 212
- Limitation of the setpoint current 212
- Limitation of the control voltage 212

The cascade structure shows that a limitation block is available in the control signal sector of each controller. The limitations of the position and velocity loops are calculated from the set limitations in the configuration and the motor parameters of the selected motor.

Limitation of the setpoint velocity

Limitation of the setpoint velocity in the control signal sector of the position loop:
This limitation value is calculated from the maximum mechanical velocity of the motor and the set value in the configuration in % of the nominal velocity. The smaller of the two values is used for the limitation.

Example

MotorManager

maximum mechanical velocity of the motor: $n_{max}=3100\text{rpm}$
Rated speed of the motor: $n_N=2500\text{rpm}$

C3 ServoManager

Max. Operating velocity: $n_{bmax}=200\%$ of n_N
 $\Rightarrow 5000\text{rpm}$

Velocity limitation value = **3100rpm**
 $MIN(n_{max}, n_{bmax} * n_N / 100) =$

Limitation of the setpoint current

Limitation of the setpoint current in the control signal sector of the velocity loop:
This limitation value is calculated from the device peak current, the pulse current of the motor and the set value in the configuration in % of the nominal current. The smaller of the three values is used for the current limitation.

Example

Device

C3 S063 V2 F10 T30 M00 device peak current: $I_{Gmax}=12.6A_{rms}$

MotorManager

Rated current of the motor: $I_N=5.5A_{rms}$
Peak Current: $I_{imp}=300\%$ I_N
 $\Rightarrow 16.5A_{rms}$

C3 ServoManager

Current (Torque) Limit: $I_{bmax}=200\%$ of I_N
 $\Rightarrow 11A_{rms}$

Current limitation value = **11A_{rms}**
 $MIN(I_{Gmax}, I_{imp} * I_N / 100, I_{bmax} * I_N / 100) =$

Limitation of the control voltage

Limitation of the control voltage in the control signal sector of the current loop:
This limitation is fixed and cannot be influenced by the user. The limitation value depends on the DC voltage of the device.

Please note!

In the event of highly dynamic motion cycles it is necessary to make sure not to enter the control signal limitation (or, if so only for a very short time) as the drive is then not in the position to follow the set dynamics due to the slow drive physics and the limited control signal range.

Feedforward channels

In this chapter you can read about:

Influence of the feedforward measures	213
Motion cycle without feedforward control	214
Motion cycle with feedforward measures	214

The feedforward channels are used for the specific influence of the guiding behavior of a control. The calculated and evaluated status variables are coupled into the corresponding places within the controller cascade. In practice, the feedforward control offers the following advantages:

- ◆ Minimal following error
- ◆ Improves the transient response
- ◆ Gives greater dynamic range with lower maximum current

The Compax3 servo drive disposes of four feedforward measures (see in the standard cascade structure):


- ◆ Velocity Feed Forward
- ◆ Acceleration feed-forward
- ◆ Current feed-forward
- ◆ Jerk feed-forward

The above order represents at the same time the effectiveness of the individual feedforward measures. The influence of the jerk feedforward may be, depending on the profile and the motor, negligibly small.

Please note! But the principle of feedforward control fails in limiting the motor current or the motor speed during the acceleration phase!


Influence of the feedforward measures

Following error minimization by feedforward control / course of the setpoint generator signals




- xws: Position setpoint value of the setpoint generator
- nws: Velocity setpoint - setpoint generator
- aws: Acceleration setpoint value setpoint generator
- rws: Jerk setpoint value setpoint generator

Motion cycle without feedforward control




Motion cycle with feedforward measures


Velocity feedforward




Velocity and acceleration feedforward



Velocity, acceleration and current feedforward



Velocity, acceleration, current and jerk feedforward



Control signal filter / filter of actual acceleration value

The filters in the Compax3 firmware are implemented as P-T1 filters (first order deceleration component see chapter 0 (see on page 241, see on page 241, see on page 242).)

The two "control signal filter (velocity loop)" (Object 2100.20) and "acceleration value filter" (Object 2100.21) are set in μs . The value range for these filters is 63... 8 300 000 μs . Depending on the replacement time constant of the closed velocity loop, we can make recommendations for the setting.

Setting recommendation for "control signal filter (velocity loop)":

$O2100.20 \leq O2210.17[\mu\text{s}] / 5$ for $O2210.17 \geq 10\ 000\mu\text{s}$

$O2100.20 \leq O2210.17[\mu\text{s}] / 3 - 1333\mu\text{s}$ for $4000\mu\text{s} \leq O2210.17 < 10\ 000\mu\text{s}$

$O2210.20 = 0$ for $O2210.17 < 4000\mu\text{s}$

O2210.17: Object replacement time constant of the velocity loop in μs .

O2100.20: Object control signal filter (velocity loop) in μs .

Please note!


It cannot be excluded that the filter may have a destabilizing effect even though set according to the above recommendation. In this case the filter time constant must be reduced.

Advanced

In this chapter you can read about:

Extended cascade (structure variant 1).....	216
Extended cascade structure (structure variant 2 with disturbance variable observer).....	217
Optimization parameter Advanced.....	219
EMC feedforward.....	219
Motor parameters	219
Filter "External Command Interface".....	219
Voltage decoupling.....	220
Load control.....	220
Luenberg observer	220
Commutation settings of the automatic commutation.....	222
Notch filter	226
Saturation behavior	228
Control measures for drives involving friction.....	229

Extended cascade (structure variant 1)



The framed objects are coupling objects for Compax3 - Compax3 coupling via HEDA.

Please note that the corresponding controller components must be deactivated for the coupling:

When coupling the velocity (O2219.14): O100.1 or O100.2=1063 (see object description)

When coupling via current (O2220.2): O100.1 or O100.2=1031 (see object description)

O100.1 is only copied into O100.2 upon activation of the controller, the controller can be influenced in active state with the aid of O100.2

Caution! Changing objects O100.1 and O100.2 may cause the control to be deactivated!
Protect dangerous areas!

External command value


During external setpoint specification, please respect the structure images for electronic cams or gearboxes for **signal filtering with external setpoint specification** (see on page 241) !

Complementary structure for **load control** (see on page 164).

Compax3 **controller structures** (see on page 210, see on page 216, see on page 217).

Symbol	Description
	Proportional term signal is multiplied with K_p
	First order delay component (P-T1 term)
	Integration block (I-block)
	PI-block
	Limitation block (signal limitation)
	Notch filter (band elimination filter)
	Addition block
blue description	Optimization objects (simple pointer line)
red description	Status objects (pointer line with vertical stroke)

Extended cascade structure (structure variant 2 with disturbance variable observer)



The framed objects are coupling objects for Compax3 - Compax3 coupling via HEDA.

Please note that the corresponding controller components must be deactivated for the coupling:

When coupling the velocity (O2219.14): O100.1 or O100.2=1063 (see object description)

When coupling via current (O2220.2): O100.1 or O100.2=1031 (see object description)

O100.1 is only copied into O100.2 upon activation of the controller, the controller can be influenced in active state with the aid of O100.2

Caution! Changing objects O100.1 and O100.2 may cause the control to be deactivated! Protect dangerous areas!

External command value

During external setpoint specification, please respect the structure images for electronic cams or gearboxes for **signal filtering with external setpoint specification** (see on page 241) !

Complementary structure for **load control** (see on page 164).

Compax3 **controller structures** (see on page 210, see on page 216, see on page 217).

Symbol	Description
	Proportional term signal is multiplied with K_p
	First order delay component (P-T1 term)
	Integration block (I-block)
	PI-block
	Limitation block (signal limitation)
	Notch filter (band elimination filter)
	Addition block
blue description	Optimization objects (simple pointer line)
red description	Status objects (pointer line with vertical stroke)

Optimization parameter Advanced

Overview optimization objects		
Optimization object	Value	Unit
Reference reaction (Feed-Forward)		
Velocity feed-forward [2010.1]	100	%
Acceleration feed-forward [2010.2]	100	%
Current feed-forward [2010.4]	100	%
Jerk feed-forward [2010.5]	100	%
Setpoint-Disturbance reaction (Dynamics)		
Stiffness [2100.2]	100	%
Damping [2100.3]	100	%
Moment of Inertia [2100.4]	100	%
Velocity loop - "D" term [2100.7]	0	%
Filter - Actual velocity [2100.5]	100	%
Filter 2 - actuating signal (velocity controller) [2100.10]	0	us
Filter - Actual acceleration [2100.6]	0	%
Filter 2 - Actual acceleration [2100.11]	0	us
Current loop - Bandwidth [2100.8]	50	%
Current loop - Damping [2100.9]	100	%
Observer		
Time Constant [2120.1]	0	us
Filter - Observed disturbance [2120.5]	1000	us
Enable Disturbance Compensation [2120.7]	0	
Automatic commutation		
Ramp time [2190.1]	100	%
Starting current [2190.2]	20	%
Motion threshold [2190.3]	100	%
Motion reduction [2190.4]	100	%
Filter external signal source		
Filter - Ext. velocity feed-forward [2011.1]	500	%
Filter - Ext. accel. feed-forward [2011.2]	500	%
Trackingfilter HEDA [2109.1]	0	500us
Filter setpoints		
Trackingfilter [2110.1]	1	500us
Filter velocity [2110.3]	0	%
Filter acceleration [2110.4]	0	%

Current controller

The current controller works with a P component in the feedback; this results in very low overshoot.

With the aid of object 2220.27 (Bit = "0"), it is possible to switch to P component in the forward path.

EMC feedforward

The EMC feedforward compensates the electromagnetically generated back e.m.f. of the motor U_{EMC} . This signal is proportional to velocity and is deduced from the setpoint velocity of the setpoint generator.

Motor parameters

Furthermore you can re-optimize the motor parameters inductance, resistance and EMC (or K_t) in the advanced mode. The $LdLqRatio$ parameter is the ratio of the smallest and the highest inductance value of the winding, measured during one motor revolution.

Filter "External Command Interface"

Signal filtering with external command value (see on page 241, see on page 241, see on page 242)

Voltage decoupling

In the current control path there is a velocity and current proportional voltage disturbance variable, which must be compensated by the current loop. Due to limited controller dynamics, this disturbance variable can not always be entirely compensated by the current loop. The influence of this disturbance variable may however be minimized by activating the voltage decoupling.

Load control

If a second position feedback is available for the acquisition of the load position, the load control can be activated.

For more detailed information on the load control see device help for T30/T40 devices in the setup chapter Compax3\\load control.

Luenberg observer**In this chapter you can read about:**

Introduction observer	220
Signal flow chart Luenberg observer	221

Introduction observer

A high signal quality of the actual signal value is of high significance in the control of the motor velocity n or the motor speed v . By means of oversampling and transmitter error compensation, a high-quality position signal can be produced for speed determination. As a rule the motor speed is determined by numeric differentiation of the motor position. In this case the quantization noise Q_{vD} of the digital speed signal depends on the quantisation Q_x of the position signal and the sampling time T_{AR} of the digital control loop:

Quantization speed signal Q_{vD}

$$Q_{vD} = \frac{Q_x}{T_{AR}}$$

The quantisation of the speed signal is inversely proportional to the sampling time T_{AR} . Hence the demands for the lowest possible sampling time and the minimum quantization noise oppose each other in the determination of speed by numeric differentiation. The noise superimposed by the digital speed signal may be reduced by the low-pass filter, however this is always at the cost of the stability margin of the digital control loop. An alternative method is to determine the speed by integration of the acceleration. The dependence of the quantisation noise Q_{vD} of the digital speed signal on the quantisation Q_x of the position signal and the sampling time T_{AR} of the digital control loop is shown by the following correlation.


Quantization speed signal Q_{vI}

$$Q_{vI} = Q_a \cdot T_{AR}$$

The observer technology offers the advantage that the velocity can be calculated with the aid of integration. The idea of the observer principle is to connect a mathematical model of the control path parallel to the section observed and with the same transfer behavior. In this case, the controller also has the intermediate variables (state variables) of the control path available. However in the presence of model deviations (in structure or parameters), different signal values occur between the model and the control path. For this reason, the technique cannot be employed in this way in practice. However, the model contains the measurable output signal of the control section as a redundant quantity. By comparing the two variables, a tracking control can be used to adapt the model state variables to the state variables of the control path. As the model deviations have become minor in this case due to the simple mechanical drive train, the observer now has an

efficient aid available to increase the signal quality. Increase in signal quality in the observer means that the noise components decrease, and the dynamics improve as the observed speed is feedforward-controlled undelayed by the current and is not just calculated delayed from the position signal using simple differentiation.

Signal flow chart Luenberg observer



- I(t): Torque-forming motor current
- K_T: Torque constant
- M_L(t): External disturbance torque
- J_{total}: Total mass moment of inertia (motor + load)
- a(t): Acceleration
- n(t): Velocity
- x(t): Position
- Index b: Observed signal quantities
- h₀...h₂: Controller coefficients of the tracking controller

The figure shows that an additional I element is connected for interference compensation to correct external disturbance forces in the observer. Therefore the speed and the acceleration observed are statically precise. The same applies to the output of the integrator in the tracking controller which is a statically precise determination of an external interference torque M_L. For this reason, the I component is not required in the speed controller for some applications, and the entire control can be set up as a state cascade control. This increases the bandwidth of the speed and position controlled member by factor 2. As a consequence, the interference stiffness of the drive and the following error behavior improve.

Here the quantization of the speed signal is proportional to the sampling time T_{AR}, hence there is no longer any conflict between the requirements for minimum sampling time and minimum quantization noise. For the integral velocity acquisition, the motor current variable, which is proportional to the acceleration, can be used. This approach is particularly advantageous in direct drive engineering; due to the absence of a mechanical drive train, there is a very good

match between the mathematical model of the observer and the real physical control section in the fundamental frequency range of the control. This applies in particular to direct drive systems with fixed moving masses, as otherwise the mismatch between model and the physical drive system has a destabilizing influence on the transfer behavior of the speed control. A remedy is to increase the observer dynamics, however this increases the noise of the observed signals. Therefore in the case of variable moving masses a compromise has to be found between the dynamics of the observer and the maximum stiffness of the drive.

Commutation settings of the automatic commutation

In this chapter you can read about:

Display of the commutation error in incremental feedback systems	223
Prerequisites for the automatic commutation	224
Course of the automatic commutation function	224
Other	226

Permanently excited synchronous motors can only be operated with an absolute feedback system (at least for electric motor rotation). The reason is the necessary commutation information (position assignment of the magnet field generated by the motor to the motor magnets). Without the commutation information, there is inevitably the possibility of a positive feedback between position and velocity loop ("running away" of the motor) or of bad motor efficiency (reduced force constant).

Digital hall sensors are the most common aid to prevent this. Due to the mechanical design it is however impossible or very hard to integrate these sensors in some motors. The Compax3 automatic commutation function (in the F12 direct drive device) described below allows however to use incremental feedback systems without hall sensors.


The functionality implemented in the servo drive establishes the necessary reference between motor stator field and permanent magnetic field without additional aids.

The incremental feedback devices are, in contrast to absolute feedback devices, able to acquire relative distances. It is true that any position can be approached from a starting point, there would be however no consistency between these position values and a fixed virtual absolute system. Other than with an absolute feedback, the correlation between rotor and stator is lost if the position acquisition is switched off ("the position acquisition zero is lost"). When switching on, the actual position is randomly taken as zero. A commutation angle error can therefore absolutely not be excluded. Even a system adjusted before, would show an angular error, for example after a current failure. Therefore the angular error occurring randomly upon each new switching on must always be compensated in an incremental system.

Display of the commutation error in incremental feedback systems

$\Delta\varepsilon = 0$ (adjusted)

$\Delta\varepsilon \neq 0$ (not adjusted)



Rotor was turned in switched-off state.

blue: ideal position

red: unfavorable position

PM: magnetic flux of the permanent magnets

i_s : Current pointer

$\Delta\varepsilon$: Commutation error

i' : ideal position

i_q : Quadrature current (torque forming)

The automatic commutation function (AK) in Compax3 uses the position dependent sinusoidal torque course of permanently excited AC synchronous motors. If the motor windings are energized with DC voltage for instance, the motor develops a sinusoidal torque depending on the rotor position, which can be used for example by evaluating the resulting movement in order to determine the correct motor commutation.

The automatic commutation with movement in the Compax3 has the following properties:

- ◆ The motor movement occurring during the commutation is, with correctly parameterized function, very small. It is typically in the range smaller than 10° electrical revolution ($=10^\circ/\text{motor poles physically or } 10^\circ/360^\circ \cdot \text{motor pitch}$ for a linear motor).
- ◆ The precision of the acquired commutation angle depends on the external conditions, however lies normally in the range better than 5° electrical revolution.
- ◆ The time until the termination of the commutation acquisition is typically below 10s.

Prerequisites for the automatic commutation

- ◆ A movement of the motor must be permitted. The movement actually occurring depends greatly on the motor (friction conditions) itself, as well as on the load moved (inertia).
- ◆ Applications requiring a motor brake, i.e. applications where active load torques are applied at the motor (e.g. vertical actuator, slope) are not permitted.
- ◆ Due to the function principle, high static friction or load torques will deteriorate the result of automatic commutation.
- ◆ When performing automatic commutation, a motion of at least $\pm 180^\circ$ must be electrically possible (no mechanic limitation)! The implemented automatic commutation function with motion cannot be used for applications with limit or reversal switches.
- ◆ With the exception of missing commutation information, the controller/motor combination is configured and ready for operation (parameters correctly assigned for the drive/linear motor). Feedback direction and effective direction of the field of rotation must be identical (automatic commutation performed in the MotorManager).


Course of the automatic commutation function

If "automatic commutation with movement" is selected as source of commutation, the automatic commutation sequence runs once if the power stage is enabled. If the power stage is enabled or disabled afterwards, the automatic commutation will be left out. If an error occurs during the execution, the automatic commutation is aborted. A new "attempt to enable" the power stage will trigger a new automatic commutation.

Function principle of the automatic commutation with movement

The implemented method with movement is based on the sinusoidal dependence of the provided motor currents and the resulting movement on the effective commutation error. The acceleration performed by the motor (-> movement) in the event of constantly maintained current is a measure for the actual change in the commutation angle in the way that it disappears upon a change of exactly 0° and is, for other angles, the acceleration and its direction in dependence of the sign and value of the angular error ($-180^\circ \dots 180^\circ$).

Acceleration torque depending on the commutation error.




$\Delta\epsilon$:	Commutation error
$M/M_{\mu\alpha\xi}$	normalized acceleration torque

Searching for the torque maxima (phase 1)

If the sum of the actual and the estimated error angle is $\pm 90^\circ$ electrically, the motor torque is maximal for the provided current. If you gradually increase the provided motor current, the motor will, from a defined value on, surpass its friction torque and exceed a motion threshold defined by O2190.3:

Illustration of the first phase




- 1): Motion threshold O2190.3
- 2): Waiting for standstill
- O2190.2: Starting current

Latching of the motor (phase 2)

Here, the drive is brought to the position with the provided motor torque=0, where the angular error is either $\pm 180^\circ$ or 0° .

Current rise in the second phase.



- O2190.1: Rising time of latching current
- 1) Maximum current from controller or motor
- 2) Monitoring on 5° electrical movement
- 3) Monitoring on 60° electrical movement

Motion reduction:

It is possible, to considerably reduce the motor movement occurring during the fine angle search with the aid of the "motion reduction" parameter (O2190.4).

Please respect also that the acquired commutation result may be slightly worse than without this measure.


Hint As a current well above the nominal motor current is provided here, there may be saturation effects on iron core motors, which might lead to an instable current loop (-> highly frequent "creaking noises" during the automatic commutation). This can be avoided by activating the saturation characteristic line in the motor data.

Test for positive feedback (phase 3)

Here it is verified, if the motor performs a motion in the expected positive direction in the event of positive current in the torque maximum. The same motion threshold (defined via O2190.3) as in phase 1 is valid. The test is repeated several times.

A current course in ramp form is specified (target: minimum motion). The break between the tests varies with the current rise time O2191.1.

Illustration of the third phase



- 1): Waiting for standstill
- tp: Waiting for standstill

Other

- ◆ During the sequence (time according to parameterization >> 1s) the automatic commutation is externally visualized by a LED blinking code (green permanent and red blinking).
- ◆ Device errors will lead to an abort of the automatic commutation.
- ◆ During automatic commutation, no motion commands are accepted.
- ◆ The controller cascade entirely deactivated during automatic commutation, with the exception of the current loop.
- ◆ In multi-axis applications, the axes to be automatically commutated must be awaited (output of the MC_Power block must deliver "True")!
- ◆ The automatic commutation is only started if the drive is at standstill.
- ◆ After the occurring and acknowledgement of a feedback error or a configuration change of the feedback system, the automatic commutation must be performed again, as it might be that the position entrainment in the servo controller is interrupted (commutation information is lost).


Notch filter

In this chapter you can read about:

Effect of the notch filter 226
 Wrongly set notch filter 227
 Frequency response of the notch filter 227
 Parameterization by 3 objects 227

Notch filters are small-band band elimination filters which slope in a wedge form towards the center frequency. The attenuation of this center frequency is extremely high in most cases. With the aid of the notch filters it is possible to purposefully eliminate the effects of mechanical resonance frequencies. With this, the mechanical resonance point is not activated itself, but the excitation of this point of resonance is avoided by the control.


Effect of the notch filter



As can be seen in the figure, the notch filter is only useful in cases where the set frequency of the notch filter is exactly the same as the disturbing frequency. The notch filter as well as the resonance point are very narrowband. If the resonance


point does only minimally change (e.g. by changing the masses involved), it is not sufficiently activated by the notch filter.

Wrongly set notch filter



In the Compax3, two notch filters which are independent of each other are implemented.

Frequency response of the notch filter.



Center frequency = 500Hz

Bandwidth = 50Hz

Depth = 0.99 (-40dB)

Parameterization by 3 objects.

In this chapter you can read about:

Frequency filter 1 (O2150.1) / frequency filter 2 (O2150.4)	227
Bandwidth filter 1 (O2150.2) / bandwidth filter 2 (O2150.5)	228
Depth filter 1 (O2150.3) / depth filter 2 (O2150.6)	228

Frequency filter 1 (O2150.1) / frequency filter 2 (O2150.4)

This defines the frequency at which the notch filter attenuation is highest. In practice it shows that notch filters can only sensibly be used if the distance between the controller bandwidth (velocity loop) and the center frequency is long enough (at least factor 5). This permits to deduce the following recommendation:

$$O2150.x \geq \frac{5000000}{2\pi \cdot O2210.17[\mu s]}$$

x = 1 or x = 4

Obj2210.17: Replacement time constant of the velocity loop in μs .

Note: If this distance is too small, the stability of the control can be very negatively influenced!

Bandwidth filter 1 (O2150.2) / bandwidth filter 2 (O2150.5)

This defines the width of the notch filter.

The value refers to the entire frequency band, where the attenuation of the filter is higher than (-)3dB.

In practice it shows that even if there is enough distance towards the control, it can be negatively influenced by too high bandwidths (higher than 1/4 of the center frequency).

$$O2150.x \leq \frac{O2150.1/4}{4}$$

x = 2 or x = 5

Depth filter 1 (O2150.3) / depth filter 2 (O2150.6)

With this the size of the attenuation of the filter must be at the position of the center frequency. One stands here for complete attenuation (-∞ dB) and zero for no attenuation.

$$O2150.x = 1 - 10^{-\left(\frac{D[dB]}{20}\right)}$$

x = 3 or x = 6

D [dB]: The desired attenuation at the center frequency in dB

Saturation behavior


In this chapter you can read about:

Current jerk response 228
 Current jerk response with the activated saturation characteristic line..... 229

Saturation can be stated with the aid of current jerk responses at different current height.

Current jerk response

Current jerk response of a motor to 2 different currents (1Arms / 2Arms)




- 1) Actual current
- 2) Setpoint current

In the above figure we can see from the settling response that the drive shows a distinctive tendency to oscillate at doubled current. The saturation characteristic line, which is used to linearly reduce the P-term of the current loop depending on the current, helps against such a saturation behavior.

If you respect the saturation for the above example with the aid of the saturation characteristic line, the tendency to oscillate of the current loop can again be activated.

Current jerk response with the activated saturation characteristic line



The parameterization of the characteristic line is made in the MotorManager.

- Note:**
- ◆ In order to accept the changes in the MotorManager in the project, the entire configuration must be confirmed.
 - ◆ In order to make the changes from the MotorManager effective in the device, the configuration download must be executed.

Control measures for drives involving friction

In this chapter you can read about:


Deadband following error.....229
 Friction compensation.....230

Some drives, which involve much friction due to their guiding system, may show permanent oscillation at standstill. The transition between static friction (standstill) and kinetic friction (very low speed) is very steep. The controller can not longer follow the friction characteristic line at this position. The I-term integrates until the control variable pulls free the drive and the drive moves too far. This procedure is repeated in the opposite direction and a control oscillation occurs (so-called limit cycle). In order to eliminate this control oscillation, the following control functions were implemented:

- ◆ Deadband following error (Obj. 2200.20)
- ◆ Filter following error (Obj. 2200.24)
- ◆ Friction compensation (Obj. 2200.20)

Deadband following error

Deadband/filter following error in the position loop




The deadband does no longer supply a velocity setpoint value (zero) for the subordinate velocity loop at small following error. The integrator of the velocity loop stops integrating and the system comes to a standstill.

In order to prevent that the velocity loop is excited by the noise on the following error, the following error should be filtered before the deadband, which will lead, however, to delays in the position loop. The deadband to be set depends on the friction behavior (amplitude of the limit cycle) and on the noise on the following error (the noise must remain within the deadband).

Friction compensation

The activation of the friction compensation (end of the velocity loop)



The friction compensation helps the control to surmount static friction at low setpoint speeds. The non linear characteristic line is partly compensated by this and a smaller deadband can be chosen, which will increase the position accuracy. The amplitude of the friction compensation depends on the application and must be calculated if needed. If the value is set too high, corrective movements may result and the tendency to oscillate is increased.

Commissioning window

In this chapter you can read about:

Load identification.....	230
Setpoint generation	230

Commissioning window

With the aid of the setup window, the drive can be set up in a simple way.

Load identification

If you do not know the mass moment of inertia, it can be determined. For this, you click on the corresponding button (see setup window no. 13). After the following parameter entry, the identification can be started via the same button.

- ◆ For more detailed information on the load identification, see the device help, chapter "load identification".
- ◆ This measurement requires the correct EMC or torque constant value K_t .

Setpoint generation

In this chapter you can read about:


Internal setpoint generation	230
External setpoint generation	232

The setpoints for the control loops are provided in two different ways - internally or externally. The setpoint generation depends on the technology option of the device.

Internal setpoint generation

The internal setpoint generation can be used for the technology options >T10. In this case, the internal setpoint generator generates the entire motion profile with position, velocity, acceleration and jerk.

Motion profile at jerk-controlled setpoint generation



- x_w Position
- v_w Velocity
- a_w Acceleration
- j_w Jerk

The drive cannot move randomly through hard profiles, as certain physical limits exist for the acceleration ability due to the motor physics and the limitation of the control variable. You must therefore make sure that the set movement corresponds to the real physics of the motor and of the servo drive.

As a support you can take the following physical correlation.

The calculation of the physically possible acceleration

rotary drives

$$a [rps^2] = \frac{M_A [Nm] - M_L [Nm]}{2\pi \cdot J_{ges} [kgm^2]}$$

- M_A: Drive torque of the motor
- M_L: Load torque of the motor
- J_{total}: entire mass moment of inertia
- a: possible acceleration

Linear drives

$$a [m/s^2] = \frac{F_A [N] - F_L [N]}{m_{ges} [kg]}$$

- F_A: Drive force of a linear motor
- F_L: Load force of a linear motor
- m_{total}: Total mass of a linear motor

The generation of the setpoint profile is jerk-controlled and jerk-limited by the specification of the jerk.



In practice, jerk-limited setpoint generation is important if the items to be moved must be handled gently. In addition, the service life of the mechanical guiding system will be extended. A separate setting of jerk and slope of the deceleration phase also permits overshoot-free positioning in the target position. For this reason, it is common practice to use higher values for acceleration and jerk in the acceleration phase than in the deceleration phase. In consequence a higher cycle rate can be achieved.

An additional important reason for the jerk limitation is the excitation of higher frequencies due to the too high jerk in the power density spectrum of the velocity function.


Jerk=1000°/s³

Jerk=1000000°/s³

Time function:



Time function and power density spectrum of Compax3 setpoint generator with different jerk settings



Power density over the frequency

The profile can be simply calculated and displayed for control purposes.

External setpoint generation

During external setpoint generation, the necessary feedforward signals are calculated from the external setpoint with the aid of numerical differentiation and final filtering.

Hint For more detailed information on the external setpoint generation see device help for T11/T30/T40 devices in the "setup" chapter Compax3\optimization\controller dynamics\signal filtering at external setpoint specification"

Test Move

In order to evaluate the behavior of the drive, test movements can be defined. For this you jump into the parameter entry either with the aid of the "enter setup/test movement parameters" or by selecting the parameter tab. Via the "setup settings" menu you access the settings for the desired test movement.

The desired motion profile can be set via the parameters in the following window.

Proceeding during controller optimization

In this chapter you can read about:


Main flow chart of the controller optimization	233
Controller optimization disturbance and setpoint behavior (standard)	234
Controller optimization disturbance and setpoint behavior (advanced)	237

If the control behavior is not sufficient for the present application, an optimization is required. We recommend the following approach:

Overview on the approach to setup + optimization

- ◆ At first, the disturbance and setpoint behavior of the velocity loop at standstill and at different displacement velocities is optimized (stiffness, attenuation, filter).
- ◆ After that, the necessary motion profiles are set via the setup tool and the desired guiding behavior in the entire velocity range is set via the feedforward control (motion profiles, feedforward).


Main flow chart of the controller optimization




Controller optimization disturbance and setpoint behavior (standard)**In this chapter you can read about:**

Controller optimization standard	235
Controller optimization of toothed belt drive	236

Controller optimization standard




Controller optimization of toothed belt drive




Controller optimization disturbance and setpoint behavior (advanced)**In this chapter you can read about:**

Controller optimization Advanced	238
Flow chart controller optimization of a direct drive.....	239
Controller optimization guiding transmission behavior.....	240


Controller optimization Advanced



Flow chart controller optimization of a direct drive



Controller optimization guiding transmission behavior



4.4.4. Signal filtering with external command value

In this chapter you can read about:


- Signal filtering for external setpoint specification and electronic gearbox.....241
- Signal filtering for external setpoint specification and electronic cam.....242

The command signal read in from an external source (via HEDA or physical input) can be optimized via different filters.

For this the following filter structure is available:

4.4.4.1 Signal filtering for external setpoint specification and electronic gearbox

Does not apply for Compax3I11T11!




* Speed v and acceleration a are only present in the event of linear interpolation (bus interpolator: O3925.1) if they are provided by an external source. In quadratic or cubic interpolation, v and a are emulated.

B: Structure image of the signal processing,

D/E: Structure of Gearing

Control structure (see on page 210, see on page 216, see on page 217)


Symbols



Tracking filter

The displayed filter influences all outputs of the tracking filter.


Number: Object number of the filter characteristic



Differentiator


Output signal = $d(\text{input signal})/dt$

The output signal is the derivation (gradient) of the input signal



Filter

Number: Object number of the filter characteristic



Interpolation

Linear Interpolation.


Values in the 500µs grid are converted into the more exact time grid of 125µs.

Note:

- ◆ A setpoint jerk setpoint feedback is not required for external setpoint specification.
- ◆ The description of the objects can be found in the object list.


4.4.4.2 Signal filtering for external setpoint specification and electronic cam

Only Compax3 T40!



B: Structure image of the signal processing,



D/E: Structure of Cam

Control structure (see on page 210, see on page 216, see on page 217)**Symbols****Tracking filter**

The displayed filter influences all outputs of the tracking filter.

Number: Object number of the filter characteristic**Differentiator**Output signal = $d(\text{input signal})/dt$

The output signal is the derivation (gradient) of the input signal

**Filter****Number:** Object number of the filter characteristic**Interpolation**

Linear Interpolation.

Values in the 500µs grid are converted into the more exact time grid of 125µs.

Note:

- ◆ A setpoint jerk setpoint feedback is not required for external setpoint specification.
- ◆ The description of the objects can be found in the object list.

4.4.5. Input simulation

In this chapter you can read about:

Calling up the input simulation	244
Operating Principle	245

Function The input simulation is used for the performance of tests without the complete input/output hardware being necessary.

The digital inputs (standard and inputs of M10/M12 option) as well as the analog inputs are supported.

The following operating modes are available for digital inputs:

- ◆ The physical inputs are deactivated, the digital inputs are only influenced via the input simulation.
- ◆ The digital inputs and the physical inputs are logically or-linked.
This necessitates very careful action, as the required function is, above all with low-active signals, no longer available.

The pre-setting of an analog input value is always made in addition to the physical analog input.

The function of the inputs depends on the Compax3 device type; please refer to the respective online help or the manual.

The input simulation is only possible if the connection with Compax3 is active and if the commissioning mode is deactivated!

4.4.5.1 Calling up the input simulation

Open the optimization window (double click in the C3 ServoManager tree entry: Optimization).

Activate the Tab "Setup" in the right lower window.

Clicking on the following button will open a menu; please select the input simulation.



4.4.5.2 Operating Principle

Window Compax3 InputSimulator:

1. Row: Standard Inputs E7 ... E0 = "0" button not pressed; = "1" switch pressed

2. Row: Optional digital inputs (M10 / M12)

Green field: port 4 is defined as input

Red field: port 4 is defined as output

the least significant input is always on the right side

3. Row: If the button "deactivating physical inputs" is pressed, all physical, digital inputs are deactivated; only the input simulation is active.

If both sources (physical and simulated inputs) are active, they are or-linked!



Caution!

Please consider the effects of the or-linking; above all on low-active functions.

4. Row: Simulation of the analog inputs 0 and 1 in steps of 100mV.

The set value is added to the value on the physical input.

After the input simulation has been called up, all simulated inputs are on "0".

When the input simulation is left, the physical inputs become valid.

4.4.6. Setup mode

The setup mode is used for moving an axis independent of the system control

The following functions are possible:

- ◆ Homing run
- ◆ Manual+ / Manual-
- ◆ Activation / deactivation of the motor holding brake.
- ◆ Acknowledging errors
- ◆ Defining and activating a test movement
- ◆ Activating the digital outputs.
- ◆ **Automatic determination of the load characteristic value** (see on page 248)
- ◆ Setup of the **load control** (see on page 161)

Activating the commissioning mode



By activating the setup mode, die Gerätefunktion is deactivated; the system function of the device is no longer available.

Access via an interface (RS232/RS485, Profibus, CANopen,...) and via digital inputs is deactivated. (if necessary, acyclic communication ways are nevertheless possible (e.g. Profibus PKW channel))

Caution!

The safety functions are not always guaranteed during the setup mode! This will for instance lead to the fact that the axis may trundle to a stop if the Emergency stop button is pressed (interruption of the 24 V on C3S X4.3), which requires special caution with z axes!

- ◆ In the Commissioning window (left at the bottom) the commissioning mode is activated.
- ◆ Then parameterize the desired test movement in the Parameter window. You can accept changed configuration settings into the current project.
- ◆ Now energize drive in the commissioning window and start the test movement.



Caution! Safeguard the travel range before energizing!

Deactivating the commissioning mode



If the setup mode is left, the drive is deactivated and the die Gerätefunktion is re-activated.

- Note:**
- ◆ The parameters of the commissioning window are saved with the project and are loaded into Compax3 if the commissioning mode is activated (see explanation below).

4.4.6.1 Motion objects in Compax3

The motion objects in Compax3 describe the active motion set.

The motion objects can be influenced via different interfaces.

The following table describes the correlations:

Source	active motion objects		Compax3 device
	==>	describe	
Set-up (working with the commissioning window)	<==	read	Active motion objects: ♦ Position [O1111.1] ♦ Speed [O1111.2] ♦ Acceleration [O1111.3] ♦ Deceleration [O1111.4] ♦ Jerk* [O1111.5] (Acceleration) ♦ Jerk* [O1111.6] (Deceleration) * for lxxT11 - devices, both jerk values are identical
	==>	♦ With the "accept entry" button. ♦ The current project gets a motion set. Download by activating the motion	
Compax3 ServoManager project	==>	♦ C3lxxT11: via an activated motion set ♦ C3l2xT11: via a configuration download	
	<==	For Compax3 l2xT11: ♦ via a configuration upload ♦ in the commissioning window via "accept configuration"	
Fieldbus (Compax3 l2xTxx)	==>	♦ Changing the motion objects directly	
	<==	♦ Reading the motion objects	
IEC61131-3 program (Compax3 lxxT30, lxxT40)	==>	♦ via positioning modules	

4.4.7. Load identification

In this chapter you can read about:

Principle.....	248
Boundary conditions	248
Process of the automatic determination of the load characteristic value (load identification).....	249
Tips.....	250

Automatic determination of the load characteristic value:

- ◆ of the mass moment of inertia with rotary systems
- ◆ of the mass with linear systems

4.4.7.1 Principle

The load characteristic value is automatically determined.

For this it is necessary to excite the system additionally with a signal (excitation signal = noise).

The excitation signal is fed into the control loop. The control loop dampens the excitation signal. Therefore, the superimposed control loop is set so slowly by reducing the stiffness, that the measurement is not influenced.

A superimposed test movement is additionally possible. This helps to eliminate possible mechanical effects such as rubbing caused by friction.

4.4.7.2 Boundary conditions

If the control is instable before the beginning of the measurement, please reduce the stiffness (in the optimization window at the left bottom)

The following factors can disturb a measurement:

- ◆ Systems with high friction (e.g. linear actuators with sliding guide)
Here, the systems where the static friction is considerably higher than the kinetic friction (slip-stick effect) are especially problematic.
- ◆ Systems with significant slack points (play)
- ◆ Systems with "too light" or susceptible to oscillation bearing of the total drive (rack).
Formation of rack resonances. (e.g. with gantries,...)
- ◆ Non constant disturbance forces which influence the speed development. (e.g. extremely strong slot moments)

The effects of the factors one to three on the measurement can be reduced by using a test movement.

Caveat emptor (exclusion of warranty)

Due to multiple possibilities for disturbing influences of a real control path, we cannot accept any liability for secondary damages caused by faultily determined values. Therefore it is essential to verify all values automatically determined before loading them into the control loop.

4.4.7.3 Process of the automatic determination of the load characteristic value (load identification)

- ◆ Please click on "unknown: default values are used" in the configuration wizard in the "External moment of inertia" window.
- ◆ After the configuration download, you can enter directly, that the optimization window is to be opened.
- ◆ In the Commissioning window (left at the bottom) change to commissioning mode.
- ◆ Finally enter the values of the excitation signal and of the test movement in the parameter window.
Parameters of the excitation signal:
 - ◆ Amplitude of the excitation signal in % of the motor reference current
Only an amplitude value causing a distinct disturbance can give a usable result.
 - ◆ permissible following error
In order to avoid a following error caused by the excitation signal, the permissible following error must be increased for the measurement if necessary.
 - ◆ Selection of the test movement: inactive, reverse, continuous
 - ◆ Parameterizing of the test movement if necessary
- ◆ Now energize drive and open load identification window in the commissioning window.



Caution! Safeguard the travel range before energizing!

- ◆ Starting the load identification.



Caution! The drive will perform a jerky movement during load identification!

- ◆ After the measurement, the values can be accepted. Depending on the application, 2 measurements for minimum external load and maximum external load are recommended.

4.4.7.4 Tips

Tip	Problem	Measures
1	Speed too low (with reverse operation)	Increase maximum speed and adapt travel range*
2	Speed too low (with continuous operation)	Increase maximum speed
3	Test movement missing	A test movement is important for drives with high friction or with mechanical slack points (play).
4	No error detected	Please note the boundary conditions (see on page 248).
5	Speed too low and amplitude of the excitation signal too small (with reverse operation)	Increase amplitude of the excitation signal; increase maximum speed and adapt travel range*
6	◆ Speed too low and ◆ amplitude of the excitation signal too small (with continuous operation)	Increase amplitude of the excitation signal; increase maximum speed.
7	◆ Test movement missing ◆ amplitude of the excitation signal too small	◆ Increase amplitude of the excitation signal or / and ◆ activate an appropriate test movement
8	amplitude of the excitation signal too small	Increase the amplitude of the excitation signal.
9	Following error occurred	Increase the parameter "permissible following error" or decrease the amplitude of the excitation signal.

*if the travel range is too short, the speed is not increased, as the drive does not reach the maximum speed.


4.4.8. Alignment of the analog inputs

In this chapter you can read about:

Offset alignment.....251
 Gain alignment.....251
 Signal processing of the analog inputs.....252

There are two possibilities to align the analog inputs in the optimization window:

- ◆ Wizard-guided under commissioning: Commissioning functions (click on the yellow triangle with the left mouse button:



Caution!

This wizard guided automatic alignment does not work if you bridge Ain+ with Ground for the alignment!

In this case, please make a manual alignment as described below.

or

- ◆ by directly entering under optimization: Analog input

Analog Input
Offset [170.4]
Gain [170.2]

4.4.8.1 Offset alignment

Performing an offset alignment when working with the ±10V analog interface in the optimization window under optimization: Analog input Offset [170.4].

Enter the offset value for 0V input voltage.

The currently entered value is shown in the status value "analog input" (optimizing window at the top right) (unit: 1 ≡ 10V). Enter this value directly with the same sign as offset value.

The status value "analogue input" shows the corrected value.

4.4.8.2 Gain alignment


Performing an offset alignment when working with the ±10V analog interface in the optimization window under optimization: Analog input: Gain [170.2].

A gain factor of 1 has been entered as default value.

The currently entered value is shown in the status value "analog input" (optimizing window at the top right).

The status value "analogue input" shows the corrected value.

4.4.8.3 Signal processing of the analog inputs



B: Continuative structure image (see on page 241)

4.4.9. C3 ServoSignalAnalyzer

In this chapter you can read about:

ServoSignalAnalyzer - function range	253
Signal analysis overview	254
Installation enable of the ServoSignalAnalyzer.....	255
Analyses in the time range	257
Measurement of frequency spectra	260
Measurement of frequency responses	263
Overview of the user interface.....	270
Basics of frequency response measurement.....	284
Examples are available as a movie in the help file	289

4.4.9.1 ServoSignalAnalyzer - function range

The function range of the ServoSignalAnalyzer is divided into 2 units:

Analysis in the time range

This part of the function is freely available within the Compax3 ServoManager.
The Compax3 ServoManager is part of the Compax3 servo drive delivery range.

Analysis in the frequency range

This part of the function requires a license key which you **can buy** (see on page 255).

The license is a company license and must only be bought once per company.

For each PC you need however an individual key, which you can request individually.

4.4.9.2 Signal analysis overview


The ServoSignalAnalyzer offers three basic methods of analyzing systems:

- ◆ Analysis in the time range by measuring the step response
- ◆ Spectral analysis of individual signals
- ◆ Measurement of frequency response (Bode diagram) of the position control or of individual parts of the control as well as of the control path

These functions are available in the Compax3 ServoManager after the **activation** (see on page 255) with the aid of a system-dependent key.

You do not require expensive and complex measurement equipment -> a Compax3 device and a PC will do!

Basic structure of the signal analysis



Systems / signals

Depending on the kind of measurement, the SignalAnalyzer can help analyze the most different signals and systems.

Signal generator

This allows to inject different excitation signals (step, sine and noise signals) into the control loop.

Superposed system

For different analyses, superposed systems must be manipulated in order to allow a measurement. After the measurement, the changes made for this purpose are reset

C3 software oscilloscope

With the aid of the software oscilloscope, the contents of different objects can be registered and be loaded into the PC for further analysis.

Control and signal processing

The control of the entire measurement as well as the processing of the uploaded sample data are made in the PC.

4.4.9.3 Installation enable of the ServoSignalAnalyzer

In this chapter you can read about:

Prerequisites	255
Installation	255
Activation.....	255

Prerequisites

- ◆ Compax3 with up-to-date controller board (CTP 17)
- ◆ Firmware version R06-0 installed

Installation

- ◆ Execution of the C3 ServoManager Setup (on CD)
- ◆ If the firmware is too old => update with the aid of the firmware from the CD

Activation

In order to be able to use the analysis functions in the frequency range (for example frequency response measurement), a software activation is required.


Please observe:

The activation is only valid for the PC on which it was performed!


Caution! If the PC disposes of network adapters which are removed at times (e.g. PCMCIA cards or notebook docking stations), these adapters should be removed before generating the key!

In order to activate the ServoSignalAnalyzer, please follow these steps:

- ◆ Start the Compax3 ServoManager.




- ◆ Select the Select the C3 ServoSignalAnalyzer in the function tree under optimization.
In the right part of the window you can see the note that no key file was found.
- ◆ A double click on the preselected C3 ServoSignalAnalyzer will generate a system-dependent key.




- ◆ Acknowledge with OK and enter the key, which is on your clipboard, into an e-mail, which you please send to **eme.ssalicence@parker.com** (**mailto:eme.ssalicence@parker.com**).
- ◆ After receipt of the reply, copy the attached file "C3_SSA.KEY" into the C3 ServoManager directory (C:\Programs\Parker Hannifin\C3Mgr2\).
- ◆ => the software is activated.

4.4.9.4 Analyses in the time range

Selection and parameterization of the desired analysis function



Exemplary step function



step Value = Step Size

The following functions are available:

Position demand value step: For analysis of the demand value behavior of the position control***Step value < (admissible motion range / 2)***

=> even a 100% overshoot does not incite an error message

Speed demand value step: For analysis of the demand value behavior of the speed control

The position control is switched off during the measurement, this might lead in exceptional cases to a slow drift of the position.

Furthermore you should make sure that the selected speed step value corresponds to the parameterized admissible motion range.

Step value < (admissible motion range / time of measurement)

with time of measurement > 2s

Current demand value step: For analysis of the demand value behavior of the current control

The current setpoint jerk is set at the end of the oscilloscope recording time, but is reset to 0 after max. 50mS.

**Caution!**

- ◆ Many systems are not stable without control!
- ◆ Position as well as speed control are switched off during measurement => **no measurement on z-axes!**

Disturbance torque / force step response: For analysis of the disturbance value behavior of the control

The step of an external disturbance force is simulated and the reaction of the controller is registered.

Shaker function

For this, a sine signal is injected to the current which is used to excite the mechanic system. This allows to analyze the oscillation behavior - what oscillates at which frequency.

Basic settings of the analysis functions:**Maximum torque / maximum current / maximum speed (display):**

This is used as a lead for the selection of a suitable step value and indicates which maximum step value is possible.

Step value:

Gives the value of a step.

Permissible motion range (+/-):

- ◆ Indication, in which position window the axis may move during the analysis.
- ◆ This range is not left even in the event of an error.
- ◆ If the drive approaches the limits of the motion range, the controller will decelerate so that the drive will come to a standstill within the permitted motion range. The maximum permitted velocity is used to calculate the deceleration ramp, therefore the drive stops even before reaching the range limits and reports an error.
- ◆ Please make sure that a sufficiently large movement is set for the measurement and that it will be reduced by a high maximum permitted velocity.

- ◆ The motion range monitoring is especially important during current step responses, as position as well as speed control are deactivated during the measurement.

Max permitted speed

When exceeding this value, an error is triggered, the controller decelerates and reports an error.


When measuring the velocity setpoint jerk, the maximum permitted velocity is set to twice the step height.

Setting and automatic start of the oscilloscope:

After pressing "accept entries", the parameters of the oscilloscope (such as scanning time and the assignment of the individual channels) are automatically set to default values according to the respective step value.

When starting the step function, the oscilloscope is automatically started.

Start of the measurement



The start of the step function is made with the aid of the highlighted button.

4.4.9.5 Measurement of frequency spectra


In this chapter you can read about:

Functionality of the measurement.....260
 Leak effect and windowing261

Please note that you require a license key (see on page 255, see on page 253) for this application!

Functionality of the measurement


Measurement of the spectral analysis



During the spectral analysis of scanned signals with the aid of the discrete Fourier transformation, a so-called frequency resolution (Δf) results, Δf being $=f/N$, independently of the scanning frequency (f) and of the number of measurement values used (N).

The spectra of scanned signals are only defined for frequencies, which are an integer multiple of this frequency resolution.

Interpretation of the frequency spectrum




Leak effect and windowing

If frequencies not corresponding to the frequency resolution are present in the analyzed spectrum, the so-called leak effect can be caused.


Display of the leak effect with the aid of a 16 point discrete Fourier transformation

Complete oscillation period in the scanning period



Envelope without leak effect

Non complete oscillation period in the scanning period




Envelope with leak effect

Sine at 200Hz without windowing

Consequence of the leak effect shown at the example of a sine signal.


($f_A=4000\text{Hz}$; $N=500$; $\Rightarrow \Delta f=8\text{Hz}$)

$f_0=200\text{Hz} = 25 \cdot \Delta f$ frequency corresponds to the frequency-resolution



The sine frequency is exactly on a multiple of the frequency resolution (200Hz / 8Hz=25). The spectrum is clearly separated and there are no leak effects visible.

Sine at 204Hz



$\Delta f = 8\text{Hz} / f_0 = 204\text{Hz} = 25.5 \cdot \Delta f$ / frequency does not correspond to the frequency resolution!

The sine frequency has only minimally changed, due to which it does, however, no longer match the frequency resolution ($204\text{Hz}/8\text{Hz} = 25.5$) => leak effect

Two consequences are visible:

The spectrum is faded in the ranges at the right and at the left of the sine frequency. In this range, an amplitude is displayed, even though these frequencies are not contained in the real signal.


- ◆ The height of the peak of the sine frequency is reduced, => it seems as if the signal energy is leaking out and distributing over the spectrum. This explains the term leak effect.

Windowing

With the aid of the windowing, leak effects can be avoided. There are many different kinds of windowing, who do all have the same restrictions.

- ◆ windowing reduces the total energy of the analyzed signal, which results in a reduced amplitude of all measured frequencies.
- ◆ Individual frequency peaks do not appear so sharp and narrow as with measurements without windowing.

Sine at 200Hz and 204Hz with Hanning windowing



4.4.9.6 Measurement of frequency responses

In this chapter you can read about:

Safety instructions concerning the frequency response measurement..... 263
 Functionality of the measurement..... 263
 Open/Closed Loop frequency response measurement 265
 Excitation Signal..... 266
 Non-linearities and their effects 267

Please note that you require a license key (see on page 255, see on page 253) for this application!


Safety instructions concerning the frequency response measurement

During the measurement of the frequency response, the control is changed and influenced in multiple ways. You should therefore respect the following notes:

- ◆ During the measurement, the entire system is excited via a broad frequency spectrum. This might damage especially sensitive components (such as lenses) The risk increases with the extent of the excitation. In addition, natural mechanical frequencies may cause an increased excitation of individual components.
- ◆ The measurement of the frequency response can only be made in the setup mode with energized controller.
- ◆ During the current measurement (between start and stop of the measurement), no write flash may be executed.
- ◆ In the event of a break in communication during the measurement, the controller must be switched off and then on again in order to reestablish the original status.
- ◆ Changes of the controller parameters during the measurement are not permitted. Those may be overwritten by standard values when the measurement is terminated.

Functionality of the measurement

Basic structure of a frequency response measurement



In general, the analysis of the dynamic behavior of a system is made by analyzing the input and output signals.

If you transform the input signal as well as the output signal of a system into the range (Fourier transformation) and then divide the output signal by the input signal, you get the complex frequency response of the system.

$$G(s) = \frac{Y(s)}{U(s)}$$

$$y(t) \xrightarrow{F} Y(s)$$

$$\text{with } u(t) \xrightarrow{F} U(s)$$

A problem are, however, superimposed systems (the control)

Course of the measurement

- ◆ Superimposed controls are switched of (open Loop) or attenuated
- ◆ The excitation signal is injected in front of the system to be measured with the aid of the signal generator. Wait, until the system settled.
- ◆ Execution of the measurement: Registration of input and output signal with the aid of the oscilloscope.
- ◆ Upload of the measurement values from the controller into the PC.
- ◆ Processing of the measurement values into a frequency response
- ◆ If a cumulated measurement is configured: Averaging over several frequency responses.

During cumulated measurement, an average is taken over all measurements in the result memory and the result is then put out.

Open/Closed Loop frequency response measurement

In order to be able to analyze the transmission behavior of subordinate systems (such as for example speed control, current control or mechanical system), the influence of the superposed controls on the measurement must be avoided.

Influence of a superposed system on the frequency response measured

In the simplest case, the superposed controls are switched off completely (Open Loop) This provides the best measurement results due to the elimination of any influence caused by the superposed controls.

This is, however, rarely possible for reasons of safety or feasibility.




Caution!

- ◆ Many systems are not stable without control!
- ◆ Position as well as speed control are switched off during measurement => **no measurement on z-axes!**

If you want to analyze for example the mechanic system of a z-axis, the position control as well as the speed control must remain active.

In systems subject to friction it may be necessary in order to improve the quality of the measurement, to **move the system with a superimposed speed** (see on page 268), which is however only possible with a closed loop measurement.

Influence of an active superposed control on the result of the measurement



At the left without, at the right with the influence of the superposed control

In order to attenuate the influence of the superposed controls, the controller bandwidth is reduced to such an extent, that their influence on the measurement is negligible.

Excitation Signal

In order to be able to analyze the behavior of the system at individual frequencies, it is necessary that these frequencies can be measured in the input signal as well as in the output signal. For this, a signal generator excites all frequencies to be measured. For this applies, that the signal noise distance of the measurement is the larger, the larger the excitation of the system.


High noise distance => low influence of disturbances on the measurement.

For this, an excitation signal is injected in front of the system to be measured.

The power (amplitude) of the excitation signal can be set.

Start with a small amplitude and increase the amplitude slowly during the current measurement until the result of the measurement shows the desired quality.

Influence of the excitation amplitude on the quality of the measurement results



Left: Too small amplitude of the excitation signal (7.3mA)

Right: Suitable amplitude of the excitation signal (73mA)

In the case of non-linearities in the system, an increase in the excitation may however lead to a **decline of the quality of the measurement** (see on page 267).


Non-linearities and their effects

In this chapter you can read about:

- Attenuation of the excitation amplitude267
- Shifting the working point into a linear range.....268

Non-linearities in mechanical systems are for example due to friction, backlash or position-dependent transmissions (cams and crankshaft drives). In general, the frequency response is only defined for linear systems (see 7.2 (see on page 285)). What happens in the frequency range in the event of a non-linear system, is shown below.

Signal amplitude too high => non-linearity in the signal range




Due to the non-linear transmission behavior of the system, many "new" frequencies were generated in the output signal. In the frequency response, only one change of the frequency present in the input signal can be displayed meaningfully.

=> The frequencies generated in the spectrum of the output signal lead to a deterioration of the measured frequency response.

There are however two possibilities to make successful measurements of frequency responses in spite of non-linearities present:

Attenuation of the excitation amplitude

Signal amplitude too small => no non-linearity in the signal range



The signal range is reduced so that approximately linear conditions are valid. The results of the measurement will then display the dynamic behavior at the working point.

Example cam drive:

If the drive moves considerably (e.g. 180°) during the measurement, the behavior of the system will change greatly over this range => caused by non-linearities in the signal range.


An inexact measurement is the result.

If the excitation is reduced so that the drive will move only by a few degrees, the behavior of the system at this working point will be approximately constant.

An exact measurement is the result.

Shifting the working point into a linear range

Signal amplitude large with offset => no non-linearity in the signal range




For this, the signal range is shifted so that approximately linear conditions are valid => the results of the measurement show the dynamic behavior at the working point.

Example rubbing caused by friction:

In systems subject to a distinct transition between rubbing caused by friction and sliding friction, the rubbing force will reduce abruptly as soon as the drive is moved ($v > 0$). With a motor at standstill, the excitation signal will cause a multiple passing through the range of rubbing friction during measurement. Due to the non-linearity in the signal range, the resulting measurement will be inexact.

If the drive moves, however, fast enough during the measurement, so that the speed will not become zero during the measurement, the system remains in sliding friction and a precise measurement can be obtained.

Optimal measurement with rubbing friction



- $V_{test\ move}$: Speed of the test movement
- $V_{stimulation}$: Speed of the excitation signal
- static friction: Static friction

Example backlash: (for example in gearboxes)


Here, non-linearities are caused, if the tooth edges will turn from one side to the other during measurement. The reason for this is a change of the sign of the force transmitted by the gearbox.

In order to avoid this, you can try to transmit a constant torque by keeping a constant speed and to avoid a change of the sign during the measurement by choosing a relatively small excitation amplitude.

4.4.9.7 Overview of the user interface

In this chapter you can read about:

Selection of the signal or system to be measured..... 270
 Frequency settings 275
 Speed control 275
 Other settings 277
 Operating and status field 280
 Display of the measurement result 281
 Display of the measurement point at the cursor position 283



- (1) Selection of the signal or system to be measured (see on page 270)
- (2) Frequency settings (see on page 275)
- (3) Other settings (see on page 277)
- (4) Operating and status field (see on page 280)
- (5) Display of the measurement result (see on page 281)
- (6) Display of the measurement point at the cursor position (see on page 283)

Selection of the signal or system to be measured.

In this chapter you can read about:

Current control..... 271
 Mechanical system 272
 Position control 273

With the aid of the tree structure, you may select what you want to measure. Here, the selection is made, if a frequency spectrum or a frequency response is to be measured.

The shown structures are simplified in such as all feedbacks are displayed without special transmission behavior. This is surely not the case in reality, serves however a better overview.


Current control

Closed current control

Shows the dynamic behavior of the closed current control.

=> How a signal on the current demand value is transmitted to the current actual value.

(response)



- | | |
|--------------------------------|------------------------------|
| Signal generator | Signal Generator |
| Position controller | Lageregler |
| actual position | Lageistwert |
| desired position | Lagesollwert |
| Velocity controller | Geschwindigkeitsregler |
| actual velocity | Geschwindigkeitsistwert |
| Current controller | Stromregler |
| actual current | Stromistwert |
| current controlled system | Stromregelstrecke |
| f: disturbance torque | Störmoment |
| velocity controlled system | Geschwindigkeitsregelstrecke |
| position controlled system | Lageregelstrecke |
| Frequency response measurement | Frequenzgangmessung |

Application:


During the optimization of the current control for verification

- ◆ for the design of superposed controllers.

Mechanical system

Current to velocity

Shows the dynamic behavior between the measured current actual value and the velocity actual value



- | | |
|--------------------------------|------------------------------|
| Signal generator | Signal Generator |
| Position controller | Lageregler |
| actual position | Lageistwert |
| desired position | Lagesollwert |
| Velocity controller | Geschwindigkeitsregler |
| actual velocity | Geschwindigkeitsistwert |
| Current controller | Stromregler |
| actual current | Stromistwert |
| current controlled system | Stromregelstrecke |
| f: disturbance torque | Störmoment |
| velocity controlled system | Geschwindigkeitsregelstrecke |
| position controlled system | Lageregelstrecke |
| Frequency response measurement | Frequenzgangmessung |


Reflects the transmission behavior between the acceleration at the motor and the acceleration at the load to be moved.

Application:

- ◆ for the analysis of the dynamic behavior of the mechanic system

Current to position

Shows the dynamic behavior between current actual value and position actual value.



- | | |
|--------------------------------|------------------------------|
| Signal generator | Signal Generator |
| Position controller | Lageregler |
| actual position | Lageistwert |
| desired position | Lagesollwert |
| Velocity controller | Geschwindigkeitsregler |
| actual velocity | Geschwindigkeitsistwert |
| Current controller | Stromregler |
| actual current | Stromistwert |
| current controlled system | Stromregelstrecke |
| f: disturbance torque | Störmoment |
| velocity controlled system | Geschwindigkeitsregelstrecke |
| position controlled system | Lageregelstrecke |
| Frequency response measurement | Frequenzgangmessung |

Application:


- ◆ for the analysis of the dynamic behavior of the mechanic system

Position control

Closed position control

Shows the dynamic behavior of the closed position control.

=> How a signal on the position demand value is transmitted to the position actual value.



Signal generator	Signal Generator
Position controller	Lageregler
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung


Application:

For the design of superposed controllers or systems.

- ◆ For the verification of the obtained controller speed during optimization
- ◆ for the revision of the controller design of the position control

open position control

Shows the dynamic behavior of all components in the position control loop, but without closing it.



Signal generator	Signal Generator
Position controller	Lageregler
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung

Application:


- ◆ For the graphic design of the position control.

Compliance of Position control

Shows the dynamic disturbance value behavior of the position control.

=> which dynamic influence does a disturbance torque have on the following error.

The disturbance torque is injected as disturbance current => this corresponds to the effect of a disturbance torque f



Signal generator	Signal Generator
Position controller	Lageregler
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung

Application:

- ◆ Verification of the dynamic disturbance value behavior of the position control.
- ◆ Which following error generates a sinusoidal disturbance torque / disturbance current with the frequency fZ ?
- ◆ The frequency response of the compliance corresponds to the disturbance step response in the time range

Frequency settings



(1) start frequency

◆ This is the smallest frequency at which is still measured. During the measurement of frequency spectrum and noise frequency response this results automatically from the bandwidth and is only displayed as an information.

(2) End (bandwidth)

◆ This corresponds to the highest frequency which is measured. Start frequency as well as the frequency resolution can be varied with the aid of the bandwidth for frequency spectrum and noise frequency response.

(3) Frequency resolution (see on page 260)


◆ During the measurement of frequency spectrum and noise frequency response this results automatically from the bandwidth and is only displayed as an information.

Speed control

Closed velocity control

Shows the dynamic behavior of the closed velocity control.

=> How a signal on the velocity demand value is transmitted to the velocity actual value.



- Signal generator
- Position controller
- actual position
- desired position
- Velocity controller
- actual velocity
- Current controller
- actual current
- current controlled system
- f: disturbance torque
- velocity controlled system
- position controlled system
- Frequency response measurement


- Signal Generator
- Lageregler
- Lageistwert
- Lagesollwert
- Geschwindigkeitsregler
- Geschwindigkeitsistwert
- Stromregler
- Stromistwert
- Stromregelstrecke
- Störmoment
- Geschwindigkeitsregelstrecke
- Lageregelstrecke
- Frequenzgangmessung

Application:

- ◆ During the optimization of the velocity control for verification
- ◆ For the design of superposed controllers.

Open velocity control

Shows the dynamic behavior of all components in the velocity control loop, but without closing it.



Signal generator	Signal Generator
Position controller	Lageregl
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung

Application:


For the graphic design of the velocity control.

Compliance of velocity control

Shows the dynamic disturbance value behavior of the velocity control.

=> which dynamic influence does a disturbance torque have on the control deviation of the velocity control.

The disturbance torque is injected as disturbance current => this corresponds to the effect of a disturbance torque f



Signal generator	Signal Generator
Position controller	Lageregler
actual position	Lageistwert
desired position	Lagesollwert
Velocity controller	Geschwindigkeitsregler
actual velocity	Geschwindigkeitsistwert
Current controller	Stromregler
actual current	Stromistwert
current controlled system	Stromregelstrecke
f: disturbance torque	Störmoment
velocity controlled system	Geschwindigkeitsregelstrecke
position controlled system	Lageregelstrecke
Frequency response measurement	Frequenzgangmessung

Application:

- ◆ Verification of the disturbance value behavior of the velocity control
- ◆ Which velocity deviation generates a sinusoidal disturbance torque / disturbance current with the frequency fZ ?
- ◆ The frequency response of the compliance corresponds to the disturbance step response in the time range

Other settings



(1) Excitation

Serves to set the excitation signal of the frequency response measurement.

(2) Permissible following error (only for frequency response measurement)

The resulting following error is increased by the injection of the excitation signal during the frequency response measurement. In order to allow for this, the permissible following error window can be enlarged so that the measurement can be made. After the end of the measurement, this is reset to the original value.

(3) Selection of the kind of analysis of the measurement results

Depending on the fact whether frequency spectra or frequency responses are measured, the following types of analyses are available:

For frequency spectra:

- ◆ (a) Spectrum
- ◆ (b) Spectrum cumulated
- ◆ (c) cascade diagram

For frequency responses:

- ◆ (d) noise frequency response
- ◆ (d) noise frequency response cumulated


Non cumulated measurement (a & d)


The measured data are displayed directly. This is especially suitable if you wish to analyze the effects of changes on the measurement results directly and promptly.

The disadvantage is however a smaller noise distance (quality) and an increased sensitiveness of the measurement towards unique disturbances.

Cumulated measurement (b & e)

An average is taken from all measurements in the result memory. This reduces the influence of random signals and disturbances extremely (improvement of the quality). The number of measurements from which the average is taken, is set with the **Size of the result memory** (see on page 280).


Comparison of two frequency spectra without and with cumulation



Cascade diagram (c)


Frequency spectra are displayed subject to time. The information on the value of the signal is color-coded.

Cascade diagrams of the velocity signal during an acceleration process



This kind of display is suitable for the analysis of temporal changes in the measured spectrum.

Operating and status field



(1) Start and Stop of the measurement


(2) Status display

Current status of the measurement or of the controller (if no measurement is taking place).

(3) Progress of the registration of the signals in the controller

The time of registration of the signals in the controller itself can, depending on the bandwidth and the kind of measurement, take up to one minute.

(4) status of the activity of the different partitions of the measurement



a: Registration of the measurement in the controller

b: Upload of the measurement from the controller to the PC

c: Processing the measurement in the PC

(5) Different settings and options

Functions available in a pull-down menu:

Open superimposed control loops (see on page 265)

accept load force

This serves, when opening the velocity controller, to accept the load which the controller has provided at the time of switching off => a z-axis does not drop down abruptly.

Measurement synchronous to the test movement

If this option is selected, it is ensured during the measurement, that the sampling does not take place in the turning point during a movement.

Unless frequencies are generated due to the deceleration/acceleration of the drive, which influence the measurement.

Result memory

In the result memory, the results of the N last measurements are kept.

This is important for the display of the cumulated measurement and for the cascade diagram. The larger the memory, the "older" the results still used. When

the contents is deleted, all old measurements are discarded and do no longer influence the new results.

Windowing (see on page 261)

Here you can select different windowing modes for the measurement of frequency spectra. As default, no window is used.

Save measure to file

The currently displayed measurement result is stored and can be uploaded later into the ServoSignalAnalyzer. This does, however, not apply to the cascade diagram display.

Open measure from file


Here you can reload the measurements memorized before. You have the possibility to load up to four measurements subsequently and display them together in a graphic display.

Copy measurement to clipboard as graphic display.


The currently displayed measurement result is copied as pixel graphic (e.g. BMP) to the clipboard.

Display of the measurement result

Frequency spectra




Bode diagrams: Value and phase



By clicking with the left mouse button on the legend, this can be shifted by 90°. By clicking on the color bar, the color of the respective graph can be modified.

Cascade diagrams



By clicking with the left mouse button on the color scale, you can change between autoscale mode and fixscale mode.

AutoScaleMode:


In this mode, the scaling of the color scale is adapted automatically so that all values can be displayed.

FixScaleMode:

Here, the scaling is fixed.

=> If, for instance, a considerably higher value than before is to be displayed, it is simply displayed like the former maximum (red).

Display of the measurement point at the cursor position



The cursor is set by clicking on the left mouse button. All measurement data of the selected cursor position (frequency) are displayed in the "cursor" operating field.

4.4.9.8 Basics of frequency response measurement

In this chapter you can read about:

Distinction between signals and systems.....	284
Linear Systems (LTI System)	285
Mechanical system.....	286
Resonance points and their causes.....	287

In the drive and control technology, the display of signals and systems in the frequency range is often the best possibility to solve different tasks.


Distinction between signals and systems

Defined objects and their interactions that can be combined to a whole by a plausible distinction from their environment (i.e. the complex reality) are called a system.

Example electric motor

This consists of a multitude of different components, but the function and the behavior of a motor can be described as a whole without describing each individual component and their interactions separately.

If the motor is energized, it will generate a torque at the motor shaft.



Current is therefore a signal, which causes at the input of the system motor a change of its torque output signal.

In order to register and process such signals in the controller, they are digitized and read in with the so-called scanning frequency (f_A). Thus the physical signal was converted into a finite sequence of numbers, which can be processed in the controller.

Linear Systems (LTI System)


Further explanations are based on the concept of so-called linear systems. This means that doubling the input value means that the portion of the output value influenced by it is also doubled. This, for instance, is not the case in the event of influence due to limitations, friction and backlash.

=> those are called non-linear systems, which can not be analyzed with the methods described here (or only with difficulties).

One of the most important properties of linear systems is that a sine signal, which is put through a linear system, is still a sine signal at the output, which differs from the input signal only in value and phase.

When a signal passes a LTI system, no new frequencies are generated.

Input and output signals of a linear system




If you know the value ($V(f_0)$) as well as the phase position ($u(f_0)$) for all frequencies, the LTI system is completely defined.

Such a graph of value and phase position in dependence of the frequency, is called frequency response or bode diagram.

=> only LTI systems can be analyzed with the aid of frequency responses.

Frequency response / bode diagram




The frequency response shows the amplification (value) and the phase shift (phase), which a signal is submitted to when passing through a system.

The displayed bode diagram allows the following conclusions:

If a sine with 60Hz and an amplitude of 1A is present at the input, a sine delayed by 94° and an amplitude of 0.01m/s will result at the output.

Mechanical system

Frequency response of a mechanic system: Current - velocity of a motor



The outlined course at the end of the measurement range does not permit statements on the system measured due to disturbances. Due to the attenuation of the signals increasing with the frequency, the sensitiveness of the measurement to disturbances (signal to noise ratio) increases with a rising frequency. The value as well as the phase response of the displayed frequency response are "disturbed" at the same intensity, this shows, that disturbances are the reason.


The value response consists basically of a straight, which declines with a slope of -20dB/decade (-20dB/decade => per tenfold increase of the frequency, the value decreases also by factor ten).

The phase response remains however almost constantly at -90° over a relatively large range.

In control technology, this is called integrating behavior (I-behavior).

the I-behavior can be explained as follows.

The measured current is proportional to the motor force and thus also to the acceleration of the driven mass. As the velocity is calculated from the integrated acceleration, the measured system looks as follows:




Input value is the current actual value, output value is the velocity actual value

Resonance points and their causes

In this chapter you can read about:

Rotary two mass system.....288
 Linear two mass system288
 Toothed belt drive as two mass system289

Mechanical system with a resonance point




f_{ARes} : Anti resonance frequency

f_{Res} : Resonance frequency

The displayed change of the frequency response (resonance point), has its cause in a so-called two mass system (caused by the elastic coupling of two masses).

Hint As, upon closer examination, each mechanic coupling shows a certain elasticity, it is no the question if there is a resonance point, but at which frequency it is and how well it is attenuated.

Rotary two mass system



The shown system corresponds for instance to a motor with a flywheel coupled via a shaft. Hereby J1 corresponds to the motor moment of inertia and J2 to the moment of inertia of the flywheel.


Calculation of the resonance frequencies in the rotary system with a hollow shaft as elastic coupling element

$$D = \int_{r_i}^{r_A} \frac{2 \cdot \pi \cdot G}{l} \cdot r^3 \cdot dr = \frac{G \cdot \pi \cdot (r_A^4 - r_i^4)}{2 \cdot l}$$

$$f_{ARes} = \frac{1}{2 \cdot \pi} \cdot \sqrt{\frac{D}{J_2}} \qquad f_{Res} = \frac{1}{2 \cdot \pi} \cdot \sqrt{D \cdot \left(\frac{1}{J_1} + \frac{1}{J_2} \right)}$$

G	Shear modulus of the material used [N/m ²] (e.g. approx. 80750N/mm ² for steel)
D	Torsional rigidity in [m/rad]
rA	Outer radius of the hollow shaft
ri	Inner radius of the hollow shaft
l	Length of the hollow shaft


Linear two mass system



Resonance frequencies in the linear system

$$f_{ARes} = \frac{1}{2 \cdot \pi} \cdot \sqrt{\frac{D}{m_2}} \qquad f_{Res} = \frac{1}{2 \cdot \pi} \cdot \sqrt{D \cdot \left(\frac{1}{m_1} + \frac{1}{m_2} \right)}$$

D	Rigidity in [N/m]
m1	e.g. motor mass
m2	e.g. load mass

Toothed belt drive as two mass system

In toothed belt drives, the toothed belt is the elastic coupling element. Its rigidity depends directly on the lengths l_1 and l_2 and changes in dependence of the position of the moved mass.

$$D_{spez} = \frac{F_{max}}{0,004}; \quad l_2 = 2 \cdot l_{Achse} - l_1$$

$$D_1 = \frac{D_{spez}}{l_1}; \quad D_2 = \frac{D_{spez}}{l_2}; \quad D = D_1 + D_2 = \frac{2 \cdot D_{spez}}{l_1 \cdot \left(2 - \frac{l_1}{l_{Achse}}\right)}$$

$$f_{ARes} = \frac{1}{2\pi} \cdot \sqrt{\frac{D}{m_2}} \quad f_{Res} = \frac{1}{2\pi} \cdot \sqrt{D \cdot \left(\frac{1}{m_2} + \frac{(r_{Zahnrad})^2}{J_1 \cdot (i_{Getriebe})^2} \right)}$$

D	Total spring constant of the toothed belt drive
Dspez	Specific spring constant of the toothed belt used
D1	Spring rate of the belt length l_1
D2	Spring rate of the belt length l_2
iGearbox	Transmission ratio of the gearbox
lAxis	Length of the axis
J1	Moment of inertia of motor and gearbox
m2	translatory moved mass
rToothed wheel	Radius of the drive pinion

4.4.9.9 Examples are available as a movie in the help file

Here you can find examples as a movie in the help file.

4.4.10. ProfileViewer for the optimization of the motion profile

In this chapter you can read about:

Mode 1: Time and maximum values are deduced from Compax3 input values	290
Mode 2: Compax3 input values are deduced from times and maximum values.....	291

You will find the ProfilViewer in the Compax3 ServoManager under the "Tools" Menu:



4.4.10.1 Mode 1: Time and maximum values are deduced from Compax3 input values

- ◆ The motion profile is calculated from Position, Speed, Acceleration, Deceleration, Acceleration Jerk and Deceleration Jerk
- ◆ As a result you will get, besides a graphical display, the following characteristic values of the profile:
 - ◆ Times for the acceleration, deceleration and constant phase
 - ◆ Maximum values for acceleration, deceleration and speed

4.4.10.2 Mode 2: Compax3 input values are deduced from times and maximum values

- ◆ A jerk-limited motion profile is calculated from the positioning time and the maximum speed / acceleration
- ◆ As a result you will get, besides a graphical display, the following characteristic values of the profile:
 - ◆ the parameters Position, Speed, Acceleration, Deceleration, Acceleration Jerk and Deceleration Jerk
 - ◆ Times for the acceleration, deceleration and constant phase
 - ◆ Maximum values for acceleration, deceleration and speed

Set deceleration and acceleration phase


The profile can be defined more exactly by entering the segmentation into deceleration and acceleration phase.

When setting 50% and 50%, a symmetrical design will result, the values for triangular operation are calculated, which is limited by the maximum speed.

The total of the percentage values may not exceed 100.

The percentage entries refer to the total positioning time.

Example:



4.4.11. Turning the motor holding brake on and off

Compax3 controls the holding brake of the motor and the power output stage. The time behavior can be set.

Application:


With an axis that is subject to momentum when it is halted (e. g. for a z-axis) the drive can be switched on and off such that no movement of the load takes place. The drive thereby remains energized during the holding brake response time. This is adjustable.

The power output stage current is de-energized by:

- ◆ Error or
- ◆ the control word
- ◆ the ServoManager

Thereafter the motor is braked to zero rotation speed on the set ramp.

When zero speed is reached, the motor is de-energized with the delay "brake closing delay time".




- 1: Motor powered
- 2: Motor de-energized
- 3: Open brake
- 4: Engage the brake
- 5: Brake closing delay time

The power output stage is enabled by:

- ◆ Acknowledge (after error) with the control word
- ◆ the ServoManager

The motor is energized with the delay "delay time for brake release".



- 1: Motor powered
- 2: Motor de-energized
- 3: Open brake
- 4: Engage the brake
- 5: Delay time for brake release

5. Communication

In this chapter you can read about:

Compa3 communication variants	293
COM port protocol	303
Remote diagnosis via Modem	308
DeviceNet	311

Here you will find the description of the fieldbus interfaces, which can be configured in the Compax3 ServoManager under the tree entry "configuring the communication".

Please note: The configuration of the process data (Mapping) is made wizard-guided with the Compax3 ServoManager.

If you perform the mapping directly via the master, you must go through this fieldbus wizard once; the Compax3 ServoManager will perform the necessary initializations.

5.1 Compax3 communication variants

In this chapter you can read about:

PC <-> Compax3 (RS232)	294
PC <-> Compax3 (RS485)	296
PC <-> C3M device combination (USB)	297
USB-RS485 Moxa Uport 1130 adapter	298
ETHERNET-RS485 NetCOM 113 adapter	299
Modem MB-Connectline MDH 500 / MDH 504	300
C3 settings for RS485 two wire operation	301
C3 settings for RS485 four wire operation	302

Overview of all possible communication modes between Compax3 devices and a PC.

5.1.1. PC <-> Compax3 (RS232)

PC <-> Compax3 (RS232): Connections to a device

PC (RS232 COM)



115kb



PC (Virtueller ComPort)



USB/RS232



115kb



PC (Virtueller ComPort)



10/100/1000Mb



Ethernet (LAN)


Ethernet/RS232




115kb



PC (RS232 COM)



PC (Virtueller ComPort)





PC (Virtueller ComPort)

**Analoges Telefonnetz
GSM / ISDN
Telephone Network**




5.1.2. PC <-> Compax3 (RS485)

PC <-> Compax3 (RS485)



5.1.3. PC <-> C3M device combination (USB)


PC <-> C3M device combination



5.1.4. USB-RS485 Moxa Uport 1130 adapter



Male DB9




PIN	RS-422/4-wire RS-485	2-wire RS-485
1	TxD-(A)	-
2	TxD+(B)	-
3	RxD+(B)	Data+(B)
4	RxD-(A)	Data-(A)

PIN	RS-422/4-wire RS-485	2-wire RS-485
5	GND	GND
6	-	-
7	-	-
8	-	-

The serial UPort 1130 USB adapter offers a simple and comfortable method of connecting an RS-422 or RS-485 device to your laptop or PC. The UPort 1130 is connected to the USB port of your computer and complements your workstation with a DB9 RS-422/485 serial interface. For simple installation and configuration, Windows drivers are already integrated. The UPort 1130 can be used with new or legacy serial devices and supports both 2- and 4-wire RS-485. It is especially suited for mobile, instrumentation and point-of-sale (POS) applications.

Manufacturer link: http://www.moxa.com/product/UPort_1130.htm
http://www.moxa.com/product/UPort_1130.htm


Connection plan for Compax3S:



5.1.5. ETHERNET-RS485 NetCOM 113 adapter



Manufacturer link: <http://www.vsc.com/de/666.htm>
 (<http://www.vsc.com/de/666.htm>)




DIP Switch settings NetCom 113 for two-wire operation:

1ON 2ON 3off 4off (Mode: RS485 by ART (2 wire without Echo))


Communication settings C3S/C3M:

Object	Function	Value
810.1	Protocol	16 (two wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	

Connection plan NetCom113 <-> C3S :



Connection plan NetCom113 <-> C3M X31:




5.1.6. Modem MB-Connectline MDH 500 / MDH 504

With the modems MDH500 and MDH504 manufactured by MB-Connectline, you can establish an independent connection. A virtual COM port is generated and the communication with the PC as well as the Compax3 takes place via RS232 or RS485.

It is not necessary to make any modem settings on the Compax3.

5.1.7. C3 settings for RS485 two wire operation

C3 ServoManager RS485 wizard settings:
 download with configuration in RS232 mode!




Communication settings C3S/C3M:

Object	Function	Value
810.1	Protocol	16 (two wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	

5.1.8. C3 settings for RS485 four wire operation

C3 ServoManager RS485 wizard settings:
 download with configuration in RS232 mode



Communication settings C3S/C3M:

Object	Function	Value
810.1	Protocol	0 (4 wire)
810.2	Baud rate	115200
810.3	NodeAddress	1..254
810.4	Multicast Address	

5.2 COM port protocol

In this chapter you can read about:

RS485 settings values.....	303
ASCII - record.....	304
Binary record.....	305

You can communicate with Compax3 in order to read or write objects via plug X10 (or X3 on the mains module of Compax3M) on the front via a COM port (max. 32 nodes).

As a rule 2 records are possible:

- ◆ ASCII record: simple communication with Compax3
- ◆ Binary record: fast and secure communication with Compax3 by the aid of block securing.

Switching between the ASCII and the binary record via automatic record detection.

Interface settings (see on page 408)

- Wiring**
- RS232: **SSK1** (see on page 383)
 - RS485: as **SSK27** (see on page 384) / RS485 is activated by +5V on X10/1.
 - USB: SSK33/03 (only for Compax3M)

5.2.1. RS485 settings values

If "Master=Pop" is selected, only the settings compatible with the Pops (Parker Operator Panels) made by Parker are possible.

Please note that the connected Pop has the same RS485 setting values.

You can test this with the "PopDesigner" software.

"Master=General" makes all Compax3 settings possible.

Multicast Address You can use this address to allow the master to access multiple devices simultaneously.

Device Address The device address of the connected Compax3 can be set here.

Baud rate Adjust the transfer speed (baud rate) to the master.

Cable type Please choose between **two-wire and four-wire RS485** (see on page 62).

Protocol Adjust the protocol settings to the settings of your master.

5.2.2. ASCII - record

The general layout of a command string for Compax3 is as follows:

[Adr] command CR

Adr	RS232: no address RS485: Compax3 address in the range 0 ... 99 Address settings can be made in the C3 ServoManager under "RS485 settings"
Command	valid Compax3 command
CR	End sign (carriage return)

Command

A command consists of the representable ASCII characters (0x21 .. 0x7E). Small letters are converted automatically into capitals and blanks (0x20) are deleted, if they are not placed between two quotation marks.

Separator between places before and after the decimal is the decimal point (0x2E).

A numeric value can be given in the Hex-format if it is preceded by the "\$" sign. Values can be requested in the Hex-format if the CR is preceded additionally by the "\$" sign.

Answer strings

All commands requesting a numeric value from Compax3 are acknowledged with the respective numeric value in the ASCII format followed by a CR without preceding command repetition and following statement of unit. The length of these answer strings differs depending on the value.

Commands requesting an Info-string (e.g. software version), are only acknowledged with the respective ASCII character sequence followed by a CR, without preceding command repetition. The length of these answer strings is here constant.

Commands transferring a value to Compax3 or triggering a function in Compax3 are acknowledged by:

>CR

if the value can be accepted resp. if the function can be executed at that point in time.

If this is not the case or if the command syntax was invalid, the command is acknowledged with

!xxxxCR

The 4 digit error number **xxxx** is given in the HEX format; you will find the meaning in the **appendix** (see on page 342).

RS485 answer string

When using RS485, each answer string is preceded by a "*" (ASCII - character: 0x2A).

Compax3 commands

Read object

RS232: O [\$] Index , [\$] Subindex [\$]

RS485: Address O [\$] Index , [\$] Subindex [\$]

The optional "\$" after the subindex stands for "hex-output" which means that an object value can also be requested in hex;

For example **"O \$0192.2\$"**: (Object 402.2)

Write object *RS232: O [\$] Index , [\$] Subindex = [\$] Value [; Value2 ; Value3 ; ...]*

RS485: Address O [\$] Index , [\$] Subindex = [\$] Value [; Value2 ; Value3 ; ...]

The optional "\$" preceding Index, Subindex and value stands for "Hex-input" which means that Index, Subindex and the value to be transferred can also be entered in hex (e.g. **O \$0192.2=\$C8**).

5.2.3. Binary record

The binary record with block securing is based on 5 different telegrams:

- ◆ 2 request telegrams which the control sends to Compax3 and
- ◆ 3 response telegrams which Compax3 returns to the control.

Telegram layout

Basic structure:

Start code	Address	Number of data bytes - 1				Data				Block securing	
SZ	A	L	D0	D1	...	Dn	Crc(Hi)	Crc(Lo)			

The start code defines the frame type and is composed as follows:

Bit	7	6	5	4	3	2	1	0
Frame type	Frame identification				PLC		Gateway	Address
RdObj read object	1	0	1	0	x	1	x	x
WrObj write object	1	1	0	0	x	1	x	x
Rsp response	0	0	0	0	0	1	0	1
Ack positive command acknowledgement	0	0	0	0	0	1	1	0
Nak Negative command acknowledgement	0	0	0	0	0	1	1	1

Bits 7, 6, 5 and 4 of the start code form the telegram identification; Bit 2 is always "1".

Bits 3, 1 and 0 have different meanings for the request and response telegrams.

The address is only necessary for RS484.

Request telegrams

-> Compax3

- ◆ the address bit (Bit 0 = 1) shows if the start code is followed by an address (only for RS485; for RS232 Bit 0 = 0)
- ◆ the gateway bit (Bit 1 = 1) shows if the message is to be passed on. (Please set Bit 1 = 0, as this function is not yet available)
- ◆ the PLC bit (Bit 3 = 1) allows access to objects in the PLC/Pop format U16, U32: for integer formats (see bus formats: Ix, Ux, V2) IEEE 32Bit Floating Point: for non integer formats (bus formats: E2_6, C4_3, Y2, Y4; without scaling)
With Bit 3 = 0 the objects are transmitted in the DSP format.
DSP formats:
24 Bit = 3 Bytes: Integer INT24 or Fractional FRACT24
48 Bit = 6 Bytes: Real REAL48 (3 Byte Int, 3 Byte Fract) / Double Integer DINT48 / Double Fractional DFRACT48

Response telegram

Compax3 ->

- ◆ Bits 0 and 1 are used to identify the response
- ◆ Bit 3 is always 0

The maximum number of data bytes in the request telegram is 256, in the response telegram 253.

The block securing (CRC16) is made via the CCITT table algorithm for all characters.

After receiving the start code, the timeout monitoring is activated in order to avoid that Compax3 waits in vain for further codes (e.g. connection interrupted) The

timeout period between 2 codes received is fixed to 5ms (5 times the code time at 9600Baud)

Write object - WrObj telegram

SZ	Adr	L	D0	D1	D2	D3 ... Dn	Crc(Hi)	Crc(Lo)
0xCX		n	Index(Hi)	Index(Lo)	Subindex	Value	0x..	0x..

Describing an object by a value.

Positive acknowledgement - Ack-telegram

SZ	L	D0	D1	Crc(Hi)	Crc(Lo)
0x06	1	0	0	0x..	0x..

Answer from Compax3 if a writing process was successful, i.e. the function could be executed and is completed in itself.

Negative acknowledgement - Nak - telegram

SZ	L	D0	D1	Crc(Hi)	Crc(Lo)
0x07	1	F-No.(Hi)	F-No.(Lo)	0x..	0x..

Answer from Compax3 if access to the object was denied (e.g. function cannot be executed at that point in time or object has no reading access). The error no. is coded according to the DriveCom profile resp. the CiA Device Profile DSP 402.

Read object - RdObj - telegram

SZ	Adr	L	D0	D1	D2	D3	D4	D5	...	Dn	Crc(Hi)	Crc(Lo)
0xAX		n	Index1(Hi)	Index1(Lo)	Subindex1	Index2(Hi)	Index2(Lo)	Subindex2	0x..	0x..

Reading one or several objects

Answer - Rsp - telegram

SZ	L	D0 ... Dx-1	Dx ... Dy-1	Dy-D..	D ... D..	D ... Dn	Crc(Hi)	Crc(Lo)
0x05	n	Value1	Value 2	Value 3	Value ..	Value n	0x..	0x..

Answer from Compax3 if the object can be read.

If the object has no reading access, Compax3 answers with the Nak - telegram.

Example:

Reading object "StatusPositionActual" (0680.5):

Request: A5 03 02 02 A8 05 E1 46

Response: 05 05 FF FF FF FF FE 2D 07 B4

Writing into an Array (01901.1 = 2350)

Request: C5 02 08 07 6D 01 00 09 2E 00 00 00 95 D5

Response: 06 01 00 00 BA 87

Block securing:

Checksum calculation for the CCITT table algorithm

The block securing for all codes is performed via the following function and the corresponding table:

The "CRC16" variable is set to "0" before sending a telegram.

Function call:

```
CRC16 = UpdateCRC16(CRC16, Character);
```

This function is called up for each Byte (Character) of the telegram.

The result forms the last two bytes of the telegram

Compax3 checks the CRC value on receipt and reports CRC error in the case of a deviation.

```
Function  const unsigned int _P CRC16_table[256] = {
    0x0000, 0x1021, 0x2042, 0x3063, 0x4084, 0x50a5, 0x60c6, 0x70e7,
    0x8108, 0x9129, 0xa14a, 0xb16b, 0xc18c, 0xd1ad, 0xe1ce, 0xf1ef,
    0x1231, 0x0210, 0x3273, 0x2252, 0x52b5, 0x4294, 0x72f7, 0x62d6,
    0x9339, 0x8318, 0xb37b, 0xa35a, 0xd3bd, 0xc39c, 0xf3ff, 0xe3de,
    0x2462, 0x3443, 0x0420, 0x1401, 0x64e6, 0x74c7, 0x44a4, 0x5485,
    0xa56a, 0xb54b, 0x8528, 0x9509, 0xe5ee, 0xf5cf, 0xc5ac, 0xd58d,
    0x3653, 0x2672, 0x1611, 0x0630, 0x76d7, 0x66f6, 0x5695, 0x46b4,
    0xb75b, 0xa77a, 0x9719, 0x8738, 0xf7df, 0xe7fe, 0xd79d, 0xc7bc,
    0x48c4, 0x58e5, 0x6886, 0x78a7, 0x0840, 0x1861, 0x2802, 0x3823,
    0xc9cc, 0xd9ed, 0xe98e, 0xf9af, 0x8948, 0x9969, 0xa90a, 0xb92b,
    0x5af5, 0x4ad4, 0x7ab7, 0x6a96, 0x1a71, 0x0a50, 0x3a33, 0x2a12,
    0xdbfd, 0xcbdc, 0xfbbf, 0xeb9e, 0x9b79, 0x8b58, 0xbb3b, 0xab1a,
    0x6ca6, 0x7c87, 0x4ce4, 0x5cc5, 0x2c22, 0x3c03, 0x0c60, 0x1c41,
    0xedae, 0xfd8f, 0xcdec, 0xddcd, 0xad2a, 0xbd0b, 0x8d68, 0x9d49,
    0x7e97, 0x6eb6, 0x5ed5, 0x4ef4, 0x3e13, 0x2e32, 0x1e51, 0x0e70,
    0xff9f, 0xefbe, 0xdfdd, 0xcffc, 0xbf1b, 0xaf3a, 0x9f59, 0x8f78,
    0x9188, 0x81a9, 0xb1ca, 0xa1eb, 0xd10c, 0xc12d, 0xf14e, 0xe16f,
    0x1080, 0x00a1, 0x30c2, 0x20e3, 0x5004, 0x4025, 0x7046, 0x6067,
    0x83b9, 0x9398, 0xa3fb, 0xb3da, 0xc33d, 0xd31c, 0xe37f, 0xf35e,
    0x02b1, 0x1290, 0x22f3, 0x32d2, 0x4235, 0x5214, 0x6277, 0x7256,
    0xb5ea, 0xa5cb, 0x95a8, 0x8589, 0xf56e, 0xe54f, 0xd52c, 0xc50d,
    0x34e2, 0x24c3, 0x14a0, 0x0481, 0x7466, 0x6447, 0x5424, 0x4405,
    0xa7db, 0xb7fa, 0x8799, 0x97b8, 0xe75f, 0xf77e, 0xc71d, 0xd73c,
    0x26d3, 0x36f2, 0x0691, 0x16b0, 0x6657, 0x7676, 0x4615, 0x5634,
    0xd94c, 0xc96d, 0xf90e, 0xe92f, 0x99c8, 0x89e9, 0xb98a, 0xa9ab,
    0x5844, 0x4865, 0x7806, 0x6827, 0x18c0, 0x08e1, 0x3882, 0x28a3,
    0xcb7d, 0xdb5c, 0xeb3f, 0xfb1e, 0x8bf9, 0x9bd8, 0xabbb, 0xbb9a,
    0x4a75, 0x5a54, 0x6a37, 0x7a16, 0x0af1, 0x1ad0, 0x2ab3, 0x3a92,
    0xfd2e, 0xed0f, 0xdd6c, 0xcd4d, 0xbdaa, 0xad8b, 0x9de8, 0x8dc9,
    0x7c26, 0x6c07, 0x5c64, 0x4c45, 0x3ca2, 0x2c83, 0x1ce0, 0x0cc1,
    0xef1f, 0xff3e, 0xcf5d, 0xdf7c, 0xaf9b, 0xbfba, 0x8fd9, 0x9ff8,
    0x6e17, 0x7e36, 0x4e55, 0x5e74, 0x2e93, 0x3eb2, 0x0ed1, 0x1ef0
};

unsigned int UpdateCRC16(unsigned int crc,unsigned char wert) {

unsigned int crc16;

crc16 = (CRC16_table[(crc >> 8) & 0x00FF] ^ (crc << 8)
^ (unsigned int)(value));

return crc16;

}

```

You will find this function on the Compax3 DVD under RS232_485\\Function UpdateCRC16.txt!

5.3 Remote diagnosis via Modem

In this chapter you can read about:

Structure.....308
 Configuration of local modem 1309
 Configuration of remote modem 2.....310
 Recommendations for preparing the modem operation.....310

Caution!

As the transmission via modem may be very slow and interference-prone, the operation of the Compax3 ServoManager via modem connection is on your own risk!

The function setup mode as well as the ROLL mode of the oscilloscope are not available for remote diagnosis!


It is not recommended to use the logic analyzer in the Compax3 IEC61131-3 debugger due to the limited bandwidth.

Requirements:

For modem operation, a direct and stable telephone connection is required. Operation via a company-internal telephone system is not recommended.

5.3.1. Structure

Layout and configuration of a modem connection ServoManager - Compax3:



The green part of the drawing shows the proceeding for Compax3 release versions < R5-0!

The proceeding for Compax3 release versions < R5-0 is described in an application example (.../modem/C3_Appl_A1016_ *language*.pdf on the Compax3 CD).

Connection Compax3 ServoManager <=> Compax3

The Compax3 ServoManager (1) establishes a RS232 connection with modem 1 (PC internal or external).

Modem 1 dials modem 2 via a telephone connection (3).

Modem 2 communicates with Compax3 (6) via RS232.

Configuration

Modem 1 is configured via the Compax3 ServoManager (1)

Modem 2 can be configured via Compax3 (on place), triggered by putting **SSK31** (see on page 387) on X10. For this, the device must be configured before. This can be made locally before the system / machine is delivered with the aid of the Compax3 ServoManager (8).

5.3.2. Configuration of local modem 1

- ◆ Menu "Options: Communication settings RS232/RS485..." must be opened
- ◆ Select "Connection via Modem"
- ◆ Under "name" you can enter a name for the connection
- ◆ Enter the target telephone number.
 - Note: If an ISDN telephone system is operated within a company network, an additional "0" may be required in order to get out of the local system into the company network before reaching the outside line with an additional "0".
- ◆ The timeout periods are set to reasonable standard values according to our experience.
- ◆ Select the modem type.
 - ◆ For "user-defined modem", additional settings are only required, if the modem does not support standard AT commands.
 - Then you can enter special AT commands.
 - ◆ **Hint:**When operating the local modem on a telephone system, it may be necessary to make a blind dialing. Here, the modem does not wait for the dialing tone.
- ◆ Select the COM interface where the modem is connected.
- ◆ Close the window and establish the connection with button  (open/close COM port).
- ◆ The connection is interrupted when the COM port is closed.
- ◆ Select the modem type.
 - ◆ For "user-defined modem", additional settings are only required, if the modem does not support standard AT commands.
 - Then you can enter special AT commands.
 - ◆ **Hint:**When operating the local modem on a telephone system, it may be necessary to make a blind dialing. Here, the modem does not wait for the dialing tone.

5.3.3. Configuration of remote modem 2

Settings in Compax3 under "configure communication: Modem settings":

- ◆ Modem initialization = "ON": After the SSK31 modem cable has been connected, Compax3 initializes the modem
- ◆ Modem initialization after Power On = "ON": After Power on of Compax3, the device initializes the modem
- ◆ Modem check = "ON": a modem check is performed
- ◆ The timeout periods are set to reasonable standard values according to our experience.
- ◆ Select the modem type.
 - ◆ For "user-defined modem", additional settings are only required, if the modem does not support standard AT commands. Then you can enter special AT commands.
 - ◆ **Hint:**When operating the local modem on a telephone system, it may be necessary to make a blind dialing. Here, the modem does not wait for the dialing tone.
- ◆ In the following wizard window, a specific download of the modem configuration can be made.

Note:

If a configuration download is interrupted, the original settings in the non volatile memory of the Compax3 are still available.

You have to finish the communication on the PC side and to reset the Compax3 via the 24V supply before you can start a new trial.

Reinitialization of the remote modem 2

Remove cable on Compax3 X10 and connect again!

5.3.4. Recommendations for preparing the modem operation

Preparations:

- ◆ Settings in Compax3 under "configure communication: Modem settings":
 - ◆ Modem initialization: "ON"
 - ◆ Modem initialization after Power On: "ON"
 - ◆ Modem check: "ON"
- ◆ Deposit SSK31 cable in the control cabinet.
- ◆ Install modem in the control cabinet and connect to telephone line.

Remote diagnosis required:

- ◆ On site:
 - ◆ Connect modem to Compax3 X10 via SSK31
 - ◆ Modem is automatically initialized
- ◆ Local:
 - ◆ Connect modem to telephone line
 - ◆ Establish cable connection to modem (COM interface)
 - ◆ Select "connection via modem" under "options: communication settings RS232/RS485...".
 - ◆ Select modem under "selection"
 - ◆ Enter telephone number
 - ◆ Select COM interface (PC - modem)
 - ◆ Establish connection with button  (open/close COM port).

5.4 DeviceNet

In this chapter you can read about:

DeviceNet Configuration.....	311
Error Reaction on Bus Failure.....	311
DeviceNet Operating modes.....	312
State machine	327
DeviceNet object classes.....	329
DeviceNet application description.....	340

Please note:

A changed assignment (mapping) of the Input/Output Message is accepted with Power off / Power on!

The length of the Input / Output Message is adapted to the real assignment (mapping) (2...32).

Statement of Conformance

http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf (in the Internet)

Address or Baud rate settings (see on page 65)

Connector assignment (see on page 65)

5.4.1. DeviceNet Configuration

Following are described the input windows of the configuration wizard.

Can be called up in the tree (Compax3 ServoManager, left window) under "configure configuration".

5.4.2. Error Reaction on Bus Failure

Here you can set how Compax3 shall respond to a react on a **Bus error** (see on page 342)l:

Possible settings for the error reaction are:

- ◆ No response
- ◆ Downramp / stop
- ◆ Downramp / stromlos schalten (standard settings)

5.4.3. DeviceNet Operating modes

In this chapter you can read about:

Operating mode: Speed control	313
Operating mode: Direct positioning	314
Operating mode: Positioning with set selection	316
Controlword /Statusword	318

◆

◆

- ◆ **CN (Controlled Node) in Velocity Mode - Velocity control:** The nominal rotation speed is specified via DeviceNet and the actual values are read back.
- ◆ **CN (Controlled Node) in Position Mode - Direct positioning:** The nominal position is specified via DeviceNet and the actual values are read back.
- ◆ **CN (Controlled Node) with set selection:** activation of motion sets stored in an array via DeviceNet.

Additional operating modes can be set via the object "**operating mode**" (see on page 318)" (C3-Objekt-Class Instanz 1100 Attribut 5).

5.4.3.1 Operating mode: Speed control

The communication between Master and Compax3 is made via the I/O messages

Design of the I/O messages: DeviceNet – Master -> Compax3

Controlword	Operating mode	Target velocity						
OW _n	OW _{n+2}	OW _{n+4}	OW _{n+6}	OW _{n+8}	OW _{n+10}	OW _{n+12}	OW _{n+14}	OW _{n+16}

Possible assignment:

Designation	Object No. Instance.Attribute	Assigned words	Assignment
Controlword (see on page 318) (control word 1)	1100.3	1	optional
Operating mode	1100.5	1	optional
Target velocity (3 decimal places)*	1100.6	2	optional
Dig. Outputs (0-3) O3)	140.3	1	optional
Dig. outputs M1x option (digital outputs of the M10/M12 option)	133.3	1	optional

Layout of the **control word** (see on page 318).

Design of the I/O messages: Compax3 -> DeviceNet – Master

Status word								
IW _n	IW _{n+2}	IW _{n+4}	IW _{n+6}	IW _{n+8}	IW _{n+10}	IW _{n+12}	IW _{n+14}	IW _{n+16}

Possible assignment:

Designation	Object No. Instance.Attribute	Assigned words	Assignment
Status word (see on page 321) (Status word 1)	1000.3	1	optional
Operating mode display	1000.5	1	optional
Velocity actual value Y4 (3 decimal places)*	681.5	2	optional
Torque actual value	683.1	1	optional
Dig. inputs (0-7) I7)	120.3	1	optional
Dig. inputs M1x option (Digital outputs of the M10/M12 option)	121.2	1	optional
LastError (current Compax3 errors)	550.1	1	optional

* The values are transmitted as int16 (1 word) or int32 (2 words).

With 1 decimal place: Divide value by 10.

With 3 decimal places: Divide value by 1000.

Example:

PLC Value	Compax3 value	
1000	1.000	(3 decimal places)
10	1.0	(1 decimal place)

Layout of the **Status word**. (see on page 321)

5.4.3.2 Operating mode: Direct positioning

The communication between Master and Compax3 is made via the I/O messages
 Procedure:

Selection of the motion function: Bit 15, 13, 6 of the control word 1

Start of the motion function: Bit 4 of the control word 1

Specification of the motion parameters: Objects of the I/O messages

Design of the I/O messages: DeviceNet – Master -> Compax3

Controlword	Operating mode	Target position						
Iw _n	Iw _{n+2}	Iw _{n+4}	Iw _{n+6}	Iw _{n+8}	Iw _{n+10}	Iw _{n+12}	Iw _{n+14}	Iw _{n+16}

Possible assignment:

Designation	Object No. Instance.Attribute	Assigned words	Assignment
Controlword (Control word 1)	1100.3	1	optional
Operating mode	1100.5	1	optional
Target position (position command value) (3 decimal places)*	1100.6	2	optional
Profile velocity (1 decimal place)*	1100.8	1	optional
Profile velocity (3 decimal places)*	1100.7	2	optional
Profile acceleration (no decimal place)	1111.10	1	optional
Profile acceleration (no decimal place)	1111.3	2	optional
Profile deceleration (no decimal place)	1111.16	1	optional
Profile deceleration (no decimal place)	1111.4	2	optional
Dig. Outputs (0-3) O3)	140.3	1	optional
Dig. outputs M1x option (digital outputs of the M10/M12 option)	133.3	1	optional

* The values are transmitted as int16 (1 word) or int32 (2 words).

With 1 decimal place: Divide value by 10.

With 3 decimal places: Divide value by 1000.

Example:

PLC Value	Compax3 value	
1000	1.000	(3 decimal places)
10	1.0	(1 decimal place)

Layout of the **control word** (see on page 318).

Profile velocity Y2 and Y4 do have the same function, they differ only in the word width.

The same applies for Profile acceleration U16 / 832 and Profile deceleration U16 / U32.

You should therefore only use one of these two values.

Attention: The meanings of the assignments change with the Gearing motion function:
 Target position (position command value) = Gearing numerator

Design of the I/O messages: Compax3 -> DeviceNet – Master

Status word								
Iw _n	Iw _{n+2}	Iw _{n+4}	Iw _{n+6}	Iw _{n+8}	Iw _{n+10}	Iw _{n+12}	Iw _{n+14}	Iw _{n+16}

Possible assignment:

Designation	Object No. Instance.Attribute	Assigned words	Assignment
Status word (Status word 1)	1000.3	1	optional
Operating mode display	1000.5	1	optional
Position actual value (3 decimal places)*	680.5	2	optional
Velocity actual value (3 decimal places)*	681.5	2	optional
Velocity actual value (1 decimal place)*	681.7	1	optional
Torque actual value	683.1	1	optional
Follow error actual value	680.6	1	optional
Dig. inputs (0-7) I7)	120.3	1	optional
Dig. inputs M1x option (Digital outputs of the M10/M12 option)	121.2	1	optional
LastError (current Compax3 errors)	550.1	1	optional

* The values are transmitted as int16 (1 word) or int32 (2 words).

With 1 decimal place: Divide value by 10.

With 3 decimal places: Divide value by 1000.

Example:

PLC Value	Compax3 value	
1000	1.000	(3 decimal places)
10	1.0	(1 decimal place)

Layout of the **Status word**. (see on page 321)

For values not transferred the standard values defined in the configuration wizard are valid!

The jerk can be changed for example via Explicit Messages.

5.4.3.3 Operating mode: Positioning with set selection

The communication between Master and Compax3 is made via the die I/O Message

Procedure:

Defining the motion sets with the Compax3 ServoManager or via Explicit Messages.

Selecting the desired motion set via control word 2

Start the motion with control word 1 Bit 4.

Layout die I/O Message: DeviceNet – Master -> Compax3

Controlword	Controlword2							
OW _n	OW _{n+2}	OW _{n+4}	OW _{n+6}	OW _{n+8}	OW _{n+10}	OW _{n+12}	OW _{n+14}	OW _{n+16}

Possible assignment:

Designation	Object No. Instance.Attribute	Assigned words	Assignment
Controlword (Control word 1)	1100.3	1	optional
Controlword2 (control word 2)	1100.4	1	optional
Operating mode	1100.5	1	optional
Dig. Outputs (0-3) O3)	140.3	1	optional
Dig. outputs M1x option (digital outputs of the M10/M12 option)	133.3	1	optional

Layout of the **control word** (see on page 318).

Layout of die I/O Message: Compax3 -> DeviceNet – Master

Status word								
IW _n	IW _{n+2}	IW _{n+4}	IW _{n+6}	IW _{n+8}	IW _{n+10}	IW _{n+12}	IW _{n+14}	IW _{n+16}

Possible assignment:

Designation	Object No. Instance.Attribute	Assigned words	Assignment
Status word (Status word 1)	1000.3	1	optional
Statusword2 (status word 2)	1000.4	1	optional
Position actual value (3 decimal places)*	680.5	2	optional
Velocity actual value (3 decimal places)*	681.5	2	optional
Torque actual value	683.1	1	optional
Follow error actual value	680.6	1	
Dig. inputs (0-7) I7)	120.3	1	optional
Dig. inputs M1x option (Digital outputs of the M10/M12 option)	121.2	1	optional
Operating mode display	1000.5	1	optional
LastError (current Compax3 errors)	550.1		

* The values are transmitted as int16 (1 word) or int32 (2 words).

With 1 decimal place: Divide value by 10.

With 3 decimal places: Divide value by 1000.

Example:

PLC Value	Compax3 value	
1000	1.000	(3 decimal places)
10	1.0	(1 decimal place)

Layout of the **Status word**. (see on page 321)

Defining sets: Please use the Compax3 ServoManager or the explicit messages in order to enter the motion sets.

Layout of the **Set table** (see on page 317).

Layout of the set table

In this chapter you can read about:

General layout of the table.....317
 Assignment of the different motion functions.....317
 Definition of the states of the programmable status bits (PSBs):.....318

The motion sets are memorized in an object table. The table has 9 columns and 32 rows.

A motion set is stored in a table row.

The assignment of the columns depends on the motion function.

General layout of the table

	Column 1 Type: REAL objects O1901	Column 2 Type: REAL objects O1902	Column 3 Type: INT objects O1903	Column 4 Type: INT objects O1904	Column 5 Type: INT objects O1905	Column 6 Type: DINT objects O1906	Column 7 Type: DINT objects O1907	Column 8 Type: DINT objects O1908	Column 9 Type: DINT objects O1909
Set 1	Row 1 "Array_Col1_Row1" (1901.1)	Row 1 "Array_Col2_Row1" (1902.1)	Row 1 "Array_Col3_Row1" (1903.1)	Row 1 "Array_Col4_Row1" (1904.1)	Row 1 "Array_Col5_Row1" (1905.1)	Row 1 "Array_Col6_Row1" (1906.1)	Row 1 "Array_Col7_Row1" (1907.1)	Row 1 "Array_Col8_Row1" (1908.1)	Row 1 "Array_Col9_Row1" (1909.1)
set no. 2
Set 3
...
Set 31	Row 31 "Array_Col1_Row31" (1901.31)	Row 31 "Array_Col2_Row31" (1902.31)	Row 31 "Array_Col3_Row31" (1903.31)	Row 31 "Array_Col4_Row31" (1904.31)	Row 31 "Array_Col5_Row31" (1905.31)	Row 31 "Array_Col6_Row31" (1906.31)	Row 31 "Array_Col7_Row31" (1907.31)	Row 31 "Array_Col8_Row31" (1908.31)	Row 31 "Array_Col9_Row31" (1909.31)

You will find the respective object number in brackets.

Assignment of the different motion functions

The columns 3 and 9 are reserved.

Motion	Column 1	Column 2	Column 4	Column 5	Column 6	Column 7	Column 8
	Type: REAL Objects O1901 Positions	Type: REAL Objects O1902 Speed	Type: INT Objects O1904 (PSBs)	Type: INT Objects O1905 Mode	Type: DINT Objects O1906 Accelerations	Type: DINT Objects O1907 Deceleration / denominator	Type: DINT Objects O1908 Jerk
MoveAbs (see on page 148)	Target position	Speed	PSBs	1 (for MoveAbs)	Accel	Decel	Jerk
MoveRel (see on page 148)	Distance	Speed	PSBs	2 (for MoveRel)	Accel	Decel	Jerk
Gearing (see on page 153)	-	Numerator	PSBs	3 (for Gearing)	Accel	Denominator	-
RegSearch	Distance	Speed	PSBs	4 (for RegSearch)	Accel	Decel	Jerk
RegMove (see on page 149)	Offset	Speed	PSBs	5 (for RegMove)	-	-	-
Velocity (see on page 154)	-	Speed	PSBs	6 (for Velocity)	Accel	-	-
STOP	-	-	PSBs	7 (for Stop)	-	Decel	Jerk

Definition of the states of the programmable status bits (PSBs):

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
factory use	Enable2 PSB2	Enable1 PSB1	Enable0 PSB0	factory use	PSB2	PSB1	PSB0
	="1": Set PSB ="0": leave PSB unchanged						

The Bits 0 ... 2 monitor the states of the status bits at the end of a motion set, if the bits were enabled via the respective Enable.

If Enable is set to "0", the respective PSB remains unchanged at the end of the motion set.

PSB0: Status word 2 Bit 12

PSB1: Status word 2 Bit 13

PSB2: Status word 2 Bit 14

5.4.3.4 Controlword /Statusword

In this chapter you can read about:

- Control word 1 (Controlword 1).....
- Status word 1 (Status word)
- Interpolated Position / Cyclic Synchronous Position Mode.....

Control word 1 (Controlword 1)

Operating mode BA C3-Objekt-Class Instanz 1100 Attribut 5.							
Bit	Direct Positioning (Profile Position)	Positioning with set selection (Position Record Select)	Velocity control (Profile Velocity) Setpoint value = 0x60FF (Object 1100.13)	Machine zero (Homing)	Manual operation (Jogging)	Interpolated Position (ip-mode) ^{2) 3)}	Cyclic Synchronous Position (csp-mode) ^{2) 4)}
	BA = "1"	BA = "-2"	BA = "3"	BA = "6"	BA = "-1"	BA = "7"	BA = "8"

0	="1": Switch on					
1	="1": Enable Voltage					
2	="0": Quick stop					
3	="1": Enable Operation					
4	= "1": New set-point (Start)	Reserved	= "1": Homing operation start (activate homing run)	= "1": Jog+ (Manual+)	= "1": Enable ip mode	-
5	= "1": Change set immediately ¹⁾ (dynamic Positioning (see on page 155))	Reserved	Reserved	= "1": Jog- (Manual-)		
6	Mode 2 (see below)	Reserved	Reserved	Reserved	Reserved	
7	="1": Fault reset (Quit, with positive edge)					
8	= "1": Halt (Stop without termination) (for Velocity and Gearing: Stop with termination)	= "1": Halt (Stop without termination)	= "1": Halt (Stop with termination)	= "1": Halt (Stop without termination)	= "1": Halt (Stop with termination)	
9	Reserved					
10	Reserved					
11	="0": Remote Control: Control word active, i.e. control DeviceNet ="1": Local Control: Control word inactive, i.e. the control word is not read; direct control via inputs (see on page 144) possible.					
12	Reserved	Reserved	Reserved			
13	Mode 1 (see below)	Reserved	Reserved			
14	= "1": Endless (continuous operation) in normal operation (= "0") homing is required	Reserved	Reserved			
15	Mode 0 (see below)	Reserved	Reserved			

1) With Bit 5 = "0" no dynamic change of record is possible - not even to a STOP record.

Only after the end of the record (position reached), the next record will be accepted.

2) Operating mode is not supported with DeviceNet (I22).

3) Interpolated Position Mode (see on page 322)

4) Cyclic Synchronous Position (see on page 322)

Change operating mode: When changing the operating mode (via Mode 0 ... 2) will trigger a "Stop", if the drive is still moving.
Changing from "Profile Velocity" to another operating mode is only possible in currentless state.

Selection of the positioning mode in the "direct positioning" operating mode

Mode 0 CW.15	Mode1 CW.13	Mode2 CW.6	Function
0	0	0	MoveAbs (see on page 148): Absolute positioning
0	0	1	MoveRel (see on page 148): Relative positioning
0	1	0	MoveAdd (see on page 320): * Additive Positioning
0	1	1	Velocity (see on page 154): Speed control
1	0	0	Gearing (see on page 153): Electronic Gearbox (Gearing)
1	0	1	RegMove (see on page 149): Reg-related positioning
1	1	0	RegSearch (see on page 149): Reg-related positioning
1	1	1	Reserved

The setpoint specification is made via target position Y4 (0x2044 / 0x607A, object 1100.6)

* Relative; Example

- ◆ Positioning mode: absolute
- ◆ Target position = 1000
- ◆ Positioning mode: relative
- ◆ Command: Target position = 200 for actual position 500
- ◆ Drive travels to 700

Additive; example

- ◆ Positioning mode: absolute
- ◆ Target position = 1000
- ◆ Positioning mode: additive
- ◆ Command: Target position = 200 for actual position arbitrary
- ◆ Drive travels to 1200

Control word 2

In the "Positioning with set selection" operating mode, the address of the motion set is specified via control word 2

Bit	Description
0	Address 0 for set selection
1	Address 1 for set selection
2	Address 2 for set selection
3	Address 3 for set selection
4	Address 4 for set selection
5 ... 15	factory use

Status word 1 (Status word)

Operating mode BA C3-Objekt-Class Instanz 1100 Attribut 5.							
Bit	Direct Positioning (Profile Position)	Positioning with set selection (Position Record Select)	Velocity Control (Profile Velocity)	Machine zero (Homing)	Manual operation (Jogging)	Interpolated Position 2) (ip-mode)	Cyclic Synchronous Position (csp-mode) 2)
	BA = "1"	BA = "-2"	BA = "3"	BA = "6"	BA = "-1"	BA = "7"	BA = "8"
0	="1": Ready to switch on						
1	="1": Switched on						
2	="1": Operation enable						
3	="1": Fault (Compax3 reports error)						
4	="0": Voltage enable						
5	="0": Quick stop						
6	="1": Switch on disable						
7	factory use						
8	="1": Speed=0 (drive motionless)						
9	="1": Remote (parameters can be changed via DeviceNet)						
10	="1": Target reached (corresponds to Position / Speed / Gearing reached)						0
11	="1": Internal limit active						
12	="1": Setpoint acknowledge (new setpoint value is accepted)	="1": Speed=0	="1": Homing attained (referenced)	0	="1": ip mode active	"0": Target ignore "1": Target accepted	
13	="1": Following error	0	="1": Homing error	0	-	="1": Following error	
14	0	0	0	0	0		
15	="1": Registration found (Registration mark detected)		0	0	0		

2) Operating mode "interpolated" is not supported with DeviceNet.

Status word 2

Status word 2 in the "Positioning with set selection" operating mode contains the selected set number as well as the PSBs.

Bit	Description
0	Address 0 of the current set
1	Address 1 of the current set
2	Address 2 of the current set
3	Address 3 of the current set
4	Address 4 of the current set
5 ... 11	factory use
12	Programmable status bit 0 (PSB0)
13	Programmable status bit 1 (PSB1)
14	Programmable status bit 2 (PSB2)
15	factory use

Interpolated Position / Cyclic Synchronous Position Mode

[In this chapter you can read about:](#)

"Interpolated Position Mode" operating mode	322
Operating mode: Cyclic Synchronous Position.....	322
Interpolation method.....	322
Synchronizations method	325

The interpolated position / cyclic synchronous position modes are necessary for the coordinated movement of dependent axes or for moving individual axes with temporal interpolation of the setpoint values. With this, time synchronization mechanisms such as the synchronization object are used for the temporal coordination of the connected drive axes.

“Interpolated Position Mode” operating mode

The operating mode switching (**C3-Objekt-Class Instanz 1100 Attribut 5=7**) (see on page 318) to "Interpolated Position Mode" takes place during operation (via the bus) and is not supported by the configuration in the ServoManager.

The command position of the "Interpolated Position mode" is preset via the bus object 3921.1 "Interpolation data". This bus object can be mapped to the telegram in the "Position Mode".

The "Interpolated Position Mode" works in SYNC operation; the cycle time is preset via bus object 0x1006; please respect the ratings.

Gearing is not possible in the "interpolated" operating mode.

Operating mode: Cyclic Synchronous Position

The operating mode switching (**C3-Objekt-Class Instanz 1100 Attribut 5=8**) (see on page 318) to "Cyclic Synchronous Position" takes place during operation (via the bus) and is not supported by the configuration in the ServoManager.

The command position of the "Cyclic Synchronous Position" is preset via the bus object 1100.6 "Target position". This bus object can be found on the telegram in the "Position Mode".

The "Cyclic Synchronous Position" operating mode works in SYNC operation; the cycle time is preset via bus object 0x1006; please respect the ratings.

Gearing is not possible in the "Cyclic Synchronous Position" operating mode.

Interpolation method**In this chapter you can read about:**

Linear Interpolation (o3925.1 = 0 or o3925.1 = -1)	323
Quadratic interpolation (o3925.1=-2)	324
Cubical interpolation (o3925.1=-3)	325

Setting the interpolation method via object 3925.1 (CANopen No.: 0x60C0.0)

0=linear Interpolation (Default)

- ◆ -1=linear Interpolation
- ◆ -2=Quadratic Interpolation
- ◆ -3=Cubical (Spline-) Interpolation


Caution! Do only switch while the drive is deactivated!

Linear Interpolation (o3925.1 = 0 or o3925.1 = -1)

With the transmitted position and the position in the previous bus cycle, a straight of the $Y(t)=a*t + b$ is calculated. The speed within a bus cycle remains constant. This method is only implemented for the PLL synchronization.

- ◆ **Advantage:** Support of a reset value range
- ◆ **Disadvantage:** During the transition to a new bus cycle, a speed leap may occur.

Example:




Quadratic interpolation (o3925.1=-2)

With the aid of the position received last and the positions from the two previous bus cycles, the polynomial coefficients of the polynomial

$Y(t) = a * t^2 + b * t + c$ are determined. The speed within a bus cycle is a first order function, i.e. the acceleration is constant.

- ◆ **Advantage:** Consistent course of speed
- ◆ **Disadvantage:** The Interpolation method does not support a reset value range.

Example:




Cubical interpolation (o3925.1=-3)

With the aid of the last position received, and the three previous values, the polynomial coefficients of the polynomial

$Y(t) = a * t^3 + b * t^2 + c * t$ are determined. The speed within a bus cycle can change quadratically, i.e. the acceleration is a first order function.

- ◆ **Advantages:** Consistent course of speed and acceleration
- ◆ **Disadvantages:** This method may lead to overshoot in the interpolated position.
The Interpolation method does not support a reset value range.

Example:



Synchronizations method

Caution!

The same operation is not possible with HEDA

Errors caused by different bus cycle times are not reported!

Process data transmission is also synchronized and does not take place at different bus cycle times.

Selection of the synchronization method

the selection is made via object 820.24. The selection is only accepted, if the bus cycle time (Bus object 0x1006) is written anew. Changes of the synchronization method and of the bus cycle time should only be made while the controller is deactivated.

PLL synchronization (Object 820.24 = 0)

During the PLL synchronization, the system clock of the slave device is synchronized to the system clock of the master with the aid of a phase control loop. This ensures that all devices are running in the same time frame.

Advantages: Exact synchronization of the setpoint acceptance from the master, synchronized acquisition of the actual values

Disadvantages: Relatively high requirements for the periodicity of the sync-telegram, i.e. the jitter must be small. For CANSync on Compax3, the maximum permitted jitter is about 50µs.

If the master allows only a vague synchronization (high jitter), it is possible to use Compax3 as SYNC generator: use the CANopen communication parameter 1105.0 (for details please refer to the DS402 specifications).

Timestamp method (Object 820.24 = 1)


During the timestamp method, the slave is not synchronized to the master clock. Instead, the time between two subsequent sync-telegrams is measured. The received position demand values or the values derived from them (e.g. speed) are scaled with the measured time.

Advantages: Relatively insensitive to jitter

Disadvantages: The actual value acquisition is not synchronized to the master. This may lead to "beats".

Linear interpolation is not possible with the timestamp method.

5.4.4. State machine



0, 1, 2, ... : Status transitions

Status values:

Designation	Explanation
Not Ready to Switch On	Control voltage switched on Initialization Brake closed Not ready to turn on
Switch On Disable	Initialization completed Parameter values can be changed Power supply voltage switched off Travel commands not possible
Ready to Switch on	Power supply voltage can be switched on Parameter values can be changed Travel commands not possible
Switched on	Power supply voltage switched on Parameter values can be changed Travel commands not possible Motor de-energized
Operation enable	Motor powered Compax3 is ready for carrying out travel commands Parameter values can be changed
Quick Stop active	The "Quick Stop" function has been executed Motor powered Parameter values can be changed
Fault reaction 1 active	A fault has occurred The motor is stopped with the ERROR_decel and ERROR_jerk ramp and remains energized. Parameter values can be changed
Fault 1	Error state, motor energized, error can be read Travel commands not possible Parameter values can be changed A positive flank is expected at FAULT RESET
Fault reaction 2 active	A fault has occurred The motor is stopped with the ERROR_decel and ERROR_jerk ramp and is deenergized at standstill. Parameter values can be changed
Fault 2	Error state, motor deenergized, error can be read Travel commands not possible Parameter values can be changed A positive flank is expected at FAULT RESET

Function of the device status LEDs (see on page 28)

Transitions:

For various transitions, for which Compax3 leaves the status "Operation Enable" (travel commands may be active), various ramps can be set. That is:

Transition	associated ramp objects
5, 11	STOP_decel (Object 1113.1), STOP_jerk ((Object 1113.2)
8	FSTOP1_decel (Object 1116.1), FSTOP1_jerk (Object 1116.2)
9	FSTOP3_decel (Object 1118.1), FSTOP3_jerk (Object 1118.2)
13.17	ERROR_decel (Object 1125.1), ERROR_jerk (Object 1125.2)

5.4.5. DeviceNet object classes

In this chapter you can read about:

Overview of the DeviceNet object classes.....330
 Object classes330
 Manufacturer-specific object class331
 Data formats of the bus objects.....337

The DeviceNet object classes described in this chapter are either set to sensible standard values or they are set under menu control with the help of the ServoManager.

The communication objects described below must be modified only for special deviating settings.

DeviceNet characteristics (I22)

DeviceNet	<ul style="list-style-type: none"> ◆ Predefined Master/Slave Connection Set ◆ Standard 2.0 Group-2-Slave ◆ Fieldbus I/O Data or Process Data (Polled, COS/Cyclic I/O and Bit Strobe)
Implemented object classes	<ul style="list-style-type: none"> ◆ Identify, Message Router, DeviceNet, Assembly, Connection, Acknowledge Handler
Baud rate [kBit/s]	<ul style="list-style-type: none"> ◆ 125, 250, 500
permissible cable length	<ul style="list-style-type: none"> ◆ up to 500m on 125Bit/s, ◆ up to 200m on 250Bit/s, ◆ up to 100m on 500Bit/s,
Max. Number of participants	<ul style="list-style-type: none"> ◆ 63 Slave
Insulation	<ul style="list-style-type: none"> ◆ Isolated Device Physical Layer
EDS file	<ul style="list-style-type: none"> ◆ C3_DeviceNet.EDS
Conformance (file in the Internet)	<ul style="list-style-type: none"> ◆ Statement of Conformance http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf
Further information:	<ul style="list-style-type: none"> ◆ Application example (C3I22_DeviceNet.ZIP) on the Compax3 CD in the "Examples" directory"

5.4.5.1 Overview of the DeviceNet object classes

Object name	Class ID	Instance ID	Description
Identify	0x01	1	Mandatory
Message Router	0x02	1	Mandatory
DeviceNet	0x03	1	Mandatory
Assembly	0x04	101-103	I/O Messages
Connection	0x05	1	Explicit Messages
		2	Polled I/O Data
		3	Bit Strobe
		4	Change of State (COS), Cyclic I/O Data
Acknowledge Handler	0x2B	1	Necessary for connection class ID 05hex, instance ID 04
Image of I/O Data	0x64	1	Manufacturer-specific object class image of I/O data
C3 object	0x65	20-3300	Manufacturer-specific object class C3 object

5.4.5.2 Object classes

Detailed information on the topic of "object classes" can be found in the online help of the device.

5.4.5.3 Manufacturer-specific object class

In this chapter you can read about:

Overview of the manufacturer-specific object class C3 objects (65hex)	331
Detailed object list	336

Overview of the manufacturer-specific object class C3 objects (65hex)

Instance	Attribute	C3 object name	C3 Object	Bus Format	Valid beginning
1	21	C3.Device_FirmwareRelease	Version of firmware package	I32	immediately
20	1	C3.ObjectDir_Objekts-->FLASH	Store objects permanently (bus)	I16	immediately
84	2	C3.DeviceSupervision_ThisDevice	Device number in the C3M combination	U16	-
84	3	C3.DeviceSupervision_DeviceCounter	Number of devices in the C3M combination	U16	-
84	4	C3.DeviceSupervision_DeviceAdr	Current RS485 address of the C3M	U16	-
84	5	C3.DeviceSupervision_OperatingTime	Hours of operation of the PSUP in s	U32	-
85	1	C3.Diagnostics_DeviceState	PSUP operating state	V2	-
85	2	C3Plus.Diagnostics_DCbus_Voltage	PSUP DC intermediate voltage	I16	-
85	3	C3Plus.Diagnostics_DCbus_Current	PSUP intermediate current	I16	-
85	4	C3Plus.Diagnostics_TemperatureHeatSink	PSUP heat dissipator temperature	I16	-
85	5	C3Plus.Diagnostics_RectifierLoad	PSUP usage in %	I16	-
86	1	C3.ErrorHistoryPointer_LastEntry	Pointer to current error	U16	-
87	1	C3.ErrorHistoryNumber_1	Error 1	U16	-
88	1	C3.ErrorHistoryTime_1	Error point in time 1	U32	-
110	1	C3Plus.Switch_DeviceFunction	Value of the function switch on C3M	U16	-
120	2	C3.DigitalInput_Value	Status of digital inputs	V2	-
120	3	C3.DigitalInput_DebouncedValue	Status of digital inputs	V2	-
121	2	C3.DigitalInputAddition_Value	Input word of I/O option	V2	-
133	3	C3.DigitalOutputAddition_Value	Output word for I/O option	V2	immediately
170	2	C3.AnalogInput0_Gain	Gain analog input 0	C4_3	VP
170	3	C3Plus.AnalogInput0_FilterCoefficient	Filter of analog input 0	I16	VP
170	4	C3.AnalogInput0_Offset	Analog input Offset 0	I16	immediately
171	3	C3Plus.AnalogInput1_FilterCoefficient	Filter of analog input 1	I16	VP
201	11	C3.NormFactorY4_FBI_SignalProcessing	Normalization factor for bus interpolation CANSync/EthernetPowerLink	V2	immediately
210	10	C3.ValidParameter_Global	Set objects to valid	U16	immediately
402	1	C3.Limit_SpeedPositive	Maximum permissible positive speed	I16	VP
402	2	C3.Limit_SpeedNegative	Maximum permissible negative speed	I16	VP
402	3	C3.Limit_CurrentPositive	Maximum permissible positive current	I16	VP
402	4	C3.Limit_CurrentNegative	Maximum permissible negative current	I16	VP
402	6	C3Plus.Limit_CurrentFine	Factor for the current limits	I16	immediately
410	2	C3.LimitPosition_Positive	positive end limit	C4_3	immediately
410	3	C3.LimitPosition_Negative	negative end limit	C4_3	immediately
410	6	C3.LimitPosition_LoadControlMaxPosDiff	Position difference load-motor (error threshold)	C4_3	VP
420	1	C3.PositioningAccuracy_Window	Positioning window for position reached	C4_3	VP
420	2	C3.PositioningAccuracy_FollowingErrorWindow	Following error limit	C4_3	VP
420	3	C3.PositioningAccuracy_FollowingErrorTimeout	Following Error Time	U16	immediately
420	7	C3.PositioningAccuracy_WindowTime	In Position Window Time	U16	immediately
550	1	C3Plus.ErrorHistory_LastError	Current error (n)	U16	-
670	2	C3Plus.StatusTorqueForce_ActualTorque	Status of actual torque	I32	-
670	4	C3Plus.StatusTorqueForce_ActualForce	Status of actual force	I32	-

Instance	Attribute	C3 object name	C3 Object	Bus Format	Valid beginning
680	4	C3.StatusPosition_DemandValue	Status demand position	C4_3	-
680	5	C3.StatusPosition_Actual	Status actual position	C4_3	-
680	6	C3.StatusPosition_FollowingError	Status of tracking error	C4_3	-
680	12	C3.StatusPosition_DemandController	Status demand position without absolute reference	C4_3	-
680	20	C3.StatusPosition_LoadControlDeviation	Position difference load-motor (unfiltered)	C4_3	-
680	21	C3.StatusPosition_LoadControlDeviationMax	Maximum position difference load-motor	C4_3	-
680	22	C3.StatusPosition_LoadControlDeviationFiltered	Position difference load-motor (filtered)	C4_3	-
680	23	C3.StatusPosition_LoadControlActual	Actual position of the load	C4_3	-
681	4	C3.StatusSpeed_DemandValue	Status demand speed of setpoint generator	C4_3	-
681	5	C3.StatusSpeed_Actual	Status actual speed unfiltered	C4_3	-
681	6	C3.StatusSpeed_Error	Status control deviation of speed	C4_3	-
681	7	C3.StatusSpeed_ActualFiltered_Y2	Status of the actual filtered speed speed in the Y2 format	Y2	-
681	9	C3.StatusSpeed_ActualFiltered	Status actual speed filtered	C4_3	-
681	10	C3.StatusSpeed_DemandSpeedController	Status demand speed controller input	C4_3	-
681	11	C3.StatusSpeed_FeedForwardSpeed	Status speed feed forward	C4_3	-
681	12	C3.StatusSpeed_ActualScaled	Filtered actual speed	C4_3	-
681	13	C3.StatusSpeed_DemandScaled	Setpoint speed of the setpoint generator	C4_3	-
681	20	C3.StatusSpeed_LoadControl	Speed of the load feedback (unfiltered)	C4_3	-
681	21	C3.StatusSpeed_LoadControlFiltered	Speed of the load feedback (filtered)	C4_3	-
682	4	C3.StatusAccel_DemandValue	Status demand acceleration	I32	-
682	5	C3.StatusAccel_Actual	Status of actual acceleration unfiltered	I32	-
682	6	C3.StatusAccel_ActualFilter	Status of filtered actual acceleration	I32	-
682	7	C3.StatusAccel_FeedForwardAccel	Status acceleration feed forward	C4_3	-
683	1	C3.StatusDevice_ActualCurrent	Status of actual current value	E2_6	-
683	2	C3.StatusDevice_ActualDeviceLoad	Status of device load	E2_6	-
683	3	C3.StatusDevice_ActualMotorLoad	Status of long-term motor load	E2_6	-
683	5	C3.StatusDevice_ObservedDisturbance	Status of observed disturbance	C4_3	-
683	8	C3Plus.StatusDevice_MotorCurrent	Motor current in per thousand of the actual current limit	I16	-
684	1	C3.StatusTemperature_PowerStage	Status of power output stage temperature	U16	-
684	2	C3.StatusTemperature_Motor	Status of motor temperature	U16	-
685	1	C3.StatusVoltage_AuxiliaryVoltage	Status of auxiliary voltage	E2_6	-
685	2	C3.StatusVoltage_BusVoltage	Status DC bus voltage	E2_6	-
685	3	C3.StatusVoltage_AnalogInput0	Status of analog input 0	Y2	-
685	4	C3.StatusVoltage_AnalogInput1	Status of analog input 1	Y2	-
688	1	C3.StatusCurrent_Reference	Status of setpoint current RMS (torque forming)	E2_6	-
688	2	C3.StatusCurrent_Actual	Status of actual current RMS (torque producing)	E2_6	-
688	8	C3.StatusCurrent_ControlDeviationIq	Status control deviation current control RMS	C4_3	-
688	9	C3.StatusCurrent_PhaseU	Status of current phase U	C4_3	-
688	10	C3.StatusCurrent_PhaseV	Status of current phase V	C4_3	-
688	11	C3.StatusCurrent_ReferenceVoltageUq	Status of current control control signal	C4_3	-
688	13	C3.StatusCurrent_ReferenceJerk	Status of demand jerk setpoint generator	I32	-
688	14	C3.StatusCurrent_FeedForwardCurrentJerk	Status of current & jerk feedforward	C4_3	-
688	18	C3.StatusCurrent_ReferenceDINT	Target current r.m.s.	I32	-
688	19	C3.StatusCurrent_ActualDINT	Actual current r.m.s.	I32	-
688	22	C3.StatusCurrent_ReferenceVoltageVector	Provided voltage pointer	C4_3	-
688	29	C3.StatusCurrent_VoltageUq	Provided voltage of quadrature current controller	C4_3	-
688	30	C3.StatusCurrent_VoltageUd	Provided voltage of direct current controller	C4_3	-
688	31	C3.StatusCurrent_DecouplingVoltageUd	Signal decoupling of direct current controller	C4_3	-

Instance	Attribute	C3 object name	C3 Object	Bus Format	Valid beginning
688	32	C3.StatusCurrent_FeedForwardbackEMF	Signal EMC feedforward	C4_3	-
690	5	C3.StatusAutocommutation_lIterations	Current increase steps automatic commutation	U16	-
820	24	C3.CANopen_SyncMode	Configuration of the bus synchronization process	I16	immediately
990	1	C3.Delay_MasterDelay	Setpoint delay for bus master	I16	immediately
1000	3	C3Plus.DeviceState_Statusword_1	Status word SW	V2	immediately
1000	4	C3Plus.DeviceState_Statusword_2	Status word 2	V2	immediately
1000	5	C3Plus.DeviceState_ActualOperationMode	Operating mode display	I16	immediately
1100	3	C3Plus.DeviceControl_Controlword_1	Control word CW	V2	immediately
1100	4	C3Plus.DeviceControl_Controlword_2	Control word 2	V2	immediately
1100	5	C3Plus.DeviceControl_OperationMode	Operating mode	I16	immediately
1100	6	C3Plus.DeviceControl_DemandValue1	Device demand value A	Y4	immediately
1100	7	C3Plus.DeviceControl_DemandValue2	Device demand value D	Y4	immediately
1100	13	C3Plus.DeviceControl_DemandValue8	Setpoint value	Y4	immediately
1100	14	C3Plus.DeviceControl_DemandValue2_Y2	Device demand value	Y2	immediately
1100	20	C3Plus.DeviceControl_QuickStopMode	Quick Stop operating mode	I16	immediately
1111	1	C3Plus.POSITION_position	Target position	C4_3	immediately
1111	2	C3Plus.POSITION_speed	Speed for positioning and velocity control	C4_3	immediately
1111	3	C3Plus.POSITION_accel	Acceleration for positioning	U32	immediately
1111	4	C3Plus.POSITION_decel	Deceleration for positioning	U32	immediately
1111	5	C3Plus.POSITION_jerk_accel	Acceleration jerk for positioning	U32	immediately
1111	6	C3Plus.POSITION_jerk_decel	Deceleration jerk for positioning	U32	immediately
1111	10	C3Plus.POSITION_accel_U16	Acceleration for positioning in U16 Format	U16	immediately
1111	13	C3Plus.POSITION_direction	Manipulation of the motion direction in reset mode	I32	immediately
1111	16	C3Plus.POSITION_decel_U16	Deceleration for Positioning in U16 Format	U16	immediately
1113	1	C3Plus.STOP_decel	Deceleration for STOP	U32	immediately
1113	2	C3Plus.STOP_jerk	Jerk for STOP	U32	immediately
1116	1	C3Plus.FSTOP1_decel	Deceleration for FSTOP1	U32	immediately
1116	2	C3Plus.FSTOP1_jerk	Jerk for FSTOP1	U32	immediately
1118	1	C3Plus.FSTOP3_decel	Deceleration for FSTOP3	U32	immediately
1118	2	C3Plus.FSTOP3_jerk	Jerk for FSTOP3	U32	immediately
1125	1	C3Plus.ERROR_decel	Deceleration upon error	U32	immediately
1125	2	C3Plus.ERROR_jerk	Jerk upon Error	U32	immediately
1127	1	C3Plus.SPEED_accel	Acceleration / deceleration in speed control operating mode	U32	immediately

Instance	Attribute	C3 object name	C3 Object	Bus Format	Valid beginning
1127	3	C3Plus.SPEED_speed	Setpoint speed in speed control operating mode	C4_3	immediately
1128	1	C3Plus.JOG_accel	Acceleration for Manual +/-	U32	immediately
1128	2	C3Plus.JOG_jerk	Jerk for Manual +/-	U32	immediately
1128	3	C3Plus.JOG_speed	Speed for Manual +/-	C4_3	immediately
1130	1	C3Plus.HOMING_accel	Acceleration / deceleration MN (homing) run	U32	immediately
1130	3	C3Plus.HOMING_speed	Speed for machine reference run	C4_3	immediately
1130	4	C3Plus.HOMING_mode	Adjusting the machine reference mode	U16	immediately
1130	5	C3Plus.HOMING_home_offset	Machine reference offset	C4_3	immediately
1130	7	C3Plus.HOMING_edge_sensor_distance	Initiator adjustment	C4_3	immediately
1130	13	C3Plus.HOMING_edge_position	Distance MN (zero) initiator - motor zero	C4_3	immediately
1141	10	C3Plus.GEAR_FFW_mode	Control bits for feedforward with source CANSync/EthernetPowerLink	U16	immediately
1211	13	C3Plus.PG2POSITION_direction	Manipulation of the motion direction in reset mode	I32	immediately
1900	1	C3Array.Pointer_Row	Pointer to table row	U16	immediately
1901	1	C3Array.Col01_Row01	variable Column 1 Row 1	Y4	immediately
1902	1	C3Array.Col02_Row01	variable Column 2 Row 1	Y2	immediately
1903	1	C3Array.Col03_Row01	variable Column 3 Row 1	I16	immediately
1904	1	C3Array.Col04_Row01	variable Column 4 Row 1	I16	immediately
1905	1	C3Array.Col05_Row01	variable Column 5 Row 1	I16	immediately
1906	1	C3Array.Col06_Row01	variable Column 6 Row 1	I32	immediately
1907	1	C3Array.Col07_Row01	variable Column 7 Row 1	I32	immediately
1908	1	C3Array.Col08_Row01	variable Column 8 Row 1	I32	immediately
1909	1	C3Array.Col09_Row01	variable Column 9 Row 1	I32	immediately
1910	1	C3Array.Indirect_Col01	Indirect table access Column 1	Y4	immediately
2010	1	C3.FeedForward_Speed	Velocity Feed Forward	U16	VP
2010	2	C3.FeedForward_Accel	Acceleration feed-forward	U16	VP
2010	4	C3.FeedForward_Current	Current feed-forward	U16	VP
2010	5	C3.FeedForward_Jerk	Jerk feed-forward	U16	VP
2010	20	C3.FeedForward_EMF	EMC feedforward	U16	VP
2011	1	C3.FeedForwardExternal_FilterSpeed	External Speed Feed Forward Filter Time Constant	U16	VP
2011	2	C3.FeedForwardExternal_FilterAccel	External Acceleration Feed Forward Filter Time Constant	U16	VP
2011	4	C3.FeedForwardExternal_FilterSpeed_us	Filter time constant ext. Speed	U16	VP
2011	5	C3.FeedForwardExternal_FilterAccel_us	Filter time constant ext. Acceleration	U16	VP
2020	1	C3.ExternalSignal_Position	Position from external signal source	C4_3	-
2020	6	C3Plus.ExternalSignal_Speed_Munits	Speed value of the external signal source	C4_3	-
2020	7	C3Plus.ExternalSignal_Accel_Munits	Acceleration of the external signal source	I32	-
2100	2	C3.ControllerTuning_Stiffness	Stiffness (speed controller)	U16	VP
2100	3	C3.ControllerTuning_Damping	Damping (rotation speed controller)	U16	VP

Instance	Attribute	C3 object name	C3 Object	Bus Format	Valid beginning
2100	4	C3.ControllerTuning_Inertia	Moment of Inertia	U16	VP
2100	5	C3.ControllerTuning_FilterSpeed	Filter - Actual velocity	U16	VP
2100	6	C3.ControllerTuning_FilterAccel	Filter - Actual acceleration	U16	VP
2100	7	C3.ControllerTuning_SpeedDFactor	D-component of speed controller	U16	VP
2100	8	C3.ControllerTuning_CurrentBandwidth	Current regulator bandwidth	U16	VP
2100	9	C3.ControllerTuning_CurrentDamping	Current loop - Damping	U16	VP
2100	11	C3.ControllerTuning_FilterAccel2	Filter actual acceleration 2	U16	VP
2100	20	C3.ControllerTuning_ActuatingSpeedSignalFilter_us	Control signal filter of velocity control	U16	VP
2100	21	C3.ControllerTuning_FilterAccel_us	Filter - Actual acceleration	U16	VP
2107	1	C3Plus.TrackingfilterPhysicalSource_TRFSpeed	Time constant tracking filter physical source	U16	VP
2109	1	C3Plus.TrackingfilterHEDA_TRFSpeed	Time constant tracking filter HEDA-process position	I16	VP
2110	1	C3Plus.TrackingfilterSG1_TRFSpeed	Time constant tracking filter setpoint encoder	I16	VP
2110	3	C3Plus.TrackingfilterSG1_FilterSpeed	Filter effect of speed filter setpoint encoder	U16	VP
2110	4	C3Plus.TrackingfilterSG1_AccelFilter	Filter effect of acceleration filter setpoint encoder	U16	VP
2110	6	C3Plus.TrackingfilterSG1_FilterSpeed_us	Filter time constant velocity setpoint generator	U16	VP
2110	7	C3Plus.TrackingfilterSG1_AccelFilter_us	Filter time constant acceleration setpoint generator	U16	VP
2120	1	C3.SpeedObserver_TimeConstant	Rapidity of the speed monitor	U32	VP
2120	5	C3.SpeedObserver_DisturbanceFilter	Time constant disturbance filter	U32	VP
2120	7	C3.SpeedObserver_DisturbanceAdditionEnable	Switch to enable disturbance compensation	BOOL	VP
2150	1	C3Plus.NotchFilter_FrequencyFilter1	Center frequency of notch filter 1	I16	VP
2150	2	C3Plus.NotchFilter_BandwidthFilter1	Bandwidth of notch filter 1	I16	VP
2150	3	C3Plus.NotchFilter_DepthFilter1	Depth of notch filter 1	I32	VP
2150	4	C3Plus.NotchFilter_FrequencyFilter2	Center frequency of notch filter 2	I16	VP
2150	5	C3Plus.NotchFilter_BandwidthFilter2	Bandwidth of notch filter 2	I16	VP
2150	6	C3Plus.NotchFilter_DepthFilter2	Depth of notch filter 2	I32	VP
2190	1	C3Plus.AutoCommutationControl_Ramptime	Ramp slope current slope AK	U16	VP
2190	2	C3Plus.AutoCommutationControl_InitialCurrent	Start current of automatic commutation	U16	VP
2190	3	C3Plus.AutoCommutationControl_PositionThreshold	Motion limit for automatic commutation	U16	VP
2190	4	C3Plus.AutoCommutationControl_MotionReduction	Motion reduction Automatic commutation	U16	VP
2190	7	C3Plus.AutoCommutationControl_StandstillThreshold	Optimization of the standstill threshold	U16	VP
2190	8	C3Plus.AutoCommutationControl_PeakCurrent	Reduction of the peak current	U16	VP
2190	10	C3Plus.AutoCommutationControl_Reset	Reset automatic commutation	U16	immediately
2200	11	C3Plus.PositionController_TrackingErrorFilter	Following error filter of the position controller	U16	VP
2200	20	C3Plus.PositionController_DeadBand	Deadband of position controller	C4_3	VP
2200	21	C3Plus.PositionController_FrictionCompensation	Friction compensation	I32	VP
2200	24	C3Plus.PositionController_TrackingErrorFilter_us	Time constant following error filter of position controller	U16	VP
2201	1	C3Plus.LoadControl_Enable	Activate Load control	I16	immediately
2201	2	C3Plus.LoadControl_Command	Load control command mode	I16	immediately
2201	3	C3Plus.LoadControl_Status	Load control status bits	I16	-
2201	11	C3Plus.LoadControl_FilterLaggingPart	Time constant of position difference filter	U32	VP
2201	12	C3Plus.LoadControl_VelocityFilter	Time constant of the load-speed filter	I16	VP

Instance	Attribute	C3 object name	C3 Object	Bus Format	Valid beginning
2210	17	C3.SpeedController_ActualBandwidth	Replacement time constant for the velocity control	I32	-
2220	20	C3.Q_CurrentController_Inductance	Parameter motor inductance	I16	VP
2220	21	C3.Q_CurrentController_Resistance	Parameter motor resistance	I16	VP
2220	22	C3.Q_CurrentController_BackEMF	Parameter motor force constant	I16	VP
2230	20	C3.D_CurrentController_Ld_Lq_Ratio	Ratio direct to quadrature inductance	U16	VP
2230	24	C3.D_CurrentController_VoltageDecouplingEnable	Activation of the voltage decoupling	I16	VP
3300	8	C3Plus.TouchProbe_IgnoreZone_Start	Beginning of the ignore zone	C4_3	immediately
3300	9	C3Plus.TouchProbe_IgnoreZone_End	End of the ignore zone	C4_3	immediately
3920	7	C3Plus.HEDA_SignalProcessing_OutputGreat	Output of the Heda Tracking Filter	C4_3	-
3921	1	C3.FBI_SignalProcessing0_Input	Interpolation input CanSync, PowerLink	I32	immediately
3921	7	C3Plus.FBI_SignalProcessing0_OutputGreat	Interpolation output of the Position CanSync, PowerLink	Y4	-
3925	1	C3.FBI_Interpolation_SubModeSelect	Interpolation method	I16	immediately
3925	22	C3.FBI_Interpolation_VelocityStatus	Input speed of the differentiated input position O2121.1	C4_3	-
3925	23	C3.FBI_Interpolation_AccelStatus	Input value of the acceleration of O3925.21	C4_3	-

Detailed object list

A detailed object list can be found in the corresponding online help.

5.4.5.4 Data formats of the bus objects

In this chapter you can read about:

Integer formats	337
Unsigned - Formats	337
Fixed point format E2_6	337
Fixed point format C4_3	338
Bus format Y2 and Y4	338
Bit sequence V2	339
Byte string OS	339

Integer formats

Twos complement representation;

The highest order bit (MSB) is the bit after the sign bit (VZ) in the first byte.

VZ == 0: positive numbers and zero; VZ == 1: negative numbers

Type	Bit	8	7	6	5	4	3	2	1
Integer 8 length: 1 Byte		VZ	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Integer 16	MSB	VZ	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸
Length: 1 Word	LSB	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Integer 32	MSB	VZ	2 ³⁰	2 ²⁹	2 ²⁸	2 ²⁷	2 ²⁶	2 ²⁵	2 ²⁴
Length: 2 Words		2 ²³	2 ²²	2 ²¹	2 ²⁰	2 ¹⁹	2 ¹⁸	2 ¹⁷	2 ¹⁶
		2 ¹⁵	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸
	LSB	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰

Unsigned - Formats

Type	Bit	8	7	6	5	4	3	2	1
Unsigned 8 Length: 1 Byte		2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Unsigned 16	MSB	2 ¹⁵	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸
Length: 1 Word	LSB	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
Unsigned 32	MSB	2 ³¹	2 ³⁰	2 ²⁹	2 ²⁸	2 ²⁷	2 ²⁶	2 ²⁵	2 ²⁴
Length: 2 Words		2 ²³	2 ²²	2 ²¹	2 ²⁰	2 ¹⁹	2 ¹⁸	2 ¹⁷	2 ¹⁶
		2 ¹⁵	2 ¹⁴	2 ¹³	2 ¹²	2 ¹¹	2 ¹⁰	2 ⁹	2 ⁸
	LSB	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰

Fixed point format E2_6

Linear fixed point value with six binary places after the decimal point. 0 corresponds to 0, 256 corresponds to 2¹⁴ (0x4000).

Twos complement representation;

MSB is the bit after the sign bit

VZ == 0: positive numbers and zero;

VZ == 1: negative numbers

Type	Bit	8	7	6	5	4	3	2	1
E2_6	MSB	VZ	2 ⁸	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²
Length: 1 Word	LSB	2 ¹	2 ⁰	2 ⁻¹	2 ⁻²	2 ⁻³	2 ⁻⁴	2 ⁻⁵	2 ⁻⁶

Fixed point format C4_3

Linear fixed point value with three decimal places after the decimal point. 0 corresponds to 0 and 0,001 corresponds to 2^0 (0x0000 0001).

Structure like data type Integer32, value of the bits reduced by a factor of 1000.

Length: 2 Words

Bus format Y2 and Y4

Layout:

- ◆ Y2 like data type Integer16
- ◆ Y4 like data type Integer32

The values can be adjusted by a normalization factor.

The following rules apply:

- ◆ Normalization factor for Y2: Object 200.1, ... 200.5
- ◆ Normalization factor for Y4: Object 201.1, ... 201.5

There are different normalization factors for individual values

1. Y2 - normalization factors

- ◆ Object 200.1: NormFactorY2_Speed: Normalization factor for Y2 speeds
- ◆ Object 200.2: NormFactorY2_Position: Normalization factor for Y2 positions
- ◆ Object 200.3: NormFactorY2_Voltage: Normalization factor for Y2 voltages
- ◆ Object 200.5: NormFactorY2_Array_Col2: Normalization factor for Column 2 of the recipe array

2. Y4 - normalization factors

- ◆ Object 201.1: NormFactorY4_Speed: Normalization factor for Y4 speeds
- ◆ Object 201.2: NormFactorY4_Position: Normalization factor for Y4 positions
- ◆ Object 201.3: NormFactorY4_Voltage: Normalization factor for Y4 voltages
- ◆ Object 201.4: NormFactorY4_Array_Col1: Normalization factor for Column 1 of the recipe array

Meaning of the normalization factors

- ◆ Bit 5: Meaning of the normalization factor:
 - ◆ Bit 5 = "0": decimal factors 1, 1/10, 1/100, ..
 - Bit 4 ... Bit 0: Normalization factor**

#	Bit 4...0	Factor dec (Bit 5 = 0) yy0x xxxx	
0	00000	10^0	1
1	00001	10^{-1}	0.1
2	00010	10^{-2}	0.01
3	00011	10^{-3}	0.001
4	00100	10^{-4}	0,0001
5	00101	10^{-5}	0,00001
6	00110	10^{-6}	0.00001
7	00111	10^{-7}	0.00001
8	01000	10^{-8}	0.00000001
9	01001	10^{-9}	0.000000001

- ◆ Bit 5 = "1": binary factors 4, 1/2, 1/4, 1/8, ...
- Bit 0 ... Bit 0: Normalization factor**

#	Bit 4...0	Factor bin (Bit 5 = 1) yy1x xxxx	
32	00000	2^0	1
33	00001	2^{-1}	0.5
34	00010	2^{-2}	0.25
35	00011	2^{-3}	0.125
36	00100	2^{-4}	0,0625
37	00101	2^{-5}	0,03125
38	00110	2^{-6}	0.015625
39	00111	2^{-7}	0.0078125
40	01000	2^{-8}	0.00390625
41	01001	2^{-9}	0.001953125
42	01010	2^{-10}	0.0009765625
43	01011	2^{-11}	0.00048828125
44	01100	2^{-12}	0.000244140625
45	01101	2^{-13}	0,0001220703125
46	01110	2^{-14}	0.00006103515625
47	01111	2^{-15}	0.000030517578125
48	10000	2^{-16}	0.0000152587890625
49	10001	2^{-17}	0.00000762939453125
50	10010	2^{-18}	0.000003814697265625
51	10011	2^{-19}	0.0000019073486328125
52	10100	2^{-20}	0.00000095367431640625
53	10101	2^{-21}	0.000000476837158203125
54	10110	2^{-22}	0.0000002384185791015625
55	10111	2^{-23}	0.00000011920928955078125
56	11000	2^{-24}	0.000000059604644775390625

- ◆ Bit 15 ... Bit 6: reserved

Bit sequence V2

The V2 bus format is a bit sequence with a length of 16 bits.

Byte string OS

Octet string OS: String with variable length.

5.4.6. DeviceNet application description

An application description for communication with a Rockwell controller (Allen Bradley, L32E) via DeviceNet can be found under <http://www.compax3.info/startup> <http://www.compax3.info/startup>.

6. Status values

In this chapter you can read about:

D/A-Monitor	341
Status values	341

A list of the status values supports you in optimization and commissioning.

Open the optimization function in the C3 ServoManager (double-click on optimization in the tree)

You will find the available status values in the lower right part of the window under selection (TAB) "Status values".

You can pull them into the oscilloscope (upper part of the left side) or into the status display (upper part of the right side) by the aid of the mouse (drag and drop).


The status values are divided into 2 groups (user levels):

standard: here you can find all important status values

advanced: Advanced status values, require a better knowledge

Switching of the user level

The user level can be changed in the optimization window (left hand side lower part under selection (TAB) "optimization") with the following button.



6.1 D/A-Monitor

A part of the status values can be output via the D/A monitor channel 0 (X11/4) and channel 1 (X11/3). In the following status list under D/A monitor output: possible / not possible).

The reference for the output voltage can be entered individually in the reference unit of the status value.

Example: Output Object 2210.2: (actual speed unfiltered)

In order to get an output voltage of 10V at 3000rpm, please enter rev/s (=3000rpm) as "value of the signal at 10V".

Hint

The unit of measurement of the D/A monitor values differs from the unit of measurement of the status values.

6.2 Status values

Additional information on the topic of "status values" can be found in the online help of the device.

7. Error

Standard error reactions:

Reaction 2: Downramp with "de-energize" **then apply brake** (see on page 292) and finally de-energize.

For errors with standard reaction 2 the **error reaction can be changed** (see on page 154).

Reaction 5: deenergize immediately (without ramps), apply brake.

Caution! A Z-axis may drop down due to the brake delay times

Most pending errors can be acknowledged with Quit!

The following errors must be acknowledged with Power on:

0x7381, 0x7382, 0x7391, 0x7392, 0x73A0

Object 550.1 displays error:
value 1 means "no error".

The errors as well as the error history can be viewed in the C3 ServoManager under optimization (at the top right of the optimization window).

7.1 Error list

Detailed information on the topic of the "error list" can be found in the online help of the device.

8.2 Order code for mains module: PSUP

Example: PSUP10D6USBM00

	PSU	P		D6	USB	M00
Power module		P				
Nominal power; supply voltage						
10kW; 400 VAC (3-phase)			10	D6		
20kW; 400 VAC (3-phase)			20	D6		
30kW; 400 VAC (3-phase)			30	D6		
Interface:						
USB connection					USB	
Options:						
no additional supplement						M00

8.3 Order code for accessories

Order Code connection set for Compax3S

The corresponding connection sets are furnished with the device.

for C3S0xxV2	ZBH 02/01	ZBH	0 2 / 0 1		
for C3S0xxV4 / S150V4 / S1xxV2	ZBH 02/02	ZBH	0 2 / 0 2		
for C3S300V4	ZBH 02/03	ZBH	0 2 / 0 3		

Order code for PSUP/Compax3M connection set

The corresponding connection sets are furnished with the device.

for C3M050D6, C3M100D6, C3M150D6	ZBH 04/01	ZBH	0 4 / 0 1		
for C3M300D6	ZBH 04/02	ZBH	0 4 / 0 2		
for PSUP10	ZBH 04/03	ZBH	0 4 / 0 3		
PSUP20, PSUP30	ZBH 04/04	ZBH	0 4 / 0 4		

Order code for feedback cables

for resolver ⁽²⁾	for MH / SMH motors	REK	4 2 / ... ⁽¹⁾		
for resolver ⁽²⁾	for MH / SMH motors (cable chain compatible)	REK	4 1 / ... ⁽¹⁾		
for SinCos® – feedback ⁽²⁾	for MH / SMH motors (cable chain compatible)	GBK	2 4 / .. ⁽¹⁾		
for EnDat 2.1 ⁽²⁾	for MH / SMH motors (cable chain compatible)	GBK	3 8 / .. ⁽¹⁾		
Encoder – Compax3		GBK	2 3 / ... ⁽¹⁾		
for LXR linear motors	(cable chain compatible)	GBK	3 3 / ... ⁽¹⁾		
for BLMA linear motors	(cable chain compatible)	GBK	3 2 / ... ⁽¹⁾		

^(x) Note on cable (see on page 347)

Motor cable order code ⁽²⁾

for SMH / MH56 / MH70 / MH105 ⁽³⁾	(1.5mm ² ; up to 13.8A)	MOK	5 5 / ... ⁽¹⁾		
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(1.5mm ² ; up to 13.8A) (cable chain compatible)	MOK	5 4 / ... ⁽¹⁾		
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(2.5mm ² ; up to 18.9A)	MOK	5 6 / ... ⁽¹⁾		
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(2.5mm ² ; up to 18.9A) (cable chain compatible)	MOK	5 7 / ... ⁽¹⁾		
for MH145 / MH205 ⁽⁴⁾	(1.5mm ² ; up to 13.8A)	MOK	6 0 / ... ⁽¹⁾		
for MH145 / MH205 ⁽⁴⁾	(1.5mm ² ; up to 13.8A) (cable chain compatible)	MOK	6 3 / ... ⁽¹⁾		
for MH145 / MH205 ⁽⁴⁾	(2.5mm ² ; up to 18.9A)	MOK	5 9 / ... ⁽¹⁾		
for MH145 / MH205 ⁽⁴⁾	(2.5mm ² ; up to 18.9A) (cable chain compatible)	MOK	6 4 / ... ⁽¹⁾		
for MH145 / MH205 ⁽⁴⁾	(6mm ² ; up to 32.3A) (cable chain compatible)	MOK	6 1 / ... ⁽¹⁾		
for MH145 / MH205 ⁽⁴⁾	(10mm ² ; up to 47.3A) (cable chain compatible)	MOK	6 2 / ... ⁽¹⁾		

^(x) Note on cable (see on page 347)

Order Code braking resistors

for C3S063V2 or C3S075V4	56Ω / 0.18kW _{cont.}	BRM	0 5	/	0 1
for C3S075V4	56Ω / 0.57kW _{cont.}	BRM	0 5	/	0 2
for C3S025V2 or C3S038V4	100Ω / 60W _{cont.}	BRM	0 8	/	0 1
for C3S150V4	47Ω / 0.57kW _{cont.}	BRM	1 0	/	0 1
for C3S150V2, C3S300V4 and PSUP20D6	4/01:15Ω / 0.57kW _{cont.} 4/02:15Ω / 0.74kW _{cont.}	BRM	0 4	/	0 ...
for C3S300V4 and PSUP20D6	4/03:15Ω / 1.5kW _{cont.}				
for C3S100V2	22Ω / 0.45kW _{cont.}	BRM	0 9	/	0 1
for C3H0xxV4	27Ω / 3.5kW _{cont.}	BRM	1 1	/	0 1
**for PSUP10D6 and PSUP20D6 2x30Ω parallel)	30Ω / 0.5kW _{cont.}	BRM	1 3	/	0 1
for PSUP10D6 (2x15Ω in series), PSUP20D6, PSUP30D6	15Ω / 0.5kW _{cont.}	BRM	1 4	/	0 1
for C3H1xxV4, PSUP30D6	18Ω / 4.5kW _{cont.}	BRM	1 2	/	0 1

Order code mains filter Compax3S

for C3S025V2 or S063V2		NFI	0 1	/	0 1
for C3S0xxV4, S150V4 or S1xxV2		NFI	0 1	/	0 2
for C3S300V4		NFI	0 1	/	0 3

Order code mains filter Compax3H

for C3H050V4		NFI	0 2	/	0 1
for C3H090V4		NFI	0 2	/	0 2
for C3H1xxV4		NFI	0 2	/	0 3

Order Code mains filter PSUP

for PSUP10	Reference axis combination 3x480V 25A 6x10m motor cable length	NFI	0 3	/	0 1
for PSUP10	Reference axis combination 3x480V 25A 6x50m motor cable length	NFI	0 3	/	0 2
for PSUP20 & PSUP30	Reference axis combination 3x480V 50A 6x50m motor cable length	NFI	0 3	/	0 3

Order code for mains filters

for PSUP30	Mains filter	LCG-0055-0.45 mH
for PSUP30	Mains filter with UL approval	LCG-0055-0.45 mH-UL

Order code for motor output filter (for Compax3S, Compax3M >20m motor cable)

up to 6,3 A rated motor current		MDR	0 1	/	0 4
Up to 16 A rated motor current		MDR	0 1	/	0 1
Up to 30A A rated motor current		MDR	0 1	/	0 2

Order code condenser module

for C3S300V4	1100μF	Modules	C4
--------------	--------	---------	----

Order code for interface cables and plugs

PC – Compax3 (RS232)		SSK	0 1 /	⁽¹⁾
PC – PSUP (USB)		SSK	3 3 /	
on X11 (Ref/Analog) and X13 at C3F001D2	with flying leads	SSK	2 1 /	⁽¹⁾
on X12 / X22 (digital I/Os)	with flying leads	SSK	2 2 /	⁽¹⁾
on X11 (Ref /Analog)	for I/O terminal block	SSK	2 3 /	⁽¹⁾
on X12 / X22 (digital I/Os)	for I/O terminal block	SSK	2 4 /	⁽¹⁾
PC ⇔ POP (RS232)		SSK	2 5 /	⁽¹⁾
Compax3 ⇔ POP (RS485) for several C3H on request		SSK	2 7 /	⁽⁶⁾
Compax3 HEDA ⇔ Compax3 HEDA or PC ⇔ C3powerPLmC		SSK	2 8 /	⁽⁵⁾
Compax3 I30 ⇔ Compax3 I30 or C3M-multi-axis communication					
Profinet, EtherCAT, Ethernet Powerlink					
Compax3 X11 ⇔ Compax3 X11 (encoder coupling of 2 axes)		SSK	2 9 /	⁽¹⁾
Compax3 X10 ⇔ Modem		SSK	3 1 / ...		
Compax3H adapter cable ⇔ SSK01 (length 15cm, delivered with the device)		SSK	3 2 / 2 0		
Compax3H X10 RS232 connection control ⇔ Programming interface (delivered with the device)		VBK	1 7 / 0 1		
Bus terminal connector (for the 1st and last Compax3 in the HEDA Bus/or multi-axis system)		BUS	0 7 / 0 1		
Profibus cable ⁽²⁾	non prefabricated	SSL	0 1 /	⁽¹⁾
Profibus plug		BUS	0 8 / 0 1		
CAN bus cable ⁽²⁾	non prefabricated	SSL	0 2 /	⁽¹⁾
CANbus connector		BUS	1 0 / 0 1		

^(x) **Note on cable** (see on page 347)

Order Code operating module

Operating module (for Compax3S and Compax3F)		BDM	0 1 / 0 1		

Order Code terminal block

for I/Os without luminous indicator	for X11, X12, X22	EAM	0 6 / 0 1		
for I/Os with luminous indicator	for X12, X22	EAM	0 6 / 0 2		

Order Code decentralized input terminals

PIO 2DI 24VDC 3.0ms	2-channel digital input terminal	PIO	4 0 0		
PIO 4DI 24VDC 3.0ms	4-channel digital input terminal	PIO	4 0 2		
PIO 8DI 24VDC 3.0ms	8-channel digital input terminal	PIO	4 3 0		
PIO 2AI DC ±10V differential input	2-channel analog - Input terminal (±10V differential input)	PIO	4 5 6		
PIO 4AI 0-10VDC S.E.	4 channel analog input terminal (0-10V signal voltage)	PIO	4 6 8		
PIO 2AI 0-20mA differential input	2-channel analog - Input terminal (0-20mA differential input)	PIO	4 8 0		

Order Code decentralized output terminals

PIO 2DO 24VDC 0.5A	2 channel digital output terminal (output voltage 0.5A)	PIO	5 0 1		
PIO 4DO 24VDC 0.5A	4 channel digital output terminal (output voltage 0.5A)	PIO	5 0 4		
PIO 8DO 24VDC 0.5A	8 channel digital output terminal (output voltage 0.5A)	PIO	5 3 0		
PIO 2AO 0-10VDC	2 channel analog output terminal (0-10V signal voltage)	PIO	5 5 0		
PIO 2AO 0-20mA	2-channel analog output terminal (0-20mA signal voltage)	PIO	5 5 2		
PIO 2AO DC ±10V	2-channel analog output terminal (±10V signal voltage)	PIO	5 5 6		

Order Code CANopen Fieldbus Coupler

CANopen Standard	max. Vectorial sum current for bus terminals 1650mA at 5V	PIO	3 3 7		
CANopen ECO	max. Vectorial sum current for bus terminals 650mA at 5V	PIO	3 4 7		

⁴ Length code 1

Length [m]	1.0	2.5	5.0	7.5	10.0	12.5	15.0	20.0	25.0	30.0	35.0	40.0	45.0	50.0
Order code	01	02	03	04	05	06	07	08	09	10	11	12	13	14

Example:

SSK01/09: Length 25m

² Colors according to DESINA³ with motor connector⁴ with cable eye for motor terminal box⁵ length code 2 for SSK28

Length [m]	0.17	0.25	0.5	1.0	3.0	5.0	10.0
Order code	23	20	21	01	22	03	05

⁶ **Order code: SSK27/nn/..**

Length A (Pop - 1. Compax3) variable (the last two numbers according to the length code for cable, for example SSK27/nn/01)

Length B (1. Compax3 - 2. Compax3 - ... - n. Compax3) fixed 50 cm (only if there is more than 1 Compax3, i.e. nn greater than 01)

Number n (the last two digits)

Examples include:

SSK27/05/.. for connecting from Pop to 5 Compax3.

SSK27/01/.. for connecting from Pop to one Compax3

MOK55 and MOK54 can also be used for linear motors LXR406, LXR412 and BLMA.

^x **Note on cable** (see on page 347)

9. Compax3 Accessories

In this chapter you can read about:

Parker servo motors	348
EMC measures	351
Connections to the motor	359
External braking resistors	365
Condenser module C4	379
Operator control module BDM	380
EAM06: Terminal block for inputs and outputs	381
Interface cable	383
Options M1x	388

9.1 Parker servo motors

In this chapter you can read about:

Direct drives	348
Rotary servo motors	350

9.1.1. Direct drives

In this chapter you can read about:

Transmitter systems for direct drives	349
Linear motors	350
Torque motors	350

9.1.1.1 Transmitter systems for direct drives

The Feedback option F12 makes it possible to operate linear motors as well as torque motors. Compax3 supports the following transmitter systems:

Special encoder systems for direct drives	Option F12
Analog hall sensors	<ul style="list-style-type: none"> ◆ Sine-Cosine signal (max. 5Vss*; typical 1Vss) 90° offset ◆ U-V signal (max. 5Vss*; typical 1Vss) 120° offset.
Encoder (linear or rotatory)	<ul style="list-style-type: none"> ◆ Sine-Cosine (max. 5Vss*; typical 1Vss) (max. 400kHz) or ◆ TTL (RS422) (max. 5MHz; track A o. B) with the following modes of commutation: <ul style="list-style-type: none"> ◆ Automatic commutation (see on page 349) or ◆ U, V, W or R, S, T commutation signals (NPN open collector) e.g. digital hall sensors, incremental encoders made by Hengstler (F series with electrical ordering variant 6)
Digital, bidirectional interface	<ul style="list-style-type: none"> ◆ All EnDat 2.1 or EnDat 2.2 (Endat01, Endat02) feedback systems with incremental track (sine-cosine track) <ul style="list-style-type: none"> ◆ linear or rotary ◆ max. 400kHz Sine-Cosine
Distance coded feedback systems	<ul style="list-style-type: none"> ◆ Distance coding with 1VSS - Interface ◆ Distance coding with RS422 - Interface (Encoder)

*Max. differential input between SIN- (X13/7) and SIN+ (X13/8).

The motor performs automatic commutation after:

- ◆ Power on,
- ◆ A configuration download or
- ◆ An IEC program download

The time duration (typically 5-10 sec) of automatic commutation can be optimized with the start current (see in the optimization display of the C3 ServoManager; given as a percentage of the reference current). Note that values that are too high will cause Error 0x73A6 to be triggered.

Typically the motor moves by 4% of the pitch length or, with rotary direct drives 4% of 360°/number of pole pairs - maximum 50%.

Note the following conditions for automatic commutation

- ◆ During automatic commutation the end limits are not monitored.
- ◆ Actively working load torques are not permitted during automatic commutation.
- ◆ Static friction deteriorates the effect of automatic commutation.
- ◆ With the exception of missing commutation information, the controller/motor combination is configured and ready for operation (parameters correctly assigned for the linear motor/drive). The transmitter and the direction of the field of rotation in effect must match.
- ◆ The auto-commutating function must be adapted to fit the mechanics if necessary during commissioning.

9.1.1.2 Linear motors

Parker offers you a number of systems of linear motor drives:

Linear motors	Feed force (continuous/dynamic)	Stroke length:
LMDT ironless linear servo motors:	26 ... 1463N	almost any
LMI iron-cored linear servo motors:	52 ... 6000N	64 ... 999mm
LXR Series Linear Motors	315N / 1000N	up to 3m
Linear motor module BLMA:	605N / 1720N	up to 6m

9.1.1.3 Torque motors

Parker offers you an extensive range of torque motors that can be adapted to your application. Please contact us for information.

Additional information can be found on the **Internet** <http://www.parker-eme.com> in the direct drives section.

9.1.2. Rotary servo motors

Parker offers you an extensive range of servo motors that can be adapted to your application. Please contact us for information.

Additional information can be found on the **Internet** <http://www.parker-eme.com/sm>

or on the DVD supplied in the documentations file.

Suitable servo motors for Compax3H are available on request!

9.2 EMC measures

In this chapter you can read about:

Mains filter.....	351
Motor output filter.....	356
Mains filters	358

9.2.1. Mains filter

For radio disturbance suppression and for complying with the emission limit values for CE conform operation we offer mains filters:

Observe the maximum permitted length of the connection between the mains filter and the device:

- ◆ unshielded <0.5m;
- ◆ shielded: <5m (fully shielded on ground e.g. ground of control cabinet)

Order code mains filter Compax3S

		<input type="text"/>	<input type="text"/>	/	<input type="text"/>	<input type="text"/>
for C3S025V2 or S063V2	NFI	0	1	/	0	1
for C3S0xxV4, S150V4 or S1xxV2	NFI	0	1	/	0	2
for C3S300V4	NFI	0	1	/	0	3

Order Code mains filter PSUP

		<input type="text"/>	<input type="text"/>	/	<input type="text"/>	<input type="text"/>
for PSUP10	Reference axis combination 3x480V 25A 6x10m motor cable length	NFI	0	3	/	0 1
for PSUP10	Reference axis combination 3x480V 25A 6x50m motor cable length	NFI	0	3	/	0 2
for PSUP20 & PSUP30	Reference axis combination 3x480V 50A 6x50m motor cable length	NFI	0	3	/	0 3

Order code for mains filters

for PSUP30	Mains filter	LCG-0055-0.45 mH
for PSUP30	Mains filter with UL approval	LCG-0055-0.45 mH-UL


Order code mains filter Compax3H

		<input type="text"/>	<input type="text"/>	/	<input type="text"/>	<input type="text"/>
for C3H050V4	NFI	0	2	/	0	1
for C3H090V4	NFI	0	2	/	0	2
for C3H1xxV4	NFI	0	2	/	0	3

9.2.1.1 Mains filter NFI01/01

for Compax3 S025 V2 and Compax3 S063 V2


Dimensional drawing:



9.2.1.2 Mains filter NFI01/02

for Compax3 S0xx V4, Compax3 S150 V4 and Compax3 S1xx V2


Dimensional drawing:



9.2.1.3 Mains filter for NFI01/03

for Compax3 S300


Dimensional drawing:



9.2.1.4 Mains filter NFI02/0x

Filter for mounting below the Compax3 Hxxx V4 housing

Dimensional drawing:



Stated in mm	Filter type	Dimensions				Hole distances			Distances		Weight kg	Grounding clamp	Connection clamp	
		B	H	H2	T	B1	H1	T1	BFU	HFU				
	C3H050V4	NFI02/01	233	515	456	70	186	495	40	150	440	4.3	M6	16mm ²
	C3H090V4	NFI02/02	249	715	649	95	210	695	40	150	630	8.5	M8	50mm ²
	C3H1xxV4	NFI02/03	249	830	719	110				150	700	15.0	M10	95mm ²

9.2.1.5 Mains filter NFI03/01 & NFI03/03


for PSUP10D6 and PSUP20D6

Dimensional drawing:


Bottom view




Side view



Front view



Top view




Filter type	A	B	C	D	I	F	G	H	Weight	GND(I)	Connection clamp
									kg		
NFI03/01	240	50	85	270	0.8	30	255	5.4	1.5	M5	10mm ²
NFI03/03	220	85	90	250	1.0	60	235	5.4	2.4	M6	16mm ²

Stated in mm

9.2.1.6 Mains filter NFI03/02

for PSUP10D6

Dimensional drawing:



9.2.2. Motor output filter

In this chapter you can read about:

Motor output filter MDR01/04	356
Motor output filter MDR01/01	356
Motor output filter MDR01/02	357
Wiring of the motor output filter	357

We offer motor output filters for disturbance suppression when the motor connecting cables are long (>20m):

Order code for motor output filter (for Compax3S, Compax3M >20m motor cable)


up to 6,3 A rated motor current	MDR	0	1	/	0 4
Up to 16 A rated motor current	MDR	0	1	/	0 1
Up to 30A A rated motor current	MDR	0	1	/	0 2

Larger motor output filters are available on request!

9.2.2.1 Motor output filter MDR01/04

up to 6.3A nominal motor current (3.6mH)


Dimensional drawing:



9.2.2.2 Motor output filter MDR01/01

Up to 16 A nominal motor current (2mH)


Dimensional drawing:



9.2.2.3 Motor output filter MDR01/02


up to 30A nominal motor current (1.1mH)

Dimensional drawing:



Weight: 5.8kg

9.2.2.4 Wiring of the motor output filter



9.2.3. Mains filters

In this chapter you can read about:

Mains filter for PSUP30.....358

Mains filters serve for reducing the low-frequency interferences on the mains side.


9.2.3.1 Mains filter for PSUP30

Required mains filter for the PSUP30: 0.45 mH / 55 A


We offer the following mains filters:

- ◆ LCG-0055-0.45 mH (WxDxH: 180 mm x 140 mm x 157 mm; 10 kg)
- ◆ LCG-0055-0.45 mH-UL (with UL approval) (WxDxH: 180 mm x 170 mm x 157 mm; 15 kg)

Dimensional drawing: LCG-0055-0.45 mH



Dimensional drawing: LCG-0055-0.45 mH-UL



9.3 Connections to the motor

In this chapter you can read about:

Resolver cable.....360
 SinCos© cable.....361
 EnDat cable.....362
 Motor cable.....362
 Encoder cable364

Under the designation "REK.." (resolver cables) and "MOK.."(motor cables) we can deliver motor connecting cables in various lengths to order. If you wish to make up your own cables, please consult the cable plans shown below:

Motor cable order code ⁽²⁾

for SMH / MH56 / MH70 / MH105 ⁽³⁾	(1.5mm ² ; up to 13.8A)	MOK	5 5	/ ⁽¹⁾
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(1.5mm ² ; up to 13.8A) (cable chain compatible)	MOK	5 4	/ ⁽¹⁾
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(2.5mm ² ; up to 18.9A)	MOK	5 6	/ ⁽¹⁾
for SMH / MH56 / MH70 / MH105 ⁽³⁾	(2.5mm ² ; up to 18.9A) (cable chain compatible)	MOK	5 7	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(1.5mm ² ; up to 13.8A)	MOK	6 0	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(1.5mm ² ; up to 13.8A) (cable chain compatible)	MOK	6 3	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(2.5mm ² ; up to 18.9A)	MOK	5 9	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(2.5mm ² ; up to 18.9A) (cable chain compatible)	MOK	6 4	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(6mm ² ; up to 32.3A) (cable chain compatible)	MOK	6 1	/ ⁽¹⁾
for MH145 / MH205 ⁽⁴⁾	(10mm ² ; up to 47.3A) (cable chain compatible)	MOK	6 2	/ ⁽¹⁾

^(x) **Note on cable** (see on page 347)


Order code for feedback cables

for resolver ⁽²⁾	for MH / SMH motors	REK	4 2	/ ⁽¹⁾
for resolver ⁽²⁾	for MH / SMH motors (cable chain compatible)	REK	4 1	/ ⁽¹⁾
for SinCos© – feedback ⁽²⁾	for MH / SMH motors (cable chain compatible)	GBK	2 4	/ ⁽¹⁾
for EnDat 2.1 ⁽²⁾	for MH / SMH motors (cable chain compatible)	GBK	3 8	/ ⁽¹⁾
Encoder – Compax3		GBK	2 3	/ ⁽¹⁾
for LXR linear motors	(cable chain compatible)	GBK	3 3	/ ⁽¹⁾
for BLMA linear motors	(cable chain compatible)	GBK	3 2	/ ⁽¹⁾

^(x) **Note on cable** (see on page 347)

9.3.1. Resolver cable

REK42/..




The same cable (with changed conductor coloring) is available under the designation REK41/.. in a version which is suitable for cable chain systems.

You can find the length code in the Chapter **Order Code Accessories** (see on page 344).

9.3.2. SinCos© cable


GBK24/...: Cable chain compatible



You can find the length code in the Chapter **Order Code Accessories** (see on page 344).

9.3.3. EnDat cable

GBK38/... (cable chain compatible)




You can find the length code in the Chapter **Order Code Accessories** (see on page 344).

9.3.4. Motor cable

Cross-section / max. permanent load	Motor connector SMH motors MH56, MH70, MH105		Motor terminal box MH145, MH205	
	standard	cable chain compatible	standard	cable chain compatible
1.5 mm ² / up to 13.8 A	MOK55	MOK54	MOK60	MOK63
2.5 mm ² / up to 18.9 A	MOK56	MOK57	MOK59	MOK64
6 mm ² / up to 32.3 A	-	-	-	MOK61
10 mm ² / up to 47.3 A		--	-	MOK62

9.3.4.1 Connection of terminal box MH145 & MH205




Terminal	Assignment
A	Phase U
B	Phase V
C	Phase W
E	Protective earth terminal
F	Brake (+ red for MH205)
G	Brake (- blue for MH205)

Additional designations can be found on the connection cable clamping board - motor (internal).

9.3.5. Encoder cable

GBK23/...: Connection Compax3 - Encoder



You can find the length code in the **Order Code Accessories** (see on page 344)

9.4 External braking resistors

In this chapter you can read about:

Permissible braking pulse powers of the braking resistors	366
Dimensions of the braking resistors	376



Danger!

Hazards when handling ballast resistors!

Housing temperature up to 200°C!

Dangerous voltage!

The device may be operated only in the mounted state!

The external braking resistors must be installed such that protection against contact is ensured (IP20).

Install the connecting leads at the bottom.

The braking resistors must be grounded.

We recommend to use a thrust washer for the BRM13 and BRM14.

Observe the instructions on the resistors (warning plate).

Please note that the length of the supply cable must not exceed 2m!

Ballast resistors for Compax3

Ballast resistor (see on page 365)	Device	Rated output
BRM08/01 (100Ω)	Compax3S025V2 Compax3S015V4 Compax3S038V4	60 W
BRM05/01 (56Ω)	Compax3S063V2 Compax3S075V4	180 W
BRM05/02 (56Ω)	Compax3S075V4	570 W
BRM10/01 (47Ω)	Compax3S150V4	570 W
BRM10/02 (470Ω)	Compax3S150V4	1500 kW
BRM04/01 (15Ω)	Compax3S150V2 Compax3S300V4 PSUP20D6	570 W
BRM04/02 (15Ω)	Compax3S150V2 Compax3S300V4 PSUP20D6	740 W
BRM04/03 (15Ω)	Compax3S300V4 PSUP20D6	1500 W
BRM09/01 (22Ω)	Compax3S100V2	570 W
BRM11/01 (27Ω)	Compax3H0xxV4	3500 W
BRM13/01 (30Ω)	PSUP10D6 PSUP20D6**	500 W
BRM14/01 (15Ω)	PSUP10D6* PSUP20D6	500 W
BRM12/01 (18Ω)	Compax3H1xxV4	4500 W

*for PSUP10D6 2x15Ω in series

**for PSUP20D6 2x30Ω parallel


9.4.1. Permissible braking pulse powers of the braking resistors

In this chapter you can read about:

Calculation of the BRM cooling time.....	367
Permissible braking pulse power: BRM08/01 with C3S015V4 / C3S038V4	368
Permissible braking pulse power: BRM08/01 with C3S025V2	368
Permissible braking pulse power: BRM09/01 with C3S100V2	369
Permissible braking pulse power: BRM10/01 with C3S150V4	369
Permissible braking pulse power: BRM10/02 with C3S150V4	370
Permissible braking pulse power: BRM05/01 with C3S063V2	370
Permissible braking pulse power: BRM05/01 with C3S075V4	371
Permissible braking pulse power: BRM05/02 with C3S075V4	371
Permissible braking pulse power: BRM04/01 with C3S150V2	372
Permissible braking pulse power: BRM04/01 with C3S300V4	372
Permissible braking pulse power: BRM04/02 with C3S150V2	373
Permissible braking pulse power: BRM04/02 with C3S300V4	373
Permissible braking pulse power: BRM04/03 with C3S300V4	374
Permissible braking pulse power: BRM11/01 with C3H0xxV4	374
Permissible braking pulse power: BRM12/01 with C3H1xxV4	375
Permissible braking pulse power: BRM13/01 with PSUP10D6	375
Permissible braking pulse power: BRM14/01 with PSUP10D6	375

The diagrams show the permissible braking pulse powers of the braking resistors in operation with the assigned Compax3.

9.4.1.1 Calculation of the BRM cooling time



F = Factor

Cooling time = F * braking time

Example 1: For a braking time of 1s, a braking power of 1kW is required. The Diagram shows the following:

The required values can be found in the range between characteristic F = 0.5 and F = 1. In order to achieve operating safety, please select the higher factor, this means that the required cooling time is 1s.

F * Braking time = cooling time

1 * 1s = 1s


Example 2: For a braking time of 0.5s, a braking power of 3kW is required. The Diagram shows the following:

The required values can be found in the range between characteristic F = 2 and F = 5. In order to achieve operating safety, please select the higher factor, this means that the required cooling time is 2.5s.


F * Braking time = cooling time

5 * 0.5s = 2.5s


9.4.1.2 Permissible braking pulse power: BRM08/01 with C3S015V4 / C3S038V4




9.4.1.3 Permissible braking pulse power: BRM08/01 with C3S025V2




9.4.1.4 Permissible braking pulse power: BRM09/01 with C3S100V2




9.4.1.5 Permissible braking pulse power: BRM10/01 with C3S150V4




9.4.1.6 Permissible braking pulse power: BRM10/02 with C3S150V4




9.4.1.7 Permissible braking pulse power: BRM05/01 with C3S063V2




9.4.1.8 Permissible braking pulse power: BRM05/01 with C3S075V4




9.4.1.9 Permissible braking pulse power: BRM05/02 with C3S075V4




9.4.1.10 Permissible braking pulse power: BRM04/01 with C3S150V2




9.4.1.11 Permissible braking pulse power: BRM04/01 with C3S300V4




9.4.1.12 Permissible braking pulse power: BRM04/02 with C3S150V2




9.4.1.13 Permissible braking pulse power: BRM04/02 with C3S300V4




9.4.1.14 Permissible braking pulse power: BRM04/03 with C3S300V4



9.4.1.15 Permissible braking pulse power: BRM11/01 with C3H0xxV4



9.4.1.16 Permissible braking pulse power: BRM12/01 with C3H1xxV4



9.4.1.17 Permissible braking pulse power: BRM13/01 with PSUP10D6

on request

9.4.1.18 Permissible braking pulse power: BRM14/01 with PSUP10D6

on request


9.4.2. Dimensions of the braking resistors

In this chapter you can read about:

BRM8/01 braking resistors.....	376
BRM5/01 braking resistor.....	376
Braking resistor BRM5/02, BRM9/01 & BRM10/01.....	376
Ballast resistor BRM4/0x and BRM10/02.....	377
Braking resistor BRM11/01 & BRM12/01.....	377
Ballast resistor BRM13/01 & BRM14/01.....	378


9.4.2.1 BRM8/01 braking resistors

Dimensional drawing:




9.4.2.2 BRM5/01 braking resistor

Dimensional drawing:




9.4.2.3 Braking resistor BRM5/02, BRM9/01 & BRM10/01

Dimensional drawing:



9.4.2.4 Ballast resistor BRM4/0x and BRM10/02

Dimensional drawing:




1: thermal overcurrent relay

Dimensions in mm:

Size:	BRM4/01	BRM4/02	BRM4/03 & BRM10/02
A	250	300	540
B	330	380	620
C	64	64	64

9.4.2.5 Braking resistor BRM11/01 & BRM12/01

Dimensional drawing:




Dimensions in mm:

	BRM11/01	BRM12/02
B	330	
B1	295	
B2	270	
H	260	
Weight	6.0	7.0

9.4.2.6 Ballast resistor BRM13/01 & BRM14/01

Dimensional drawing:



9.5 Condenser module C4

Order code condenser module


Modules	C4

for C3S300V4

1100µF


Technical Characteristics

Type	Capacity	Cable length
Module C4	1100µF	~30 cm



Dimensions in mm

Module C4	A	B	C	C1	D	E	F	G	H
	430	190	90	120	370	15	18	30	∅ 6



9.6 Operator control module BDM

Order Code operating module

		/		
BDM	0 1	/	0 1	

Operating module (for Compax3S and Compax3F)

Flexible service and maintenance



Functions:

- ◆ Mobile or stationary handling: can remain on the unit for display and diagnostic purposes, or can be plugged into any unit.
- ◆ Can be plugged in while in operation
- ◆ Power supply via Compax3 servo control
- ◆ Display with 2 times 16 places.
- ◆ Menu-driven operation using 4 keys.
- ◆ Displays and changing of values.
- ◆ Display of Compax3 messages.
- ◆ Duplication of device properties and IEC61131-3 program to another Compax3 with identical hardware.
- ◆ Additional information can be found in the BDM manual This can be found on the Compax3 CD or on our Homepage: **BDM-manual** (http://divapps.parker.com/divapps/EME/EME/Literature_List/dokumentationen/BDM.pdf).

9.7 EAM06: Terminal block for inputs and outputs

Order Code terminal block

for I/Os without luminous indicator	for X11, X12, X22	EAM	0 6 / 0 1		
for I/Os with luminous indicator	for X12, X22	EAM	0 6 / 0 2		

The terminal block EAM06/.. can be used to route the Compax3 plug connector X11 or X12 for further wiring to a terminal strip and to a Sub-D plug connector.

Via a supporting rail (Design:  or ) the terminal unit can be attached to a mounting rail in the switch cabinet.

EAM06/ is available in 2 variants:

- ◆ EAM06/01: Terminal block for X11, X12, X22 without luminous indicator
- ◆ EAM06/02: Terminal block for X12, X22 with luminous indicator

Corresponding connecting cables EAM06 - Compax3 are available:

- ◆ from X11 - EAM06/01: SSK23/..
- ◆ from X12, X22 - EAM06/xx: SSK24/..

EAM06/01: Terminal block without luminous indicator for X11, X12 or X22




Figure similar

Width: 67.5 mm

EAM06/02: Terminal block with luminous indicator for X12, X22






Figure similar

Width: 67.5 mm

Cable plan SSK23/..: X11 to EAM 06/01




Cable plan SSK24/..: X12 to EAM 06/xx



9.8.2. RS485 cable to Pop

SSK27: Connection Pop - Compax3 - Compax3 - ...



R21 = 220 Ohm

⁶ **Order code: SSK27/nn/..**

Length A (Pop - 1. Compax3) variable (the last two numbers according to the length code for cable, for example SSK27/nn/01)

Length B (1. Compax3 - 2. Compax3 - ... - n. Compax3) fixed 50 cm (only if there is more than 1 Compax3, i.e. nn greater than 01)

Number n (the last two digits)


Examples include:

SSK27/05/.. for connecting from Pop to 5 Compax3.

SSK27/01/.. for connecting from Pop to one Compax3

9.8.3. I/O interface X12 / X22


SSK22/...: Cable for X12 / X22 with flying leads



You can find the length code in the **Order Code Accessories** (see on page 344)

9.8.4. Ref X11



SSK21/...: Cable for X11 with open ends



You can find the length code in the **Order Code Accessories** (see on page 344)

9.8.5. Encoder coupling of 2 Compax3 axes

SSK29/...: Cable from Compax3 X11 to Compax3 X11




You can find the length code in the **Order Code Accessories** (see on page 344)

Compax3 HEDA ⇔ Compax3 HEDA or PC ⇔ C3powerPLmC
Compax3 I30 ⇔ Compax3 I30 or C3M-multi axis communication


Profinet, EtherCAT, Ethernet Powerlink

Layout of SSK28:



9.8.6. Modem cable SSK31

SSK31/..



You can find the length code in the **Order Code Accessories** (see on page 344)

9.9 Options M1x


In this chapter you can read about:

Input/output option M12	388
HEDA (motion bus) - Option M11	389
Option M10 = HEDA (M11) & I/Os (M12)	391

9.9.1. Input/output option M12

An optional input/output extension is available for Compax3. This option is named M12 (or M10: with HEDA) and offers 8 digital 24V inputs and 4 digital outputs on X22.

9.9.1.1 Assignment of the X22 connector



Pin X22/	Input/output	I/O /X22 High density/Sub D	Configurable in the C3 ServoManager *:	
1	n.c.	factory use		
2	O0/I0	Output 0 / Input 0 - adjustable	*	
3	O1/I1	Output 1 / Input 1 - adjustable		
4	O2/I2	Output 2 / Input 2 - adjustable		
5	O3/I3	Output 3 / Input 3 - adjustable		
6	O4/I4	Output 4 / Input 4 - adjustable	*	
7	O5/I5	Output 5 / Input 5 - adjustable		
8	O6/I6	Output 6 / Input 6 - adjustable		
9	O7/I7	Output 7 / Input 7 - adjustable		
10	O8/I8	Output 8 / Input 8 - adjustable	*	
11	I	24 VDC power supply		(not 24VDC)
12	O9/I9	Output 9 / Input 9 - adjustable		
13	O10/I10	Output 10 / Input 10 - adjustable		
14	O11/I11	Output 11 / Input 11 - adjustable		
15	E	GND24V		

* Configurable as input or output in the wizard window "I/O assignment" in groups of 4.


All inputs and outputs have 24V level.

Maximum load on an output: 100mA

Maximum capacitive load: 50nF (max. 4 Compax3 inputs)

Caution! The 24VDC power supply (X22/11) must be supplied from an external source and must be protected by a 1.2A delayed fuse!


Input wiring of digital inputs



The circuit example is valid for all digital inputs!

F1: Quick action electronic fuse; can be reset by switching the 24VDC supply off and on again.

Output wiring of digital outputs




The circuit example is valid for all digital outputs!

The outputs are short circuit proof; a short circuit generates an error.

F1: Quick action electronic fuse; can be reset by switching the 24VDC supply off and on again.

9.9.2. HEDA (motion bus) - Option M11



	RJ45 (X20)	RJ45 (X21)
Pin	HEDA in	HEDA out
1	Rx	Tx
2	Rx/	Tx/
3	Lx	Lx
4	-	factory use
5	-	factory use
6	Lx/	Lx/
7	-	factory use
8	-	factory use

Function of the HEDA LEDs

Green LED (left)

HEDA module energized

Red LED (right)

Error in the receive area

Possible causes:

- ◆ at the Master
 - ◆ no slave sending back
 - ◆ Wrong cabling
 - ◆ Terminal plug is missing
 - ◆ several masters are sending in the same slot
- ◆ at the slave
 - ◆ several masters in the system
 - ◆ no master active
 - ◆ Terminal plug is missing
 - ◆ no transmission from one or several receive slots (neither by the master nor by another slave)


HEDA-wiring:

HEDA-Master



Layout of SSK28 (see on page 346, see on page 386)

Design of the HEDA bus terminator BUS 07/01:



Jumpers: 1-7, 2-8, 3-4, 5-6

Function of the HEDA LEDs

Green LED (left)

HEDA module energized

Red LED (right)

Error in the receive area

Possible causes:

- ◆ at the Master
 - ◆ no slave sending back
 - ◆ Wrong cabling
 - ◆ Terminal plug is missing
 - ◆ several masters are sending in the same slot
- ◆ at the slave
 - ◆ several masters in the system
 - ◆ no master active
 - ◆ Terminal plug is missing
 - ◆ no transmission from one or several receive slots (neither by the master nor by another slave)

9.9.3. Option M10 = HEDA (M11) & I/Os (M12)

The M10 option includes the M12 input/output option and the HEDA M11 option.

10. Technical Characteristics

Mains connection Compax3S0xxV2 1AC

Controller type	S025V2	S063V2
Supply voltage	Single phase 230VAC/240VAC 80-253VAC / 50-60Hz	
Input current	6Arms	13Arms
Maximum fuse rating per device (=short circuit rating)	10 A (MCB miniature circuit breaker, K characteristic)	16A (automatic circuit breaker K)

Mains connection Compax3S1xxV2 3AC

Controller type	S100V2	S150V2
Supply voltage	Three phase 3* 230VAC/240VAC 80-253VAC / 50-60Hz	
Input current	10Arms	13Arms
Maximum fuse rating per device (=short circuit rating)	16A	20A
	MCB miniature circuit breaker, K characteristic	

Mains connection Compax3SxxxV4 3AC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Supply voltage	Three phase 3*400VAC/480VAC 80-528VAC / 50-60Hz				
Input current	3Aeff	6Arms	10Arms	16Arms	22Arms
Maximum fuse rating per device(=short circuit rating)	6A	10A	16A	20A	25A
	MCB miniature circuit breaker, K characteristic				D*

Mains connection PSUP10D6

Device type PSUP10	230V	400V	480V
Supply voltage	230VAC $\pm 10\%$ 50-60Hz	400VAC $\pm 10\%$ 50-60Hz	480VAC $\pm 10\%$ 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	22Arms	22Arms	18Arms
Output voltage	325VDC $\pm 10\%$	565VDC $\pm 10\%$	680VDC $\pm 10\%$
Output power	6kW	10 kW	10 kW
Pulse power (<5s)	12kW	20kW	20kW
Power dissipation	60W	60W	60W
Maximum fuse rating per device (=short circuit rating)	Measure for line and device protection: MCB miniature circuit breaker (K characteristic) 25A in accordance with UL category DIVQ Recommendation: (ABB) S203UP-K 25(480VAC)		

Mains connection PSUP20D6

Device type PSUP20	230V	400V	480V
Supply voltage	230VAC $\pm 10\%$ 50-60Hz	400VAC $\pm 10\%$ 50-60Hz	480VAC $\pm 10\%$ 50-60Hz
Rated voltage	3AC 230V	3AC 400V	3AC 480V
Input current	44Arms	44Arms	35Arms
Output voltage	325VDC $\pm 10\%$	565VDC $\pm 10\%$	680VDC $\pm 10\%$
Output power	12kW	20kW	20kW
Pulse power (<5s)	24kW	40kW	40kW
Power dissipation	120W	120W	120W
Maximum fuse rating per device (=short circuit rating) 2 circuit breakers in line are required	Cable protection measure: MCB (K characteristic) with a rating of 50A / 4xxVAC (depending on the input voltage) Recommendation: (ABB) S203U-K50 (440VAC) Device protection measure: Circuit breakers 80A / 700VAC per supply leg in accordance with UL category JFHR2 Requirement: Bussmann 170M1366 or 170M1566D		

Mains connection Compax3HxxxV4 3*400VAC

Device type Compax3	H050V4	H090V4	H125V4	H155V4
Supply voltage	Three-phase 3*400VAC 350-528VAC / 50-60Hz			
Input current	66Arms	95Arms	143Arms	164Arms
Output current	50Arms	90Arms	125Arms	155Arms
Maximum fuse rating per device(=short circuit rating)	80A	100A	160A	200A
Branch circuit protection according to UL	JDDZ Class K5 or H JDRX Class H			

Mains connection Compax3HxxxV4 3*480VAC

Device type Compax3	H050V4	H090V4	H125V4	H155V4
Supply voltage	Three-phase 3*480VAC 350-528VAC / 50-60Hz			
Input current	54Arms	82Arms	118Arms	140Arms
Output current	43Arms	85Arms	110Arms	132Arms
Maximum fuse rating per device(=short circuit rating)	80A	100A	160A	200A
Branch circuit protection according to UL	JDDZ Class K5 or H JDRX Class H			

Control voltage 24VDC Compax3S and Compax3H

Controller type	Compax3
Voltage range	21 - 27VDC
Current drain of the device	0.8 A
Total current drain	0.8 A + Total load of the digital outputs + current for the motor holding brake
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes
Short-circuit proof	conditional (internally protected with 3.15AT)

Control voltage 24 VDC PSUP

Device type	PSUP
Voltage range	21 - 27VDC
Ripple	0.5Vpp
Requirement according to safe extra low voltage (SELV)	yes (class 2 mains module)
Current drain PSUP	PSUP10: 0.2A PSUP20 / PSUP30: 0.3A
Electric current drain Compax3M	C3M050D6: 0.85 3M100D6: 0.85A C3M150D6: 0.85A C3M300D6: 1.0 A + Total load of the digital outputs + current for the motor holding brake

Output data Compax3S0xx at 1*230VAC/240VAC

Controller type	S025V2	S063V2
Output voltage	3x 0-240V	3x 0-240V
Nominal output current	2.5Arms	6.3Arms
Pulse current for 5s	5.5Arms	12.6Arms
Power	1kVA	2.5kVA
Switching frequency	16kHz	16kHz
Power loss for In	30W	60W

Output data Compax3S1xx at 3*230VAC/240VAC

Controller type	S100V2	S150V2
Output voltage	3x 0-240V	3x 0-240V
Nominal output current	10Arms	15Arms
Pulse current for 5s	20Arms	30Arms
Power	4kVA	6kVA
Switching frequency	16kHz	8kHz
Power loss for In	80W	130W

Output data Compax3Sxxx at 3*400VAC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Output voltage	3x 0-400V				
Nominal output current	1.5Arms	3.8Arms	7.5Arms	15Arms	30Arms
Pulse current for 5s	4.5Arms	9.0Arms	15Arms	30Arms	60Arms*
Power	1kVA	2.5kVA	5kVA	10kVA	20kVA
Switching frequency	16kHz	16kHz	16kHz	8kHz	8kHz
Power loss for In	60W	80W	120W	160W	350W

* With cyclic peak currents (S8 or S9 operation), the device utilization (683.2) may not be > 70%; otherwise it is necessary to use a condenser module "C4Module (see on page 379)".

Output data Compax3Sxxx at 3*480VAC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Output voltage	3x 0-480V				
Nominal output current	1.5Arms	3.8Arms	6.5Arms	13.9Arms	30Arms
Pulse current for 5s	4.5Arms	7.5Arms	15Arms	30Arms	60Arms*
Power	1.25kVA	3.1kVA	6.2kVA	11.5kVA	25kVA
Switching frequency	16kHz	16kHz	16kHz	8kHz	8kHz
Power loss for In	60W	80W	120W	160W	350W

* With cyclic peak currents (S8 or S9 operation), the device utilization (683.2) may not be > 70%; otherwise it is necessary to use a condenser module "C4Module (see on page 379)".

Output data Compax3Mxxx at 3*230VAC

Device type Compax3	M050D6	M100D6	M150D6	M300D6
Input voltage	325VDC ±10%			
Output voltage	3x 0-230V (0...500Hz)			
Nominal output current	5Arms	10Arms	15Arms	30Arms
Pulse current for 5s*	10Arms	20Arms	30Arms	60Arms
Power	2kVA	4kVA	6kVA	12kVA
Switching frequency	8kHz	8kHz	8kHz	8kHz
Power loss for In	70W+**	90W+**	120W+**	270W+**

*Electrical turning frequency for pulse current: $f > 5$ Hz; with an electrical turning frequency of $f < 5$ Hz, the maximum pulse current time is 100ms

** Maximum additional losses with option card 5 W.

Output data Compax3Mxxx at 3*400VAC

Device type Compax3	M050D6	M100D6	M150D6	M300D6
Input voltage	565VDC ±10%			
Output voltage	3x 0-400V (0...500Hz)			
Nominal output current	5Arms	10Arms	15Arms	30Arms
Pulse current for 5s*	10Arms	20Arms	30Arms	60Arms
Power	3.33kVA	6.66kVA	10kVA	20kVA
Switching frequency	8kHz	8kHz	8kHz	8kHz
Power loss for In	70W+**	90W+**	120W+**	270W+**

*Electrical turning frequency for pulse current: $f > 5$ Hz; with an electrical turning frequency of $f < 5$ Hz, the maximum pulse current time is 100ms

** Maximum additional losses with option card 5 W.

Output data Compax3Mxxx at 3*480VAC

Device type Compax3	M050D6	M100D6	M150D6	M300D6
Input voltage	680VDC ±10%			
Output voltage	3x 0-480V (0...500Hz)			
Nominal output current	4Arms	8Arms	12.5Arms	25Arms
Pulse current for 5s*	8Arms	16Arms	25Arms	50Arms
Power	3.33kVA	6.66kVA	10kVA	20kVA
Switching frequency	8kHz	8kHz	8kHz	8kHz
Power loss for In	70W+**	90W+**	120W+**	270W+**

*Electrical turning frequency for pulse current: $f > 5$ Hz; with an electrical turning frequency of $f < 5$ Hz, the maximum pulse current time is 100ms

** Maximum additional losses with option card 5 W.

Output data Compax3Hxxx at 3*400VAC

Controller type	H050V4	H090V4	H125V4	H155V4
Output voltage	3x 0-400V			
Nominal output current	50Arms	90Arms	125Arms	155Arms
Pulse current for 5s *	75Arms	135Arms	187.5Arms	232.5Arms
Power	35kVA	62kVA	86kVA	107kVA
Switching frequency	8kHz	8kHz	8kHz	8kHz
Power loss for In	880W	900W	1690W	1970W

* during low speeds, the overload time is reduced to 1s. Limit:

< 2.5 electric rev/s (= actual revolutions/s * number of pole pairs) resp. >2.5 pitch/s

Output data Compax3Hxxx at 3*480VAC

Controller type	H050V4	H090V4	H125V4	H155V4
Output voltage	3x 0-480V			
Nominal output current	43Arms	85Arms	110Arms	132Arms
Pulse current for 5s*	64.5Arms	127.5Arms	165Arms	198Arms
Power	35kVA	70kVA	91kVA	109kVA
Switching frequency	8kHz	8kHz	8kHz	8kHz
Power loss for In	850W	1103W	1520W	1800W

* during low speeds, the overload time is reduced to 1s. Limit:

< 2.5 electric rev/s (= actual revolutions/s * number of pole pairs) resp. >2.5 pitch/s

Resulting nominal and peak currents depending on the switching frequency

Compax3S0xxV2 at 1*230VAC/240VAC

Switching frequency*		S025V2	S063V2
16kHz	I _{nom}	2.5A _{rms}	6,3A _{rms}
	I _{peak} (<5s)	5.5A _{rms}	12,6A _{rms}
32kHz	I _{nom}	2.5A _{rms}	5.5A _{rms}
	I _{peak} (<5s)	5.5A _{rms}	12,6A _{rms}

Compax3S1xxV2 at 3*230VAC/240VAC

Switching frequency*		S100V2	S150V2
8kHz	I _{nom}	-	15A _{rms}
	I _{peak} (<5s)	-	30A _{rms}
16kHz	I _{nom}	10A _{rms}	12.5A _{rms}
	I _{peak} (<5s)	20A _{rms}	25A _{rms}
32kHz	I _{nom}	8A _{rms}	10A _{rms}
	I _{peak} (<5s)	16A _{rms}	20A _{rms}

Compax3S0xxV4 at 3*400VAC

Switching frequency*		S015V4	S038V4	S075V4	S150V4	S300V4
8kHz	I _{nom}	-	-	-	15A _{rms}	30A _{rms}
	I _{peak} (<5s)	-	-	-	30A _{rms}	60A _{rms}
16kHz	I _{nom}	1.5A _{rms}	3.8A _{rms}	7.5A _{rms}	10.0A _{rms}	26A _{rms}
	I _{peak} (<5s)	4.5A _{rms}	9.0A _{rms}	15.0A _{rms}	20.0A _{rms}	52A _{rms}
32kHz	I _{nom}	1.5A _{rms}	2.5A _{rms}	3.7A _{rms}	5.0A _{rms}	14A _{rms}
	I _{peak} (<5s)	3.0A _{rms}	5.0A _{rms}	10.0A _{rms}	10.0A _{rms}	28A _{rms}

Compax3S0xxV4 at 3*480VAC

Switching frequency*		S015V4	S038V4	S075V4	S150V4	S300V4
8kHz	I _{nom}	-	-	-	13.9A _{rms}	30A _{rms}
	I _{peak} (<5s)	-	-	-	30A _{rms}	60A _{rms}
16kHz	I _{nom}	1.5A _{rms}	3.8A _{rms}	6.5A _{rms}	8.0A _{rms}	21.5A _{rms}
	I _{peak} (<5s)	4.5A _{rms}	7.5A _{rms}	15.0A _{rms}	16.0A _{rms}	43A _{rms}
32kHz	I _{nom}	1.0A _{rms}	2.0A _{rms}	2.7A _{rms}	3.5A _{rms}	10A _{rms}
	I _{peak} (<5s)	2.0A _{rms}	4.0A _{rms}	8.0A _{rms}	7.0A _{rms}	20A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

Resulting nominal and peak currents depending on the switching frequency

Compax3MxxxD6 at 3*400VAC

Switching frequency*		M050D6	M100D6	M150D6	M300D6
8kHz	I_{nom}	5A _{rms}	10A _{rms}	15A _{rms}	30A _{rms}
	$I_{peak} (<5s)$	10A _{rms}	20A _{rms}	30A _{rms}	60A _{rms}
16kHz	I_{nom}	3.8A _{rms}	7.5A _{rms}	10A _{rms}	20A _{rms}
	$I_{peak} (<5s)$	7.5A _{rms}	15A _{rms}	20A _{rms}	40A _{rms}
32kHz	I_{nom}	2.5A _{rms}	3.8A _{rms}	5A _{rms}	11A _{rms}
	$I_{peak} (<5s)$	5A _{rms}	7.5A _{rms}	10A _{rms}	22A _{rms}

Compax3MxxxD6 at 3*480VAC

Switching frequency*		M050D6	M100D6	M150D6	M300D6
8kHz	I_{nom}	4A _{rms}	8A _{rms}	12.5A _{rms}	25A _{rms}
	$I_{peak} (<5s)$	8A _{rms}	16A _{rms}	25A _{rms}	50A _{rms}
16kHz	I_{nom}	3A _{rms}	5.5A _{rms}	8A _{rms}	15A _{rms}
	$I_{peak} (<5s)$	6A _{rms}	11A _{rms}	16A _{rms}	30A _{rms}
32kHz	I_{nom}	2A _{rms}	2.5A _{rms}	4A _{rms}	8.5A _{rms}
	$I_{peak} (<5s)$	4A _{rms}	5A _{rms}	8A _{rms}	17A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

Resulting nominal and peak currents depending on the switching frequency

Compax3HxxxV4 at 3*400VAC

Switching frequency*		H050V4	H090V4	H125V4	H155V4
8kHz	I_{nom}	50A _{rms}	90A _{rms}	125A _{rms}	155A _{rms}
	$I_{peak} (<5s)$	75A _{rms}	135A _{rms}	187.5A _{rms}	232.5A _{rms}
16kHz	I_{nom}	33A _{rms}	75A _{rms}	82A _{rms}	100A _{rms}
	$I_{peak} (<5s)$	49.5A _{rms}	112.5A _{rms}	123A _{rms}	150A _{rms}
32kHz	I_{nom}	19A _{rms}	45A _{rms}	49A _{rms}	59A _{rms}
	$I_{peak} (<5s)$	28.5A _{rms}	67.5A _{rms}	73.5A _{rms}	88.5A _{rms}

Compax3HxxxV4 at 3*480VAC

Switching frequency*		H050V4	H090V4	H125V4	H155V4
8kHz	I_{nom}	43A _{rms}	85A _{rms}	110A _{rms}	132A _{rms}
	$I_{peak} (<5s)$	64.5A _{rms}	127.5A _{rms}	165A _{rms}	198A _{rms}
16kHz	I_{nom}	27A _{rms}	70A _{rms}	70A _{rms}	84A _{rms}
	$I_{peak} (<5s)$	40.5A _{rms}	105A _{rms}	105A _{rms}	126A _{rms}
32kHz	I_{nom}	16A _{rms}	40A _{rms}	40A _{rms}	48A _{rms}
	$I_{peak} (<5s)$	24A _{rms}	60A _{rms}	60A _{rms}	72A _{rms}

The values marked with grey are the pre-set values (standard values)!

*corresponds to the frequency of the motor current

Resolution of the motor position

For option F10: Resolver	<ul style="list-style-type: none"> ◆ Position resolution: 16 Bits (= 0.005°) ◆ Absolute accuracy: ±0.167°
For option F11: SinCos®	<ul style="list-style-type: none"> ◆ Position resolution: 13.5 Bits / Encoder sine period => 0.03107°/encoder resolution
For option F12:	<ul style="list-style-type: none"> ◆ Maximum position resolution <ul style="list-style-type: none"> ◆ Linear: 24 Bits per motor magnet spacing ◆ Rotary: 24 Bits per motor revolution ◆ Resolution for Sine-Cosine encoders (e.g. EnDat) with 1Vss signal): 13.5 bits / graduation of the scale of the encoder ◆ For RS 422 encoders: 4x encoder resolution ◆ Accuracy of the feedback zero pulse acquisition = accuracy of the feedback resolution. ◆ Resolution for analog hall sensors with 1Vss signal: 13.5 Bits / motor magnet spacing

Accuracy

The exactitude of the position signal is above all determined by the exactitude of the feedback system used.

Motors and feedback systems supported

Motors Direct drives ◆ Linear motors ◆ Torque motors	<ul style="list-style-type: none"> ◆ Sinusoidally commutated synchronous motors <ul style="list-style-type: none"> ◆ Maximum electrical turning frequency: 1000Hz* ◆ Max. velocity at 8 pole motors: 15000 rpm. ◆ General max. Velocity: 60*1000/number of pole pairs in [rpm] ◆ Max. number of poles = 600 ◆ Sinusoidal commutated asynchronous motors <ul style="list-style-type: none"> ◆ Maximum electrical turning frequency: 1000Hz ◆ Max. velocity: 60*1000/number of pole pairs - slip in [rpm]. ◆ Field weakening: typically up to triple (higher on request). ◆ Temperature sensor: KTY84-130 (insulated in accordance with EN60664-1 or IEC60664-1) ◆ 3 phase synchronous direct drives
Position encoder (Feedback)	<u>Option F10: Resolver</u>
LTN:	◆ RE-21-1-A05, RE-15-1-B04
Tamagawa:	◆ TS2610N171E64, TS2620N21E11, TS2640N321E64, TS2660N31E64
Tyco (AMP)	◆ V23401-T2009-B202
	<u>Option F11: SinCos®</u>
	<ul style="list-style-type: none"> ◆ Singleturn (SICK Stegmann) ◆ Multiturn (SICK Stegmann) Absolute position up to 4096 motor revolutions. ◆ SEK52, SEL52, SEK37, SEL37, SEK160, SEK90 ◆ Rotary feedback with HIPERFACE® interface: e.g.: SRS50, SRM50, SKS36, SKM36, SEK52

* higher values on request

Special encoder systems for direct drives	Option F12
Analog hall sensors	<ul style="list-style-type: none"> ◆ Sine-Cosine signal (max. 5V_{ss}*; typical 1V_{ss}) 90° offset ◆ U-V signal (max. 5V_{ss}*; typical 1V_{ss}) 120° offset.
Encoder (linear or rotatory)	<ul style="list-style-type: none"> ◆ Sine-Cosine (max. 5V_{ss}*; typical 1V_{ss}) (max. 400kHz) or ◆ TTL (RS422) (max. 5MHz; track A o. B) with the following modes of commutation: ◆ Automatic commutation (see on page 349) or ◆ U, V, W or R, S, T commutation signals (NPN open collector) e.g. digital hall sensors, incremental encoders made by Hengstler (F series with electrical ordering variant 6)
Digital, bidirectional interface	<ul style="list-style-type: none"> ◆ All EnDat 2.1 or EnDat 2.2 (Endat01, Endat02) feedback systems with incremental track (sine-cosine track) ◆ linear or rotary ◆ max. 400kHz Sine-Cosine
Distance coded feedback systems	<ul style="list-style-type: none"> ◆ Distance coding with 1V_{SS} - Interface ◆ Distance coding with RS422 - Interface (Encoder)

*Max. differential input between SIN- (X13/7) and SIN+ (X13/8).

Feedback error compensation

Feedback error compensation	<ul style="list-style-type: none"> ◆ Automatic feedback error compensation (offset & amplification) for analog hall sensors and sine-cosine encoder can be activated in the MotorManager.
------------------------------------	--

Motor holding brake output

Motor holding brake output	Compax3
Voltage range	21 – 27VDC
Maximum output current (short circuit proof)	1.6A
Securing of brake Compax3M	3.15A

Braking operation Compax3S0xxV2 1AC

Controller type	S025V2	S063V2
Capacitance / storable energy	560µF / 15Ws	1120µF / 30Ws
Minimum braking- resistance	100Ω	56Ω
Recommended nominal power rating	20 ... 60W	60 ... 180W
Maximum continuous current	8A	15A

Braking operation Compax3S1xxV2 3AC

Controller type	S100V2	S150V2
Capacitance / storable energy	780µF / 21Ws	1170µF / 31Ws
Minimum braking- resistance	22Ω	15Ω
Recommended nominal power rating	60 ... 450W	60 ... 600W
Maximum continuous current	20A	20A

Braking operation Compax3SxxxV4 3AC

Controller type	S015V4	S038V4	S075V4	S150V4	S300V4
Capacitance / storable energy 400V / 480V	235µF 37 / 21 Ws	235µF 37 / 21 Ws	470µF 75 / 42 Ws	690µF 110 / 61 Ws	1230µF 176 / 98 Ws
Minimum braking- resistance	100Ω	100Ω	56Ω	33Ω	15Ω
Recommended nominal power rating	60 ... 100W	60 ... 250W	60 ... 500 W	60 ... 1000 W	60 ... 1000 W
Maximum continuous current	10A	10A	15A	20A	30A

Braking operation Compax3MxxxD6 (axis controller)

Device type Compax3	M050	M100	M150	M300
Capacity/ storable energy	110µF/ 18Ws at 400V 10Ws at 480V	220µF/ 37Ws at 400V 21Ws at 480V	220µF/ 37Ws at 400V 21Ws at 480V	440µF/ 74Ws at 400V 42Ws at 480V

Braking operation of Compax3HxxxV4

Controller type	H050V4	H090V4	H125V4	H155V4
Capacitance / storable energy 400V / 480V	2600 µF 602 / 419 Ws	3150 µF 729 / 507 Ws	5000 µF 1158 / 806 Ws	5000 µF 1158 / 806 Ws
Minimum braking- resistance	24 Ω	15 Ω	8 Ω	8 Ω
Maximum continuous current	11 A	17 A	31 A	31 A

Ballast resistors for Compax3

Ballast resistor (see on page 365)	Device	Rated output
BRM08/01 (100Ω)	Compax3S025V2 Compax3S015V4 Compax3S038V4	60 W
BRM05/01 (56Ω)	Compax3S063V2 Compax3S075V4	180 W
BRM05/02 (56Ω)	Compax3S075V4	570 W
BRM10/01 (47Ω)	Compax3S150V4	570 W
BRM10/02 (470Ω)	Compax3S150V4	1500 kW
BRM04/01 (15Ω)	Compax3S150V2 Compax3S300V4 PSUP20D6	570 W
BRM04/02 (15Ω)	Compax3S150V2 Compax3S300V4 PSUP20D6	740 W
BRM04/03 (15Ω)	Compax3S300V4 PSUP20D6	1500 W
BRM09/01 (22Ω)	Compax3S100V2	570 W
BRM11/01 (27Ω)	Compax3H0xxV4	3500 W
BRM13/01 (30Ω)	PSUP10D6 PSUP20D6**	500 W
BRM14/01 (15Ω)	PSUP10D6* PSUP20D6	500 W
BRM12/01 (18Ω)	Compax3H1xxV4	4500 W

*for PSUP10D6 2x15Ω in series

**for PSUP20D6 2x30Ω parallel

Size / weight Compax3S

Controller type	Dimensions HxWxD [mm]	Weight [kg]
Compax3S025V2	191 x 84 x 172	2.0
Compax3S063V2	191 x 100 x 172	2.5
Compax3S015V4	248 x 84 x 172	3.1
Compax3S100V2	248 x 115 x 172	4.3
Compax3S150V2	248 x 158 x 172	6.8
Compax3S038V4	248 x 100 x 172	3.5
Compax3S075V4	248 x 115 x 172	4.3
Compax3S150V4	248 x 158 x 172	6.8
Compax3S300V4	380 x 175 x 172	10.9

Minimum mounting distance: 15mm at the sides, above & below 100mm

Protection type IP20

Drawings, Mounting (see on page 71, see on page 77)

Size / weight PSUP/Compax3M

Device type	Dimensions HxWxD [mm]	Weight [kg]
PSUP10D6	360 x 50 x 263	3.95
PSUP20D6 & PSUP30D6	360 x 100 x 263	6.3
Compax3M050D6	360 x 50 x 263	3.5
Compax3M100D6	360 x 50 x 263	3.6
Compax3M150D6	360 x 50 x 263	3.6
Compax3M300D6	360 x 100 x 263	5.25

Protection type IP20

Size / weight Compax3H

Mounting (see on page 71, see on page 77)

Controller type	Dimensions HxWxD [mm]	Weight [kg]
Compax3H050V4	453 x 252 x 245	17.4
Compax3H090V4	668.6 x 257 x 312	32.5
Compax3H125V4	720 x 257 x 355	41
Compax3H155V4	720 x 257 x 355	41

Protection class IP20 when mounted in a control cabinet (not for Compax3H1xxxV4)

Safety technology Compax3S

Safe torque-off in accordance with EN ISO 13849: 2008, Category 3, PL d/e Certified. Test mark IFA 1003004	<ul style="list-style-type: none"> ◆ For implementation of the “protection against unexpected start-up” function described in EN1037. ◆ Please note the circuitry examples (see on page 80).
---	---

Compax3S STO (=safe torque off)

Nominal voltage of the inputs	24 V
Required isolation of the 24V control voltage	Grounded protective extra low voltage, PELV
Protection of the STO control voltage	1 A
Grouping of safety level	<p>STO switch-off via internal safety relay & digital input: PL e, PFHd=2.98E-8</p> <p>STO switch-off via internal safety relay & fieldbus: PL d, PFHd=1.51E-7</p> <p>A MTTFd=15 of the external PLC and STO cycles/year < 500 000 are assumed.</p>

Safety technology Compax3M

Safe torque-off in accordance with EN ISO 13849-1: 2007, Category 3, PL=e Certified. Test mark MFS 09029	<ul style="list-style-type: none"> ◆ Please respect the stated safety technology on the type designation plate (see on page 13) and the circuitry examples (see on page 95)
---	--

Compax3M S1 Option: Signal inputs for connector X14

Nominal voltage of the inputs	24V
Required isolation of the 24V control voltage	Grounded protective extra low voltage, PELV
Protection of the STO control voltage	1A
Number of inputs Signal inputs via optocoupler	<p>2</p> <p>Low = 0...7V DC or open</p> <p>High = 15...30V DC</p> <p>I_{in} at 24V DC: 8mA</p>
STO1/	<p>Low = STO activated</p> <p>High = STO deactivated</p> <p>Reaction time max. 3ms</p>
STO2/	<p>Low = STO activated</p> <p>High = STO deactivated</p> <p>Reaction time max. 3ms</p>
Switch-off time with unequal input statuses (max. reaction time)	20 seconds
Grouping of safety level	<p>Category 3</p> <p>PL=e</p> <p>(according to table 4 in EN ISO 13849-1 this corresponds to SIL 3)</p> <p>PFHd=4.29E-8</p>

UL certification for Compax3S

conform to UL:	◆ according to UL508C
Certified	◆ E-File_No.: E235342

The UL certification is documented by a "UL" logo on the device (type specification plate).



UL-approval for PSUP/Compax3M

conform to UL:	◆ according to UL508C
Certified	◆ E-File_No.: E235342

The UL certification is documented by a "UL" logo on the device (type specification plate).



Insulation requirements

Enclosure rating	Protection class in accordance with EN 60664-1
Protection against human contact with dangerous voltages	In accordance with EN 61800-5-1
Overtoltage category	Voltage category III in accordance with EN 60664-1
Degree of contamination	Degree of contamination 2 in accordance with EN 60664-1 and EN 61800-5-1

Environmental conditions Compax3S and Compax3H

General ambient conditions	In accordance with EN 60 721-3-1 to 3-3 Climate (temperature/humidity/barometric pressure): Class 3K3	
Permissible ambient temperature:		
Operation	0 to +45 °C	class 3K3
storage	-25 to +70 °C	class 2K3
transport	-25 to +70 °C	class 2K3
Tolerated humidity:	no condensation	
Operation	<= 85% class 3K3	(Relative humidity)
storage	<= 95% class 2K3	
transport	<= 95% class 2K3	
Elevation of operating site	<=1000m above sea level for 100% load ratings <=2000m above sea level for 1% / 100m power reduction please inquire for greater elevations	
Mechanic resonances:	EN 60068-2-6 (sinusoidal excitation)	
Sealing	Protection type IP20 in accordance with EN 60 529	

Cooling Compax3S and Compax3H

Cooling mode:	C3S025V2 ... S150V4: Convection C3S300V4 & C3H: Forced air ventilation with fan in the heat dissipator Air flow rate: 459m ³ /h (C3H)
Supply:	C3S300V4, C3H050, C3H090 internal C3H125, C3H155 external 220/240VAC: 140W, 2.5μF, Stator - 62Ω Optionally on request: 110/120VAC: 130W, 10μF, Stator - 16Ω Circuit breaker: 3A

EMC limit values Compax3S and Compax3H

EMC interference emission	Limit values in accordance with EN 61 800-3, Limit value class C3/C4 without additional mains filter: Information on C2 limit value classes (see on page 19)
EMC disturbance immunity	Industrial area limit values in accordance with EN 61 800-3

Ambient conditions PSUP/Compax3M

General ambient conditions	In accordance with EN 60 721-3-1 to 3-3 Climate (temperature/humidity/barometric pressure): Class 3K3	
Permissible ambient temperature:	Class 3K3	
Operation	0 to +40 °C	Class 3K3
storage	-25 to +70 °C	
transport	-25 to +70 °C	
Tolerated humidity:	no condensation	
Operation	<= 85% class 3K3	(Relative humidity)
storage	<= 95%	
transport	<= 95%	
Elevation of operating site	<=1000m above sea level for 100% load ratings <=2000m above sea level for 1% / 100m power reduction please inquire for greater elevations	
Sealing	Protection type IP20 in accordance with EN 60 529	
Mechanic resonances:	Class 2M3, 20m/s ² ;8-200Hz	

Cooling PSUP/Compax3M

Cooling mode:	Forced air ventilation with fan in the heat dissipator
----------------------	--

EMV limit values PSUP/Compax3M

EMC interference emission	Limit values in accordance with EN 61 800-3, Limit value class C3 with mains filter.
EMC disturbance immunity	Industrial area limit values in accordance with EN 61 800-3

EC directives and applied harmonized EC norms

EC low voltage directive 2006/95/EG	<p>EN 61800-5-1, Standard for electric power drives with settable speed; requirements to electric safety</p> <p>EN 60664-1, isolation coordinates for electrical equipment in low-voltage systems</p> <p>EN 60204-1, machinery norm partly applied</p>
EC-EMC-directive 2004/108/EC	<p>EN 61800-3, EMC standard</p> <p>Product standard for variable speed drives</p>

COM ports

RS232	<ul style="list-style-type: none"> ◆ 115200 baud ◆ Word length: 8 bits, 1 start bit, 1 stop bit ◆ Hardware handshake XON, XOFF
RS485 (2 or 4-wire)	<ul style="list-style-type: none"> ◆ 9600, 19200, 38400, 57600 or 115200 baud ◆ Word length 7/8 bit, 1 start bit, 1 stop bit ◆ Parity (can be switched off) even/odd ◆ 2 or 4-wire
USB (Compax3M)	<ul style="list-style-type: none"> ◆ USB 2.0 Full Speed compatible

Load position control

Dual Loop Option	<ul style="list-style-type: none"> ◆ 2. Feedback system for load position control (see on page 161) possible.
-------------------------	---

Signal interfaces

Signal inputs / signal sources	<ul style="list-style-type: none"> ◆ Encoder input track A/B (RS422) <ul style="list-style-type: none"> ◆ up to max. 10MHz ◆ Internal quadrature of the resolution ◆ Step / direction input (24V-level) <ul style="list-style-type: none"> Max. 300kHz at $\geq 50\Omega$ source impedance and minimum pulse width of 1.6μs. ◆ +/-10V analog input <ul style="list-style-type: none"> 14Bit; 62.5μs scanning rate. ◆ SSI - feedback
Signal outputs	<ul style="list-style-type: none"> ◆ Encoder simulation <ul style="list-style-type: none"> ◆ 1...16384 increments/revolution or pitch ◆ Limit frequency 620kHz (track A or B) ◆ Bypass function for encoder feedback with feedback module F12.(Limit frequency 5MHz, track A or B).
Signal transmission	<p>HEDA (Option M10 or M11)</p> <p>Transfer of process values:</p> <ul style="list-style-type: none"> ◆ from Slave to Master ◆ from Slave to Master and ◆ from Slave to Slave.

DeviceNet characteristics (I22)

DeviceNet	<ul style="list-style-type: none"> ◆ Predefined Master/Slave Connection Set ◆ Standard 2.0 Group-2-Slave ◆ Fieldbus I/O Data or Process Data (Polled, COS/Cyclic I/O and Bit Strobe)
Implemented object classes	<ul style="list-style-type: none"> ◆ Identify, Message Router, DeviceNet, Assembly, Connection, Acknowledge Handler
Baud rate [kBit/s]	<ul style="list-style-type: none"> ◆ 125, 250, 500
permissible cable length	<ul style="list-style-type: none"> ◆ up to 500m on 125Bit/s, ◆ up to 200m on 250Bit/s, ◆ up to 100m on 500Bit/s,
Max. Number of participants	<ul style="list-style-type: none"> ◆ 63 Slave
Insulation	<ul style="list-style-type: none"> ◆ Isolated Device Physical Layer
EDS file	<ul style="list-style-type: none"> ◆ C3_DeviceNet.EDS
Conformance (file in the Internet)	<ul style="list-style-type: none"> ◆ Statement of Conformance http://www.compax3.de/C3_DeviceNet_Statement_of_Conformance.pdf
Further information:	<ul style="list-style-type: none"> ◆ Application example (C3I22_DeviceNet.ZIP) on the Compax3 CD in the "\Examples" directory"

Functions

Operating modes:	<ul style="list-style-type: none"> ◆ Speed control ◆ Direct positioning (position control) ◆ Positioning with set selection
Speed control	<ul style="list-style-type: none"> ◆ Cyclic predefined Setpoint value ◆ Up to 2 cyclic actual values
Direct positioning	<ul style="list-style-type: none"> ◆ Cyclic predefined Setpoint value ◆ Cyclic actual values ◆ Different motion functions
Positioning with set selection	<ul style="list-style-type: none"> ◆ up to 31 motion sets possible. ◆ Different motion functions
Motion functions	<ul style="list-style-type: none"> ◆ Absolute positioning ◆ Relative positioning ◆ Electronic Gearbox (Gearing) ◆ Reg-related positioning (exactitude < 1µs) ◆ Speed control ◆ Stop - Set ◆ Defining status bits for the sequence control ◆ Specification of speed, acceleration, deceleration and jerk ◆ Different machine zero modes ◆ Absolute / continuous operation
Actual position	<ul style="list-style-type: none"> ◆ Encoder simulation ◆ Resolution: 1 - 16384 increments / revolution
Signal monitor	<ul style="list-style-type: none"> ◆ 2 channels ±10 V analog ◆ Resolution: 8 Bit

11. Index

+

+/-10V analog speed setpoint value as signal source • 160

A

Absolute encoder • 117
 Acceleration / deceleration for positioning • 136
 Acceleration for positioning and velocity control • 136
 Access to the hazardous area • 90, 94
 Activation • 255
 Additional conditions of utilization • 21
 Adjusting the basic address • 64
 Adjusting the bus address • 65
 Adjusting the machine zero proximity switch • 131
 Advanced • 215
 Advantages of using the • 81
 Alignment of the analog inputs • 251
 Analog Inputs/Outputs • 341
 Analogue / encoder (plug X11) • 68
 Analyses in the time range • 257
 Application parameters • 178
 Approximation of a well-attenuated control loop • 199
 ASCII - record • 304
 Assignment of the different motion functions • 317
 Assignment of the X22 connector • 388
 Asynchronous motors • 193
 Extension of the controller structure • 196
 Attenuation of the excitation amplitude • 267
 Automated controller design • 207
 Automatic controller design • 197

B

Ballast resistor • 36, 111, 402
 Ballast resistor BRM13/01 & BRM14/01 • 378
 Ballast resistor BRM4/0x and BRM10/02 • 377
 Bandwidth filter 1 (O2150.2) / bandwidth filter 2 (O2150.5) • 228
 Basic functions: • 93
 Basic structure of the control with Compax3 • 176
 Basics of frequency response measurement • 284
 Binary record • 305
 Bit sequence V2 • 339
 Boundary conditions • 248
 Brake delay times • 292
 Braking resistor / high voltage DC C3S connector X2 • 36
 Braking resistor / high voltage supply connector X2 for 3AC 400VAC/480VAC_C3S devices • 39

Braking resistor / high voltage supply plug X2 for 1AC 230VAC/240VAC devices • 36
 Braking resistor / high voltage supply plug X2 for 3AC 230VAC/240VAC devices • 37
 Braking resistor / supply voltage C3H • 60
 Braking resistor / temperature switch PSUP (mains module) • 49
 Braking resistor BRM11/01 & BRM12/01 • 377
 Braking resistor BRM5/02, BRM9/01 & BRM10/01 • 376
 BRM10/02 • 365, 370, 377
 BRM5/01 braking resistor • 376
 BRM8/01braking resistors • 376
 Bus format Y2 and Y4 • 338
 Byte string OS • 339

C

C3 ServoSignalAnalyzer • 253
 C3 settings for RS485 four wire operation • 302
 C3 settings for RS485 two wire operation • 301
 Calculation of the BRM cooling time • 367
 Calculation of the reference current from the characteristic line. • 181
 Calling up the input simulation • 244
 Capacitors • 15
 Cascade control • 203
 Cascade structure of Compax3 • 204
 Change assignment direction reversal / limit switches • 135
 Change initiator logic • 135
 Changing the switching frequency and the reference point • 192
 Characteristics of a control loop setpoint response • 202
 Circuit layout overview • 87
 Circuit: • 88, 92
 COM port protocol • 303
 Commissioning window • 230
 Communication • 293
 Communication Compax3M • 63
 Communication in the axis combination (connector X30, X31) • 63
 Communication interfaces • 62
 Commutation settings • 186
 Commutation settings of the automatic commutation • 222
 Compa3 communication variants • 293
 Compax3 Accessories • 348
 Compax3 device description • 28
 Compax3 Xxx I22T11 Introduction • 26
 Compax3H connections front plate • 56
 Compax3H plugs/connections • 53
 Compax3M STO application description • 98
 Compax3S connectors • 30
 Compax3Sxxx V2 • 35
 Compax3Sxxx V4 • 38

Condenser module C4 • 379
 Conditions of utilization • 19
 Conditions of utilization for cables / motor filter • 20
 Conditions of utilization for CE-conform operation • 19
 Conditions of utilization for the STO function with Compax3M • 96
 Conditions of utilization for UL certification Compax3H • 24
 Conditions of utilization for UL certification Compax3M • 23
 Conditions of utilization for UL certification Compax3S • 22
 Conditions of utilization mains filter • 19
 Conditions of utilization STO (=safe torque off) Safety function • 85
 Configuration • 105, 179
 Configuration name / comments • 155
 Configuration of load control • 163
 Configuration of local modem 1 • 309
 Configuration of remote modem 2 • 310
 Configuring the signal Source • 157
 Connect braking resistor C3H • 60
 Connection of a braking resistor • 37, 39
 Connection of terminal box MH145 & MH205 • 363
 Connection of the digital Outputs/Inputs • 70
 Connection of the power voltage • 54
 Connection of the power voltage of 2 C3H 3AC devices • 61
 Connection of the power voltage of 2 C3S 3AC devices • 39
 Connections of Compax3H • 53
 Connections of Compax3S • 30
 Connections of the axis combination • 44
 Connections of the encoder interface • 68
 Connections on the device bottom • 43
 Connections to the motor • 359
 Connector and pin assignment C3S • 31
 Control measures for drives involving friction • 229
 Control path • 179
 Control structures • 210, 216, 217
 Control signal filter / filter of actual acceleration value • 215
 Control signal limitations • 211
 Control voltage 24 VDC • 33
 Control voltage 24 VDC C3H • 59
 Control voltage 24VDC / enable connector X4 C3S • 33
 Control voltage 24VDC PSUP (mains module) • 45
 Control word 1 (Controlword 1) • 318
 Control word 2 • 320
 Controller coefficients • 208
 Controller optimization • 176
 Controller optimization Advanced • 238
 Controller optimization disturbance and setpoint behavior (advanced) • 237
 Controller optimization disturbance and setpoint behavior (standard) • 234

Controller optimization guiding transmission behavior • 240
 Controller optimization of toothed belt drive • 236
 Controller optimization standard • 235
 Controlword /Statusword • 318
 Correlation between the terms introduced • 206
 Course of the automatic commutation function • 224
 Cubical interpolation (o3925.1=-3) • 325
 Current (Torque) Limit • 139
 Current control • 271
 Current jerk response • 228
 Current jerk response with the activated saturation characteristic line • 229
 Current on the mains PE (leakage current) • 25
 Cut-off frequency for the field weakening range • 195

D

D/A-Monitor • 341
 Data formats of the bus objects • 337
 Deadband following error • 229
 Debouncing
 Limit switch, machine zero and input 0 • 135
 Defining jerk / ramps • 136
 Defining the reference system • 112
 Definition of the states of the programmable status bits (PSBs): • 318
 Demand behavior • 201
 Depth filter 1 (O2150.3) / depth filter 2 (O2150.6) • 228
 Description of jerk • 136
 Detailed object list • 336
 Determination of the commutation settings • 196
 Device assignment • 11
 DeviceNet • 311
 DeviceNet application description • 340
 DeviceNet Configuration • 311
 DeviceNet connector X23 • 65
 DeviceNet object classes • 329
 DeviceNet Operating modes • 312
 Devices with the STO (=safe torque off) safety function • 82
 Digital inputs/outputs • 70
 Digital inputs/outputs (plug X12) • 69
 Dimensions of the braking resistors • 376
 Direct drives • 348
 Display of the commutation error in incremental feedback systems • 223
 Display of the measurement point at the cursor position • 283
 Display of the measurement result • 281
 Distinction between signals and systems • 284
 Disturbance behavior • 202
 Disturbance jerk response • 206
 D-term • 207
 D-term of the KD velocity controller • 208
 Dynamic positioning • 155
 Dynamic stiffness • 205

Dynamics of a control • 197

E

EAM06

Terminal block for inputs and outputs • 381

Effect of the notch filter • 226

Electronic gearbox (Gearing) • 153

Electronic simulation of a disturbance torque
jerk with the disturbance current jerk • 205

EMC feedforward • 219

EMC measures • 351

Emergency stop and protective door
monitoring without external safety switching
device. • 101

Encoder A/B 5V, step/direction or SSI
feedback as signal source • 158

Encoder bypass with Feedback module F12
(for direct drives) • 142

Encoder cable • 364

Encoder coupling of 2 Compax3 axes • 386

Encoder simulation • 142

EnDat cable • 362

Energize and deenergize circuitry • 99

Error • 342

Position difference between load mounted and
motor feedback too high • 164

Error list • 342

Error Reaction on Bus Failure • 311

Error response • 154

ETHERNET-RS485 NetCOM 113 adapter •
299

Example

Electronic gearbox with position detection via
encoder • 158

Setting the Oscilloscope • 174

Example 1

Reg comes after the reg restriction window •
149

Example 2

Reg within the reg restriction window • 150

Example 3

Reg is missing or comes after termination of
the RegSearch motion set • 150

Example 4

Reg comes before the reg restriction window •
151

Example 5

The registration mark comes after the reg
restriction window, registration mark can,
however, not be reached without direction
reversal • 152

Examples are available as a movie in the help
file • 289

Examples in the help file • 145

Excitation Signal • 266

Extended cascade (structure variant 1) • 216

Extended cascade structure (structure variant
2 with disturbance variable observer) • 217

External braking resistors • 365

External Moment of Inertia • 192

external position correction • 161

External setpoint generation • 232

F

Feedback error compensation • 185

Feedforward channels • 213

Ferrite • 34

Filter • 219

Fixed point format C4_3 • 338

Fixed point format E2_6 • 337

Flow chart controller optimization of a direct
drive • 239

Following Error (Position Error) • 190

Following error limit • 140

Frequency filter 1 (O2150.1) / frequency filter 2
(O2150.4) • 227

Frequency response of the notch filter. • 227

Frequency response of the P-TE component
(value and phase) • 201

Frequency settings • 275

Friction compensation • 230

Front connector • 42

Function description for fieldbus applications
with T11 devices: • 100

Function of the Bus LEDs • 66

Function principle of the automatic
commutation with movement • 224

Functionality of the measurement • 260, 263

G

Gain alignment • 251

General Description • 80

General drive • 111

General hazards • 16

General layout of the table • 317

H

Hardware end limits • 134

HEDA (motion bus) - Option M11 • 389

Homing modes with home switch (on X12/14) •
120

I

I/O Assignment • 142

I/O interface X12 / X22 • 385

I²t - monitoring of the motor • 186

Ignore zone (example) • 146

Important terms and explanations • 80

Increased following error • 184

Influence of the feedforward measures • 213

Input simulation • 244

Input wiring of digital inputs • 389

Input/output option M12 • 388

Instable behavior • 184

Installation • 255

Installation and dimensions Compax3 • 71

Installation enable of the ServoSignalAnalyzer
• 255

Installation instructions Compax3M • 40

Integer formats • 337

Intended use • 81

Interface • 183

Interface cable • 383

Internal setpoint generation • 230

Interpolated Position / Cyclic Synchronous
 Position Mode • 321
 Interpolation method • 322
 Introduction • 11, 176
 Introduction observer • 220

J

Jerk for STOP, MANUAL and error • 138
 Jerk limit for positioning • 136
 Jerk value • 136

K

Konformität • 311

L

Layout of the set table • 317
 Leak effect and windowing • 261
 LEDs • 28, 29
 Level • 70
 Limit and monitoring settings • 139, 192
 Limitation behavior • 203
 Limitation of the control voltage • 212
 Limitation of the setpoint current • 212
 Limitation of the setpoint velocity • 212
 Linear Interpolation (o3925.1 = 0 or o3925.1 = -1) • 323
 Linear motors • 350
 Linear Systems (LTI System) • 285
 Linear two mass system • 288
 Linearized motor characteristic lien for different operating points • 187
 Load control • 161, 220
 Load control signal image • 164
 Load identification • 230, 248
 Logic proximity switch types • 70
 Luenberg observer • 220

M

Machine Zero • 115
 Machine zero modes overview • 118
 Machine zero modes without home switch • 126
 Machine zero only from motor reference • 128
 Machine zero speed and acceleration • 131
 Main flow chart of the controller optimization • 233
 Main voltage supply C3S connector X1 • 35
 Mains connection Compax3H • 59
 Mains filter • 351
 Mains filter for NFI01/03 • 353
 Mains filter for PSUP30 • 358
 Mains filter NFI01/01 • 352
 Mains filter NFI01/02 • 352
 Mains filter NFI02/0x • 353
 Mains filter NFI03/01& NFI03/03 • 354
 Mains filter NFI03/02 • 355
 Mains filters • 358
 Mains supply PSUP (mains module) X41 • 46
 Manufacturer-specific object class • 331
 Mass inertia • 180
 Maximum operating speed • 141

Meaning of the status LEDs - Compax3 axis controller • 28
 Meaning of the status LEDs - PSUP (mains module) • 29
 Measure reference • 112
 Measurement of frequency responses • 263
 Measurement of frequency spectra • 260
 Measurement of the motor temperature of Compax3M (axis controller) • 51
 Mechanical system • 272, 286
 MN-M 1,2
 Limit switch as machine zero • 130
 MN-M 11...14
 With direction reversal switches on the negative side • 125
 MN-M 128/129
 Stromschwelle while moving to block • 126
 MN-M 130, 131
 Acquire absolute position via distance coding • 128
 MN-M 132, 133
 Determine absolute position via distance coding with direction reversal switches • 130
 MN-M 17,18
 Limit switch as machine zero • 127
 MN-M 19,20
 MN-Initiator = 1 on the positive side • 120
 MN-M 21,22
 MN Initiator = 1 on the negative side • 121
 MN-M 23...26
 Direction reversal switches on the positive side • 122
 MN-M 27...30
 Direction reversal switches on the negative side • 122
 MN-M 3,4
 MN-Initiator = 1 on the positive side • 123
 MN-M 33,34
 MN at motor zero point • 128
 MN-M 35
 MN (machine zero) at the current position • 126
 MN-M 5,6
 MN-Initiator = 1 on the negative side • 124
 MN-M 7...10
 Direction reversal switches on the positive side • 125
 Mode 1
 Time and maximum values are deduced from Compax3 input values • 290
 Mode 2
 Compax3 input values are deduced from times and maximum values • 291
 Modem cable SSK31 • 387
 Modem MB-Connectline MDH 500 / MDH 504 • 300
 Monitor information • 168
 Motion cycle with feedforward measures • 214
 Motion cycle without feedforward control • 214
 Motion functions • 148
 Motion objects in Compax3 • 247

Motion profile at jerk-controlled setpoint generation • 231
 Motion set • 247
 Motor / Motor brake (C3S connector X3) • 34
 Motor / Motor brake C3H • 58
 Motor / motor brake Compax3M (axis controller) • 50
 Motor cable • 362
 Motor characteristic line of a synchronous servo motor (torque via velocity) • 181
 Motor Connection • 34
 Motor continuous usage • 187
 Motor holding brake • 34
 Motor output filter • 356
 Motor output filter MDR01/01 • 356
 Motor output filter MDR01/02 • 357
 Motor output filter MDR01/04 • 356
 Motor parameters • 191, 219
 Motor parameters relevant for the control • 180
 Motor pulse usage • 188
 Motor reference point • 192
 Motor selection • 107
 Motor types supported • 192
 Mounting and dimensions C3H • 77
 Mounting and dimensions Compax3S • 71
 Mounting and dimensions Compax3S0xxV2 • 71
 Mounting and dimensions Compax3S100V2 and S0xxV4 • 72
 Mounting and dimensions Compax3S150V2 and S150V4 • 73
 Mounting and dimensions Compax3S300V4 • 74
 Mounting and dimensions PSUP/C3M • 75
 Mounting and dimensions PSUP10/C3M050D6, C3M100D6, C3M150D6 • 75
 Mounting and dimensions PSUP20/PSUP30/C3M300D6 • 76
 Mounting distances, air currents Compax3H050V4 • 78
 Mounting distances, air currents Compax3H090V4 • 78
 Mounting distances, air currents Compax3H1xxV4 • 79
 MoveAbs and MoveRel • 148

N

Noise • 183
 Nominal point • 187
 Nominal point data • 181
 Non-linearities and their effects • 267
 Notch filter • 226
 Note on error switch-off • 86
 Notes on the STO function • 85

O

Object classes • 330
 Object for the load control (overview) • 165
 Objects for load control • 165
 Offset alignment • 251

Open/Closed Loop frequency response measurement • 265
 Operating and status field • 280
 Operating mode
 Cyclic Synchronous Position • 322
 Direct positioning • 314
 Positioning with set selection • 316
 Speed control • 313
 Operating Principle • 245
 Operation with MultiTurn emulation • 117
 Operator control module BDM • 380
 Optimization • 166
 Optimization parameter Advanced • 219
 Optimization window • 167
 Optimize motor reference point and switching frequency of the motor current • 108
 Option M10 = HEDA (M11) & I/Os (M12) • 391
 Options M1x • 388
 Order code • 343
 Order code device
 Compax3 • 343
 Order code for accessories • 344
 Order code for mains module
 PSUP • 344
 Oscillating plant • 197
 Oscilloscope operating mode switch: • 170
 Other • 226
 Other motor • 191
 Other settings • 277
 Output wiring of digital outputs • 389
 Overview of the DeviceNet object classes • 330
 Overview of the manufacturer-specific object class C3 objects (65hex) • 331
 Overview of the user interface • 270

P

Packaging, transport, storage • 14
 Parameterization by 3 objects. • 227
 Parker Motor • 191
 Parker servo motors • 348
 Path optimized positioning • 144
 PC - PSUP (Mains module) • 63
 PC <-> C3M device combination (USB) • 297
 PC <-> Compax3 (RS232) • 294
 PC <-> Compax3 (RS485) • 296
 Permissible braking pulse power
 BRM04/01 with C3S150V2 • 372
 BRM04/01 with C3S300V4 • 372
 BRM04/02 with C3S150V2 • 373
 BRM04/02 with C3S300V4 • 373
 BRM04/03 with C3S300V4 • 374
 BRM05/01 with C3S063V2 • 370
 BRM05/01 with C3S075V4 • 371
 BRM05/02 with C3S075V4 • 371
 BRM08/01 with C3S015V4 / C3S038V4 • 368
 BRM08/01 with C3S025V2 • 368
 BRM09/01 with C3S100V2 • 369
 BRM10/01 with C3S150V4 • 369
 BRM10/02 with C3S150V4 • 370
 BRM11/01 with C3H0xxV4 • 374
 BRM12/01 with C3H1xxV4 • 375

- BRM13/01 with PSUP10D6 • 375
- BRM14/01 with PSUP10D6 • 375
- Permissible braking pulse powers of the braking resistors • 366
- Plug and pin assignment C3H • 56
- Plug assignment Compax3S0xx V2 • 33, 34, 35, 36, 62, 67
- Position control • 273
- Position correction • 161
- Position loop • 207
- Position measurement external • 161
- Position mode in reset operation • 144
- Positioning after homing run • 115, 116
- Positioning window - Position reached • 139
- Power supply • 35
- Power supply connector X1 for 3AC 400VAC/480VAC-C3S devices • 38
- Power supply plug X1 for 1 AC 230VAC/240VAC devices • 35
- Power supply plug X1 for 3AC 230VAC/240VAC devices • 35
- Power supply voltage DC C3H • 60
- Prerequisites • 255
- Prerequisites for the automatic commutation • 224
- Principle • 248
- Proceeding during configuration, setup and optimization • 176
- Proceeding during controller optimization • 232
- Process of the automatic determination of the load characteristic value (load identification) • 249
- ProfileViewer for the optimization of the motion profile • 290
- Programmable status bits (PSBs) • 147
- PSUP/Compax3M Connections • 42
- P-TE - Symbol • 199
- P-term KV position loop • 208

Q

- Quadratic interpolation (o3925.1=-2) • 324
- Quality of different feedback systems • 183

R

- Ramp upon error and de-energize • 138
- Recommendations for preparing the modem operation • 310
- Reduction of the current ripple • 190
- Ref X11 • 385
- Reference point 1
 - higher velocity at reduced torque • 188
- Reference point 2
 - Increased torque thanks to additional cooling • 189
- Reg-related positioning (RegSearch, RegMove) • 149
- Reg-related positioning / defining ignore zone • 146
- Relevant application parameters • 189
- Remote diagnosis via Modem • 308
- Replacement switching diagram - data for a phase • 193

- Resolution • 183
- Resolver • 67
- Resolver / feedback (plug X13) • 67
- Resolver cable • 360
- Resonance points and their causes • 287
- Response • 203
- Rigidity • 204
- Rotary servo motors • 350
- Rotary two mass system • 288
- Rotor time constant • 196
- RS232 cable • 383
- RS232 plug assignment • 62
- RS232/RS485 interface (plug X10) • 62
- RS485 cable to Pop • 384
- RS485 plug assignment • 62
- RS485 settings values • 303

S

- Safe torque off • 80
- Safe torque off basic function • 89
- Safe torque off description • 89, 93
- Safe torque off layout with bus • 91
- Safety function - STO (=safe torque off) • 80
- Safety instructions • 16
- Safety instructions concerning the frequency response measurement • 263
- Safety notes for the STO function in the Compax3M • 96
- Safety switching circuits • 95
- Safety technology option for Compax3M (axis controller) • 52
- Safety-conscious working • 16
- Saturation behavior • 195, 228
- Saturation values • 182
- Scope • 168
- Scope of delivery • 12
- Select signal source for Gearing • 157
- Selection of the signal or system to be measured. • 270
- Selection of the supply voltage used • 107
- ServoSignalAnalyzer - function range • 253
- Setpoint and disturbance behavior of a control loop • 201
- Setpoint generation • 230
- Setting the axis function • 64
- Setting the time basis XDIV • 170
- Setting up Compax3 • 105
- Settings for channels 1..4 • 171
- Setup and optimization of the control • 209
- Setup mode • 246
- Shifting the working point into a linear range • 268
- Signal analysis overview • 254
- Signal filtering for external setpoint specification and electronic cam • 242
- Signal filtering for external setpoint specification and electronic gearbox • 241
- Signal filtering with external command value • 241
- Signal flow chart Luenberg observer • 221
- Signal interfaces • 67
- Signal processing of the analog input 0 • 160

- Signal processing of the analog inputs • 252
 - Signal source HEDA • 158
 - Signal source of the load feedback system • 157
 - SinCos© cable • 361
 - Slip • 161
 - Slip Frequency • 194
 - Software end limits • 132
 - Software for supporting the configuration, setup and optimization • 177
 - Special functions • 172
 - Special safety instructions • 17
 - Speed control • 275
 - Speed for positioning and velocity control • 136
 - Speed specification (Velocity) • 154
 - Stability problem in the high-frequency range: • 198
 - Stability problem in the low-frequency range: • 198
 - Stability, attenuation • 197
 - Standard • 209
 - Standard cascade structure • 210
 - Standard optimization parameters • 211
 - State machine • 327
 - Static stiffness • 204
 - Status LEDs • 28, 29
 - Status values • 341
 - Status word 1 (Status word) • 321
 - Status word 2 • 321
 - Step response of a delay component • 199
 - Step response of the velocity loop depending on the optimization parameter • 207
 - STO (= safe torque off) with Compax3m (Option S1) • 95
 - STO (= safe torque off) with Compax3S • 83
 - STO application example (= safe torque off) • 87
 - STO delay times • 84, 97
 - STO function test • 102
 - STO function with safety switching device for T11 applications with fieldbusses • 99
 - STO function with safety switching device via Compax3M inputs • 98
 - STO Principle (= Safe Torque Off) with Compax3S • 83
 - STO test protocol specimen • 103
 - Stop command (Stop) • 154
 - Storage • 15
 - Structure • 308
 - Structure of a cascade control • 204
 - Structure of a control • 197
 - Supply networks • 25
 - Switching frequency of the motor current / motor reference point • 190
 - Synchronizations method • 325
- T**
- Teach machine zero • 126
 - Technical Characteristics • 392
 - Technical Characteristics STO Compax3S • 90, 94
 - Technical details of the Compax3M S1 option • 104
 - Temperature switch PSUP (mains module) • 50
 - Test commissioning of a Compax3 axis • 107
 - Test functions • 202
 - The calculation of the physically possible acceleration • 231
 - Time function and power density spectrum of Compax3 setpoint generator with different jerk settings • 232
 - Tips • 250
 - Too high overshoot on velocity • 184
 - Toothed belt drive as two mass system • 289
 - Toroidal core ferrite • 34
 - Torque motors • 350
 - Tracking filter • 241
 - Traditional generation of a disturbance torque/force jerk • 205
 - Transmitter systems for direct drives • 349
 - Travel Limit Settings • 132
 - Trigger settings • 172
 - Turning the motor holding brake on and off • 292
 - Type specification plate • 13
 - Type specification plate data • 193
 - Typical problems of a non optimized control • 184
- U**
- Unsigned - Formats • 337
 - Usage in accordance with intended purpose • 16
 - USB - RS232 converter • 62
 - USB-RS485 Moxa Uport 1130 adapter • 298
 - User interface • 169
- V**
- Velocity Loop P Term • 208
 - Velocity, bandwidth • 198
 - Voltage decoupling • 220
- W**
- Warranty conditions • 18
 - Wiring of analog interfaces • 68
 - Wiring of the motor output filter • 357
 - With direction reversal switches • 121, 124, 129
 - With motor reference point • 123, 128
 - With upper mounting, the housing design may be different • 76
 - Without direction reversal switches • 120, 123
 - Without motor reference point • 120, 126
 - Write into set table • 147
 - Wrongly set notch filter • 227
- X**
- X1 • 35
 - X10 • 62
 - X11 • 68
 - X13 • 67

X2 • 36

X3 • 34

X4 • 33

Z

Zeitraster Signalquelle Master • 160

